### Group 4 - 翁堉豪 312551076 / 張紀睿 312551086

以下是Lab5 進行 Cross-compile 的具體步驟:

## 前置準備

### 創建安裝目錄:

創建新的目錄分別用來存儲安裝包與編譯後的檔案。

mkdir -p ~/cross-compile mkdir ~/cross-compile/build

### 下載並解壓縮軟體包:

下載所需的軟體包(alsa-lib, alsa-utils, zlib, libid3tag, libmad, madplay), 並將它們解壓縮到一個工作目錄中。

tar xvf alsa-lib-1.0.26.tar.bz2 -C ~/cross-compile

tar xvf alsa-utils-1.0.26.tar.bz2 -C ~/cross-compile

tar xvf zlib-1.2.3.tar.gz -C ~/cross-compile

tar xvf libid3tag-0.15.1b.tar.gz -C ~/cross-compile

tar xvf libmad-0.15.1b.tar.gz -C ~/cross-compile

tar xvf madplay-0.15.2b.tar.gz -C ~/cross-compile

### 設定環境變數:

這將幫助指定交叉編譯工具鏈和安裝位置。您需要設定的環境變數包括 CC(C 編譯器), CXX(C++ 編譯器), LD(連結器), 以及 --prefix 參數所指定的安裝目錄。

#### export

 $\label{lem:cc-def} CC=/opt/EmbedSky/gcc-linaro-5.3-2016.02-x86\_64\_arm-linux-gnueabihf/bin/arm-linux-gnueabihf-gcc$ 

#### export

CXX=/opt/EmbedSky/gcc-linaro-5.3-2016.02-x86\_64\_arm-linux-gnueabihf/bin/arm-linux-gnueabihf-g++

#### export

LD=/opt/EmbedSky/gcc-linaro-5.3-2016.02-x86\_64\_arm-linux-gnueabihf/bin/arm-linux-gnueabihf-ld

export PREFIX=~/cross-compile/build

## alsa-lib

### 進入 alsa-lib 目錄:

cd ~/cross-compile/alsa-lib-1.0.26

#### 配置 alsa-lib:

./configure --host=arm-linux-gnueabihf --prefix=\$PREFIX \

- --enable-shared --disable-python \
- --with-configdir=/usr/local/share/alsa \
- --with-plugindir=/usr/local/lib/alsa\_lib \

CC=\$CC CXX=\$CXX LD=\$LD

### 編譯並安裝 alsa-lib:

make

sudo make install

## alsa-utils

### 切換到 alsa-utils 的目錄:

cd ~/cross-compile/alsa-utils-1.0.26

### 配置 alsa-utils:

./configure --host=arm-linux-gnueabihf \

--prefix=\$PREFIX \

CFLAGS="-I\$PREFIX/include" \

LDFLAGS="-L\$PREFIX/lib -lasound" \

- --disable-alsamixer --disable-xmlto \
- --with-alsa-inc-prefix=\$PREFIX/include \
- --with-alsa-prefix=\$PREFIX/lib \

CC=\$CC CXX=\$CXX LD=\$LD

## 編譯並安裝 alsa-utils:

make

sudo make install

### zlib

### 切換到 zlib 的目錄:

cd ~/cross-compile/zlib-1.2.3

#### 配置 zlib 並加入 -fPIC:

CFLAGS="-O3 -fPIC" ./configure --prefix=\$PREFIX

### 修改 Makefile 以使用交叉編譯工具:

```
sed -i 's/CC=gcc/CC=arm-linux-gnueabihf-gcc/g; \
s/LDSHARED=gcc -shared -Wl,-soname,libz.so.1/LDSHARED=arm-linux-gnueabihf-gcc
-shared -Wl,-soname,libz.so.1/g; \
s/CPP=gcc -E/CPP=arm-linux-gnueabihf-gcc -E/g; \
s/AR=ar rc/AR=arm-linux-gnueabihf-ar rc/g; \
s/RANLIB=ranlib/RANLIB=arm-linux-gnueabihf-ranlib/g' Makefile
```

### 編譯並安裝 zlib:

make sudo make install

# libid3tag

## 切換到 libid3tag 目錄:

cd ~/cross-compile/libid3tag-0.15.1b

## 配置 libid3tag:

```
./configure --host=arm-linux-gnueabihf \
--prefix=$PREFIX \
CPPFLAGS=-I$PREFIX/include \
LDFLAGS=-L$PREFIX/lib \
CC=$CC
```

## 編譯並安裝 libid3tag:

make sudo make install

## libmad

### 進入 libmad 的目錄:

cd ~/cross-compile/libmad-0.15.1b

#### 配置 libmad:

```
./configure --host=arm-linux-gnueabihf \
--prefix=$PREFIX \
CPPFLAGS="-I$PREFIX/include" \
LDFLAGS="-L$PREFIX/lib" \
CC=$CC
```

### 編輯 Makefile 以移除 -fforce-mem 選項(因為新版本的GCC不再支持):

sed -i 's/-fforce-mem//g' Makefile

### 將fixed.h中的下方段落替換:

```
# define MAD_F_MLN(hi, lo) \
    asm ("rsbs %0, %2, #0\n\t" \
        "rsc %1, %3, #0" \
        : "=r" (lo), "=r" (hi) \
        : "0" (lo), "1" (hi) \
        : "cc")
```

```
替換為:
#ifdef __thumb__
/* In Thumb-2, the RSB-immediate instruction is only allowed with a zero
operand. If needed this code can also support Thumb-1
(simply append "s" to the end of the second two instructions). */
# define MAD_F_MLN(hi, lo) \
asm ("rsbs %0, %0, #0\n\t" \
    sbc %1, %1, %1\n\t" \
    "sub %1, %1, %2" \
   :"+&r" (lo), "=&r" (hi) \
   : "r" (hi) \
   : "cc")
#else /*!__thumb___*/
# define MAD_F_MLN(hi, lo) \
    asm ("rsbs %0, %2, \#0\n\t" \
    "rsc %1, %3, #0" \
    : "=r" (lo), "=r" (hi) \
    : "=&r" (lo), "=r" (hi) \
```

```
: "0" (lo), "1" (hi) \
: "cc")
#endif /* __thumb__ */
```

#### 編譯並安裝 libmad:

make

sudo make install

# madplay

### 進入 madplay 目錄:

cd ~/cross-compile/madplay-0.15.2b

### 配置 madplay:

./configure --host=arm-linux-gnueabihf --prefix=\$PREFIX \
CPPFLAGS=-I\$PREFIX/include LDFLAGS=-L\$PREFIX/lib \
CC=\$CC CXX=\$CXX LD=\$LD

### 編譯與安裝 madplay:

make

sudo make install

# 在虛擬機上複製文件到 SD 卡

### 在 SD 卡上創建三個資料夾:

bin、lib 和 alsa。

### 複製執行檔和庫(tony是本組實驗用的虛擬機名稱):

從 /home/tony/cross-compile/build/bin 將 aplay 和 madplay 複製到 SD 卡的 bin 資料夾。 從 /home/tony/cross-compile/build/lib 將所有 .so 文件(不包括符號鏈接)複製到 SD 卡的 lib 資料夾。

### 複製 ALSA 配置:

從 /usr/local/share/alsa 將所有文件和資料夾複製到 SD 卡的 alsa 資料夾。

# 在開發板上的操作

### 從 SD 卡移動文件:

將 SD 卡插入您的 ARM 目標板。

將 SD 卡上 bin 資料夾中的 aplay 和 madplay 移動到目標板的 /usr/bin。

將 SD 卡上 lib 資料夾中的 .so 文件移動到目標板的 /usr/lib。

將 SD 卡上 alsa 資料夾中的所有文件和資料夾移動到目標板的 /usr/local/share/alsa。

### 建立對應的符號鏈接:

在目標板上的 /usr/lib 目錄中為 libid3tag.so.0.3.0、libmad.so.0.2.1 和 libasound.so.2.0.0。
ln -sf /usr/lib/libid3tag.so.0.3.0 /usr/lib/libid3tag.so.0
ln -sf /usr/lib/libmad.so.0.2.1 /usr/lib/libmad.so.0
ln -sf /usr/lib/libasound.so.2.0.0 /usr/lib/libasound.so.2
ldconfig

#### 播放音訊:

madplay -o wav:- music.mp3 | aplay

## 參考

- https://chat.openai.com/
- https://note.drx.tw/2008/04/command.html
- https://www.twblogs.net/a/5e6b933dbd9eee211685f17d
- https://blog.csdn.net/weixin 44175439/article/details/120186387
- <a href="https://www.cnblogs.com/chd-zhangbo/p/5270290.html">https://www.cnblogs.com/chd-zhangbo/p/5270290.html</a>
- https://groups.google.com/g/linux.debian.bugs.dist/c/d1lBFkrKfRM