

Introduction

Famous
applications of
optical
interferometry

Practical
applications of
optical
interferometry

Detection/locking
schemes

Mechanical
stability

Laser interferometry

Dries van Oosten

Debye Institute for NanoMaterials Science



Universiteit Utrecht

Content

Introduction

Introduction

Famous applications of optical interferometry

Famous
applications of
optical
interferometry

Practical applications of optical interferometry

Practical
applications of
optical
interferometry

Detection/locking schemes

Detection/locking
schemes


Mechanical stability

Mechanical
stability



Universiteit Utrecht

The etalon



$$r_{12} = \frac{n_1 - n_2}{n_1 + n_2}$$

$$t_{12} = \frac{2n_1}{n_1 + n_2}$$

$$r_{21} = -r_{12} = -r$$

$$r^2 + t_{12} t_{21} = 1$$

Introduction

Famous applications of optical interferometry

Practical applications of optical interferometry

Detection/locking schemes

Mechanical stability



Universiteit Utrecht

The etalon

Let's do the math

$$\begin{aligned} E_{\text{refl}} &= -rE_{\text{in}} + E_{\text{in}} t_{12} e^{i\delta} r e^{i\delta} t_{21} \\ &\quad + E_{\text{in}} t_{12} e^{i\delta} r e^{i\delta} r e^{i\delta} r e^{i\delta} t_{21} \\ &\quad + \dots \\ &= -rE_{\text{in}} + rE_{\text{in}} t_{12} t_{21} e^{2i\delta} \sum_{n=0}^{\infty} (r^2 e^{2i\delta})^n \end{aligned}$$

$$\frac{E_{\text{refl}}}{E_{\text{in}}} = r_{\text{FP}} = \frac{-r(1 - e^{2i\delta})}{1 - r^2 e^{2i\delta}}$$

$$\left| \frac{E_{\text{out}}}{E_{\text{in}}} \right|^2 = [r_{\text{FP}}]^2 = R_{\text{FP}} = \frac{4R \sin^2 \delta}{(1 - R)^2 + 4R \sin^2 \delta}$$

$$R = 10^{-2}$$

$$V_{\text{FSR}} = \frac{c}{2n_2 L}$$

*iδ
new
ik₀n₂L ih₀n₂L*

Introduction

Famous applications of optical interferometry

Practical applications of optical interferometry

Detection/locking schemes

Mechanical stability



Universiteit Utrecht

The etalon

Let's do the math

Introduction

Famous
applications of
optical
interferometry

Practical
applications of
optical
interferometry


Detection/locking
schemes

Mechanical
stability



Universiteit Utrecht

Soap film



Introduction

Famous
applications of
optical
interferometry

Practical
applications of
optical
interferometry


Detection/locking
schemes

Mechanical
stability



Universiteit Utrecht

Fabry-Perot



Introduction

Famous
applications of
optical
interferometry

Practical
applications of
optical
interferometry


Detection/locking
schemes

Mechanical
stability



Universiteit Utrecht

Fabry-Perot



Introduction

Famous
applications of
optical
interferometry

Practical
applications of
optical
interferometry

Detection/locking
schemes

Mechanical
stability



Universiteit Utrecht

Content

Introduction

Introduction

Famous applications of optical interferometry

Famous
applications of
optical
interferometry

Practical applications of optical interferometry

Practical
applications of
optical
interferometry

Detection/locking schemes

Detection/locking
schemes


Mechanical stability

Mechanical
stability



Universiteit Utrecht

The Michelson-Morley interferometer



$$|E_{\text{det}}|^2 = |E_{\text{in}}|^2 t^2 r^2 \underbrace{|1 + e^{-2ik\Delta L}|^2}_{4 \cos^2(k\Delta L)}$$

$$\begin{aligned} E_{\text{in}} &= E_0 e^{-ikL_1} \\ E_1 &= E_{\text{in}} r e^{-2ikL_1} t \\ E_2 &= E_{\text{in}} r e^{-2ikL_2} t \\ E_{\text{det}} &= E_1 + E_2 \\ &= E_{\text{in}} r \cdot t e^{-2ikL_1} \\ &\quad \times (1 + e^{-2ik\Delta L}) \end{aligned}$$

$$\Delta L = L_2 - L_1$$

Introduction

Famous applications of optical interferometry

Practical applications of optical interferometry

Detection/locking schemes

Mechanical stability



Universiteit Utrecht

The Michelson-Morley interferometer

Let's do some math

Introduction

Famous
applications of
optical
interferometry

Practical
applications of
optical
interferometry


Detection/locking
schemes

Mechanical
stability



Universiteit Utrecht

The Michelson-Morley experiment



Introduction

Famous applications of optical interferometry

Practical applications of optical interferometry

Detection/locking schemes

Mechanical stability



Universiteit Utrecht

The Michelson-Morley experiment



Introduction

Famous applications of optical interferometry

Practical applications of optical interferometry

Detection/locking schemes

Mechanical stability



Universiteit Utrecht

LIGO/VIRGO: preposterously big Michelson-Morley experiments



Introduction

Famous applications of optical interferometry

Practical applications of optical interferometry


Detection/locking schemes

Mechanical stability



Universiteit Utrecht

LIGO/VIRGO: preposterously big Michelson-Morley experiments



Introduction

Famous applications of optical interferometry

Practical applications of optical interferometry

Detection/locking schemes

Mechanical stability



Universiteit Utrecht

Introduction

- ▶ We obviously not going to detect gravity waves during this course
- ▶ Even repeating the Michelson-Morley experiment is extremely difficult
- ▶ Let's look at some applications for mere mortals

Famous applications of optical interferometry

Practical applications of optical interferometry

Detection/locking schemes

Mechanical stability



Universiteit Utrecht

Content

Introduction

Introduction

Famous applications of optical interferometry

Famous
applications of
optical
interferometry

Practical applications of optical interferometry

Practical
applications of
optical
interferometry

Detection/locking schemes

Detection/locking
schemes


Mechanical stability

Mechanical
stability



Universiteit Utrecht

Fourier transform spectroscopy



Introduction

Famous applications of optical interferometry

Practical applications of optical interferometry


Detection/locking schemes

Mechanical stability



Universiteit Utrecht

Optical profilometry



Introduction

Famous applications of optical interferometry

Practical applications of optical interferometry


Detection/locking schemes

Mechanical stability



Universiteit Utrecht

Optical coherence tomography



Introduction

Famous applications of optical interferometry

Practical applications of optical interferometry


Detection/locking schemes

Mechanical stability



Universiteit Utrecht

Laser stabilisation



Introduction

Famous applications of optical interferometry

Practical applications of optical interferometry


Detection/locking schemes

Mechanical stability



Universiteit Utrecht

Transfer cavity



Introduction

Famous applications of optical interferometry

Practical applications of optical interferometry

Detection/locking schemes

Mechanical stability



Universiteit Utrecht

Error signal

- ▶ Error signal: is zero when you are at the target
- ▶ How?
- ▶ Detect the slope: slope is zero at maximum or minimum

Introduction

Famous
applications of
optical
interferometry

Practical
applications of
optical
interferometry

Detection/locking
schemes

Mechanical
stability



Universiteit Utrecht

Pound Drever Hall

$$E = E_0 e^{i \omega t}$$

w_m

$$E = E_0 e^{j(\omega t + \beta \sin \omega_0 t)}$$

$$FP \rightarrow \beta \ll \omega_m \ll \omega$$

5

$$\tilde{x} = e^{i\omega t} \left(1 + \beta s \sin \omega t \right)$$

$$= \frac{E_0 e^{i\omega t}}{2} \left(1 + \frac{\beta}{2} e^{i\omega_{int} t} - \frac{\beta}{2} e^{-i\omega_{int} t} \right)$$

$$r_{FP} = \frac{-\sigma(1 - e^{2i\delta})}{(-\sigma^2 e^{2i\delta})} \rightarrow S(\omega)$$

$$E_{FP} = E_0 \left\{ r_{FP}(w) e^{iwt} + \frac{\beta}{2} r_{FP}(w+w_m) e^{+i(w-w_m)t} \right\}$$

$$P_{FP} \propto E_{FP}^* E_{FP} = \frac{\beta}{2} |E_0|^2 \left(\chi(w) e^{iw_{mt}} + \chi^*(w) e^{-iw_{mt}} \right)$$

$$\chi(\omega) = r_{FP}^{\text{eff}}(\omega) + \text{const. terms.} + e^{+2i\pi\omega T} \text{ terms}$$



Universiteit Utrecht

Pound Drever Hall

Let's do the math

$$\chi = \chi' + i\chi''$$
$$\beta E_0 l^2 (\chi' \cos \omega_{\text{int}} - \chi'' \sin \omega_{\text{int}})$$
$$\left. \chi \cos(\omega_{\text{int}} + \varphi) \right\}$$

$$\cos \omega_{\text{int}} \cos(\omega_{\text{int}} + \varphi) = \frac{1}{2} \cos(2\omega_{\text{int}} + \varphi) + \frac{1}{2} \cos \varphi$$
$$\sin \omega_{\text{int}} \quad , \quad = \quad \dots \quad - \frac{1}{2} \sin \varphi$$

$$\chi \left(\frac{1}{2} \chi' \cos \varphi + \frac{1}{2} \chi'' \sin \varphi \right)$$

$$\varphi = 0 \rightarrow \text{measurement } \chi'$$

Introduction

Famous applications of optical interferometry

Practical applications of optical interferometry


Detection/locking schemes

Mechanical stability



Universiteit Utrecht

Pound Drever Hall



Introduction

Famous applications of optical interferometry

Practical applications of optical interferometry

Detection/locking schemes

Mechanical stability



Universiteit Utrecht

Pound Drever Hall

Laser locking

- ▶ now we have an error signal
- ▶ tells us in which direction the correct frequency/length is
- ▶ feed into an integrator, feed integrator signal into actuator

Introduction

Famous
applications of
optical
interferometry

Practical
applications of
optical
interferometry

Detection/locking
schemes

Mechanical
stability



Universiteit Utrecht

Pound Drever Hall

Laser locking

Introduction

Famous
applications of
optical
interferometry

Practical
applications of
optical
interferometry

Detection/locking
schemes

Mechanical
stability



Universiteit Utrecht

Mechanical stability

- ▶ Interferometers: sensitive to vibration, both seismic and acoustic
- ▶ Isolate your setup: heavy optical table air cushion (tennisballs, bicycle tires, ...)
- ▶ Active feedback: measure acceleration and cancel it using some actuator (piezo, solenoid, ...)

Introduction

Famous applications of optical interferometry

Practical applications of optical interferometry



Detection/locking schemes

Mechanical stability



Universiteit Utrecht

Mechanical stability: VIRGO



Introduction

Famous applications of optical interferometry

Practical applications of optical interferometry

Detection/locking schemes

Mechanical stability



Universiteit Utrecht