
User
Orchestrator
LLM
Safety
ROS 2 and firmware
“move 0.5 m forward”
message + 58 tool schemas
tool call: move_robot(vx, vy, wz, duration)
validate
clamped to limits
/cmd_vel, then stop
odometry, status
tool result
final answer
reply