7 61 60 59 58 57 56 55 54 53 52 51 50 49 48	47 46 45 44 43 42 41 40 39 38 37 36 35 34 33 38	3 2 2 31 30 29 28 27 26 25 24 23 22 21 20 19 18 17 1	1 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0	1 0 CANID
	CONT	ROL OUTPUT FOR HIPS		
TIMESTAMP		LEFT HIP CONTROL OUTPUT [-32768, 32767]	RIGHT HIP CONTROL OUTPUT [-32768, 32767]	0x0B
	CONTROL OU	TPUT FOR KNEES AND ANKLES		
LEFT KNEE CONTROL OUTPUT [-32768, 32767]	RIGHT KNEE CONTROL OUTPUT [-32768, 32767]	LEFT ANKLE CONTROL OUTPUT [-32768, 32767]	RIGHT ANKLE CONTROL OUTPUT [-32768, 32767]	0x0C
	MEASURED OUTP	UT AND SYSTEM SETPOINT FOR HIP		
LEFT HIP MEASURED OUTPUT [-32768, 32767]	LEFT HIP SYSTEM SETPOINT [-32768, 32767]	RIGHT HIP MEASURED OUTPUT [-32768, 32767]	RIGHT HIP SYSTEM SETPOINT [-32768, 32767]	0x0D
	ALPHA ANGLE A	AND LEVER ARM ANGLE FOR HIP		-
LEFT HIP LEVER ARM ANGLE [-3999, 4000]	LEFT HIP ALPHA ANGLE [-8191, 8192]	RIGHT HIP LEVER ARM ANGLE [-3999, 4000]	RIGHT HIP ALPHA ANGLE [-819, 8192]	0x0E
	FIX LINK AF	NGLE AND TORQUE FOR HIP		
LEFT HIP TORQUE [-32768, 32767]	LEFT HIP FIX LINK ANGLE [-3999, 4000]	RIGHT HIP TORQUE [-32768, 32767]	RIGHT HIP FIX LINK ANGLE [-3999, 4000]	0x0F
	MEASURED OUTPU	T AND SYSTEM SETPOINT FOR KNEES		
LEFT KNEE MEASURED OUTPUT [-32768, 32767]	LEFT KNEE SYSTEM SETPOINT [-32768, 32767]	RIGHT KNEE MEASURED OUTPUT [-32768, 32767]	RIGHT KNEE SYSTEM SETPOINT [-32768, 32767]	0x10
	ALPHA ANGLE AI	ND LEVER ARM ANGLE FOR KNEES		-
LEFT KNEE LEVER ARM ANGLE [-3999, 4000]	LEFT KNEE ALPHA ANGLE [-8191, 8192]	RIGHT KNEE LEVER ARM ANGLE [-3999, 4000]	RIGHT KNEE ALPHA ANGLE [-819, 8192]	0x11
	FIX LINK ANG	GLE AND TORQUE FOR KNEES		
LEFT KNEE TORQUE [-32768, 32767]	LEFT KNEE FIX LINK ANGLE [-3999, 4000]	RIGHT KNEE TORQUE [-32768, 32767]	RIGHT KNEE FIX LINK ANGLE [-3999, 4000]	0x12
	MEASURED OUTPUT	AND SYSTEM SETPOINT FOR ANKLES		
LEFT ANKLE MEASURED OUTPUT [-32768, 32767]	LEFT ANKLE SYSTEM SETPOINT [-32768, 32767]	RIGHT ANKLE MEASURED OUTPUT [-32768, 32767]	RIGHT ANKLE SYSTEM SETPOINT [-32768, 32767]	0x13
	ALPHA ANGLE AN	ID LEVER ARM ANGLE FOR ANKLES		
LEFT ANKLE LEVER ARM ANGLE [-3999, 4000]	LEFT ANKLE ALPHA ANGLE [-8191, 8192]	RIGHT ANKLE LEVER ARM ANGLE [-3999, 4000]	RIGHT ANKLE ALPHA ANGLE [-819, 8192]	0x14
	FIX LINK ANG	GLE AND TORQUE FOR ANKLES		
LEFT ANKLE TORQUE [-32768, 32767]	LEFT ANKLE FIX LINK ANGLE [-3999, 4000]	RIGHT ANKLE TORQUE [-32768, 32767]	RIGHT ANKLE FIX LINK ANGLE [-3999, 4000]	0x15