# M0RVJ Micro:bit CW Transceiver

### **COMMANDS**

## Speed

A = 15WPM

B = 18WPM

C = 21WPM

D = 24WPM

E = 27WPM

F = 30WPM

#### Tone

G = 500hz

H = 550hz

I = 600hz

J = 650hz

K = 700hz

L = 750hz

M = 800hz

#### Channel

N = 1

O = 2

P = 3

Q = 4

R = 5

S = 6

#### Tutor

T = M0RVJ suggests cwops.org

#### **Power**

U = Low Power / QRP

V = High Power / QRO

#### Reset

Z = defaults A H N U

## International Morse Code

- 1. The length of a dot is one unit.
- 2. A dash is three units.
- 3. The space between parts of the same letter is one unit.
- 4. The space between letters is three units.

