C172SP G1000 GROUND PROCEDURES		
DISPATCH	Alt. Static CHECK	XPDRSET
Weather BRIEF	Fuel ShutoffIN	Mixture BEST POWER
	Fuel Selector BOTH	Throttle 1800 RPM
NOTAMS CHECK	Brakes SET	Annunciators CHECK
W&B CHECK	Master BATT ON	VacuumCHECK
Perf. Reqs CHECK	Avionics BUS 1 FAN	Amps/VoltsCHECK
SquawksCHECK	Avionics BUS 2 FAN	OilCHECK
IMSAFE CHECK	Avionics OFF	Mags CHECK
Devices CHARGED		Throttle 1000 RPM
PASSENGER BRIEF	Beacon ON	Throttle Friction SET
PIC NOTE	HOT: SKIP PRIME	
Ramp Safety NOTE	Throttle1"	SWITCH TO FLIGHT
Flight Plan NOTE	Mixture RICH	SHUTDOWN
Seatbelts NOTE	Fuel Pump ON	XPDR SET
Air VentsNOTE	Fuel Pump OFF	Brakes SET
Safety Equipment NOTE	END PRIME	Electrical OFF
Traffic & Talking NOTE	MixtureIDLE C/O	Avionics OFF
Questions NOTE	ThrottleSLIGHT	MixtureIDLE C/O
	Clear Prop ANNOUNCE	Mags OFF
INSPECTION	MagsSTART	Master OFF
AV1ATECHECK	Mixture BEST POWER	Standby BattOFF
FuelSTICK	Throttle 1000 RPM	Fuel LEFT
AROWCHECK	Oil Pressure CHECK	ForeFlight STOP REC
ScoutSETUP	Master ALT ON	Flight Plan CLOSE
Avionics OFF		SECURING
MasterON	Mixture LEAN	
Fuel GaugeTRUE	Flaps	Scout REMOVE
Fuel Gauge TRUE Flaps EXTEND	Flaps UP Lights ON	Scout REMOVE Control LockSET
Fuel GaugeTRUE Flaps EXTEND ElectricsTEST	Flaps UP Lights ON Avionics ON	Scout REMOVE Control LockSET Hobbs/TachNOTE
Fuel GaugeTRUE FlapsEXTEND ElectricsTEST ElectricsOFF	Flaps UP Lights ON Avionics ON Radios SET	Scout REMOVE Control Lock SET Hobbs/Tach NOTE Squawks NOTE
Fuel Gauge TRUE Flaps EXTEND Electrics TEST Electrics OFF Master OFF	Flaps UP Lights ON Avionics ON Radios SET ATIS GET	Scout REMOVE Control Lock SET Hobbs/Tach NOTE Squawks NOTE Sun Shade REPLACE
Fuel Gauge TRUE Flaps EXTEND Electrics TEST Electrics OFF Master OFF Oil 6-8 QTS	Flaps UP Lights ON Avionics ON Radios SET ATIS GET Barometer SET	Scout REMOVE Control Lock SET Hobbs/Tach NOTE Squawks NOTE Sun Shade REPLACE Pitot Cover REPLACE
Fuel Gauge TRUE Flaps EXTEND Electrics TEST Electrics OFF Master OFF	Flaps UP Lights ON Avionics ON Radios SET ATIS GET Barometer SET XPDR SET	Scout REMOVE Control Lock SET Hobbs/Tach NOTE Squawks NOTE Sun Shade REPLACE Pitot Cover REPLACE Wheels CHOCK
Fuel Gauge TRUE Flaps EXTEND Electrics TEST Electrics OFF Master OFF Oil 6–8 QTS Fuel DRAIN Exterior CHECK	Flaps UP Lights ON Avionics ON Radios SET ATIS GET Barometer SET XPDR SET Totalizer SET	Scout REMOVE Control Lock SET Hobbs/Tach NOTE Squawks NOTE Sun Shade REPLACE Pitot Cover REPLACE Wheels CHOCK Ties TIE
Fuel Gauge TRUE Flaps EXTEND Electrics TEST Electrics OFF Master OFF Oil 6–8 QTS Fuel DRAIN Exterior CHECK Ties/Chocks REMOVE	Flaps UP Lights ON Avionics ON Radios SET ATIS GET Barometer SET XPDR SET	Scout REMOVE Control Lock SET Hobbs/Tach NOTE Squawks NOTE Sun Shade REPLACE Pitot Cover REPLACE Wheels CHOCK Ties TIE Doors LOCK
Fuel Gauge TRUE Flaps EXTEND Electrics TEST Electrics OFF Master OFF Oil 6–8 QTS Fuel DRAIN Exterior CHECK Ties/Chocks REMOVE Baggage CHECK	Flaps UP Lights ON Avionics ON Radios SET ATIS GET Barometer SET XPDR SET Totalizer SET	Scout REMOVE Control Lock SET Hobbs/Tach NOTE Squawks NOTE Sun Shade REPLACE Pitot Cover REPLACE Wheels CHOCK Ties TIE Doors LOCK FIRE ON START
Fuel Gauge TRUE Flaps EXTEND Electrics TEST Electrics OFF Master OFF Oil 6–8 QTS Fuel DRAIN Exterior CHECK Ties/Chocks REMOVE	Flaps UP Lights ON Avionics ON Radios SET ATIS GET Barometer SET XPDR SET Totalizer SET TAXI Brakes TEST	Scout REMOVE Control Lock SET Hobbs/Tach NOTE Squawks NOTE Sun Shade REPLACE Pitot Cover REPLACE Wheels CHOCK Ties TIE Doors LOCK
Fuel Gauge TRUE Flaps EXTEND Electrics TEST Electrics OFF Master OFF Oil 6–8 QTS Fuel DRAIN Exterior CHECK Ties/Chocks REMOVE Baggage CHECK	Flaps UP Lights ON Avionics ON Radios SET ATIS GET Barometer SET XPDR SET Totalizer SET	Scout REMOVE Control Lock SET Hobbs/Tach NOTE Squawks NOTE Sun Shade REPLACE Pitot Cover REPLACE Wheels CHOCK Ties TIE Doors LOCK FIRE ON START
Fuel Gauge TRUE Flaps EXTEND Electrics TEST Electrics OFF Master OFF Oil 6-8 QTS Fuel DRAIN Exterior CHECK Ties/Chocks REMOVE Baggage CHECK Walkaround EXECUTE Seat ADJUST	Flaps UP Lights ON Avionics ON Radios SET ATIS GET Barometer SET XPDR SET Totalizer SET TAXI Brakes TEST Controls WIND Taxi Turns EXECUTE	Scout
Fuel Gauge TRUE Flaps EXTEND Electrics TEST Electrics OFF Master OFF Oil 6–8 QTS Fuel DRAIN Exterior CHECK Ties/Chocks REMOVE Baggage CHECK Walkaround EXECUTE Seat ADJUST	Flaps UP Lights ON Avionics ON Radios SET ATIS GET Barometer SET XPDR SET Totalizer SET TAXI Brakes TEST Controls WIND Taxi Turns EXECUTE RUNUP	Scout
Fuel Gauge TRUE Flaps EXTEND Electrics TEST Electrics OFF Master OFF Oil 6-8 QTS Fuel DRAIN Exterior CHECK Ties/Chocks REMOVE Baggage CHECK Walkaround EXECUTE Seat ADJUST START Passengers BRIEF	Flaps UP Lights ON Avionics ON Radios SET ATIS GET Barometer SET XPDR SET Totalizer SET TAXI Brakes TEST Controls WIND Taxi Turns EXECUTE RUNUP Brakes SET	Scout REMOVE Control Lock SET Hobbs/Tach NOTE Squawks NOTE Sun Shade REPLACE Pitot Cover REPLACE Wheels CHOCK Ties TIE Doors LOCK FIRE ON START IF START Run 5 sec Mixture IDLE C/O Evacuate GO
Fuel Gauge TRUE Flaps EXTEND Electrics TEST Electrics OFF Master OFF Oil 6-8 QTS Fuel DRAIN Exterior CHECK Ties/Chocks REMOVE Baggage CHECK Walkaround EXECUTE Seat ADJUST START Passengers BRIEF Seatbelts CHECK	Flaps UP Lights ON Avionics ON Radios SET ATIS GET Barometer SET XPDR SET Totalizer SET TAXI Brakes TEST Controls WIND Taxi Turns EXECUTE RUNUP Brakes SET Controls CORRECT	Scout
Fuel Gauge TRUE Flaps EXTEND Electrics TEST Electrics OFF Master OFF Oil 6-8 QTS Fuel DRAIN Exterior CHECK Ties/Chocks REMOVE Baggage CHECK Walkaround EXECUTE Seat ADJUST START Passengers BRIEF Seatbelts CHECK iPad CONN SCOUT	Flaps UP Lights ON Avionics ON Radios SET ATIS GET Barometer SET XPDR SET Totalizer SET TAXI Brakes TEST Controls WIND Taxi Turns EXECUTE RUNUP Brakes SET Controls CORRECT PFD NO RED XS	Scout REMOVE Control Lock SET Hobbs/Tach NOTE Squawks NOTE Sun Shade REPLACE Pitot Cover REPLACE Wheels CHOCK Ties TIE Doors LOCK FIRE ON START IF START Run 5 sec Mixture IDLE C/O Evacuate GO IF NO START Crank CONTINUE
Fuel Gauge TRUE Flaps EXTEND Electrics TEST Electrics OFF Master OFF Oil 6–8 QTS Fuel DRAIN Exterior CHECK Ties/Chocks REMOVE Baggage CHECK Walkaround EXECUTE Seat ADJUST START Passengers BRIEF Seatbelts CHECK iPad CONN SCOUT ForeFlight START REC	Flaps UP Lights ON Avionics ON Radios SET ATIS GET Barometer SET XPDR SET Totalizer SET TAXI Brakes TEST Controls WIND Taxi Turns EXECUTE RUNUP Brakes SET Controls CORRECT PFD NO RED XS Flight Inst. CHECK	Scout REMOVE Control Lock SET Hobbs/Tach NOTE Squawks NOTE Sun Shade REPLACE Pitot Cover REPLACE Wheels CHOCK Ties TIE Doors LOCK FIRE ON START IF START Run 5 sec Mixture IDLE C/O Evacuate GO IF NO START Crank CONTINUE Mixture IDLE C/O
Fuel Gauge TRUE Flaps EXTEND Electrics TEST Electrics OFF Master OFF Oil 6–8 QTS Fuel DRAIN Exterior CHECK Ties/Chocks REMOVE Baggage CHECK Walkaround EXECUTE Seat ADJUST START Passengers BRIEF Seatbelts CHECK iPad CONN SCOUT ForeFlight START REC Circuit Breakers CHECK	Flaps UP Lights ON Avionics ON Radios SET ATIS GET Barometer SET XPDR SET Totalizer SET TAXI Brakes TEST Controls WIND Taxi Turns EXECUTE RUNUP Brakes SET Controls CORRECT PFD NO RED XS Flight Inst. CHECK Fuel BOTH	Scout REMOVE Control Lock SET Hobbs/Tach NOTE Squawks NOTE Sun Shade REPLACE Pitot Cover REPLACE Wheels CHOCK Ties TIE Doors LOCK FIRE ON START IF START Run 5 sec Mixture IDLE C/O Evacuate GO IF NO START Crank CONTINUE Mixture IDLE C/O Throttle FULL
Fuel Gauge TRUE Flaps EXTEND Electrics TEST Electrics OFF Master OFF Oil 6–8 QTS Fuel DRAIN Exterior CHECK Ties/Chocks REMOVE Baggage CHECK Walkaround EXECUTE Seat ADJUST START Passengers BRIEF Seatbelts CHECK iPad CONN SCOUT ForeFlight START REC Circuit Breakers CHECK Standby Batt. TEST/ARM	Flaps UP Lights ON Avionics ON Radios SET ATIS GET Barometer SET XPDR SET Totalizer SET TAXI Brakes TEST Controls WIND Taxi Turns EXECUTE RUNUP Brakes SET Controls CORRECT PFD NO RED XS Flight Inst. CHECK Fuel BOTH Autopilot CHECK	Scout REMOVE Control Lock SET Hobbs/Tach NOTE Squawks NOTE Sun Shade REPLACE Pitot Cover REPLACE Wheels CHOCK Ties TIE Doors LOCK FIRE ON START IF START Run 5 sec Mixture IDLE C/O Evacuate GO IF NO START Crank CONTINUE Mixture IDLE C/O Throttle FULL Fuel Shutoff OUT
Fuel Gauge TRUE Flaps EXTEND Electrics TEST Electrics OFF Master OFF Oil 6–8 QTS Fuel DRAIN Exterior CHECK Ties/Chocks REMOVE Baggage CHECK Walkaround EXECUTE Seat ADJUST START Passengers BRIEF Seatbelts CHECK iPad CONN SCOUT ForeFlight START REC Circuit Breakers CHECK Standby Batt. TEST/ARM Engine Ind. CHECK	Flaps UP Lights ON Avionics ON Radios SET ATIS GET Barometer SET XPDR SET Totalizer SET TAXI Brakes TEST Controls WIND Taxi Turns EXECUTE RUNUP Brakes SET Controls CORRECT PFD NO RED XS Flight Inst. CHECK Fuel BOTH Autopilot CHECK Trim TAKEOFF	Scout REMOVE Control Lock SET Hobbs/Tach NOTE Squawks NOTE Sun Shade REPLACE Pitot Cover REPLACE Wheels CHOCK Ties TIE Doors LOCK FIRE ON START IF START Run 5 sec Mixture IDLE C/O Evacuate GO IF NO START Crank CONTINUE Mixture IDLE C/O Throttle FULL
Fuel Gauge TRUE Flaps EXTEND Electrics TEST Electrics OFF Master OFF Oil 6-8 QTS Fuel DRAIN Exterior CHECK Ties/Chocks REMOVE Baggage CHECK Walkaround EXECUTE Seat ADJUST START Passengers BRIEF Seatbelts CHECK iPad CONN SCOUT ForeFlight START REC Circuit Breakers CHECK Standby Batt. TEST/ARM Engine Ind. CHECK E Bus Volts 24 MIN	Flaps UP Lights ON Avionics ON Radios SET ATIS GET Barometer SET XPDR SET Totalizer SET TAXI Brakes TEST Controls WIND Taxi Turns EXECUTE RUNUP Brakes SET Controls CORRECT PFD NO RED XS Flight Inst. CHECK Fuel BOTH Autopilot CHECK Trim TAKEOFF GPS/NAV CONFIG	Scout REMOVE Control Lock SET Hobbs/Tach NOTE Squawks NOTE Sun Shade REPLACE Pitot Cover REPLACE Wheels CHOCK Ties TIE Doors LOCK FIRE ON START IF START Run 5 sec Mixture IDLE C/O Evacuate GO IF NO START Crank CONTINUE Mixture IDLE C/O Throttle FULL Fuel Shutoff OUT
Fuel Gauge TRUE Flaps EXTEND Electrics TEST Electrics OFF Master OFF Oil 6–8 QTS Fuel DRAIN Exterior CHECK Ties/Chocks REMOVE Baggage CHECK Walkaround EXECUTE Seat ADJUST START Passengers BRIEF Seatbelts CHECK iPad CONN SCOUT ForeFlight START REC Circuit Breakers CHECK Standby Batt. TEST/ARM Engine Ind. CHECK	Flaps UP Lights ON Avionics ON Radios SET ATIS GET Barometer SET XPDR SET Totalizer SET TAXI Brakes TEST Controls WIND Taxi Turns EXECUTE RUNUP Brakes SET Controls CORRECT PFD NO RED XS Flight Inst. CHECK Fuel BOTH Autopilot CHECK Trim TAKEOFF	Scout REMOVE Control Lock SET Hobbs/Tach NOTE Squawks NOTE Sun Shade REPLACE Pitot Cover REPLACE Wheels CHOCK Ties TIE Doors LOCK FIRE ON START IF START Run 5 sec Mixture IDLE C/O Evacuate GO IF NO START Crank CONTINUE Mixture IDLE C/O Throttle FULL Fuel Shutoff OUT

C172SP G1000 FLIGHT PROCEDURES		
TAKEOFF BRIEF	Flaps	ENGINE FIRE
RunwayCHECK		MixtureIDLE C/O
HISET TO COMPASS	APPROACH CFGS	Fuel ShutoffOUT
Crosswind CHECK	NORMAL/SOFT	Master OFF
Abort Speed NOTE	FlapsFULL	Cabin AirCLOSE
Technique NOTE	Speed65	Vents OPEN
FlapsSET	SHORT	SpeedINCREASE
Min. Ret. Alt NOTE		Flight TERMINATE
Best Glide 60–70	FlapsFULL	ELECTRICAL FIRE
TimerSTART	Speed 60	Master OFF
Mixture BEST POWER	LOW VOLTAGE	Vents/Air CLOSE
CLIMB	Power GT 1000 RPM	Extinguisher USE
Flaps	Lights/Pitot OFF	Vents OPEN
Mixture LEAN >3k	Avionics OFF	Breakers CHECK
HISET TO COMPASS	Master ALT OFF	Master ON IF CRITICAL
Engine InstCHECK	Alt CHECK	Flight TERMINATE
PRE-DESCENT	Master ALT ON	IMPORTANT NUM.
HISET TO COMPASS	Avionics ESSENTIAL	V _{so} 40
Engine Inst CHECK	Lights/Pitot ESSENTIAL	V _s 48
ATIS GET	Flight TERMINATE	V _{rotate}
BarometerSET	CYCLE ONCE ONLY	V _x
Tower CONTACT	OVERVOLTAGE	V _y
Fuel BOTH		V _{fe} 85
Mixture ENRICH	Master ALT OFF	V _{fe-10} 110
Lights ON	AltPULL	V _a 105
AFTER LANDING	Avionics OFF	V _{no} 129
FlapsUP	Lights/Pitot Essential	V _{ne}
Trim TAKEOFF	Flight TERMINATE	Best Glide65
Mixture LEAN	ENGINE FAILURE	Max Gross 2550 Max Crosswind 15
Taxi Diag OPEN	Best Glide 60–70	Fuel53
SWITCH TO GROUND	Landing Site FIND	ruei 33
TAKEOFF CFGS	Fuel Shutoff ON	
NORMAL	Throttle HALF	
Flaps	Throttle FULL	
Rotate 55	Mixture VARY	
Climb 74	Fuel Pump ON	
SHORT	MagsTEST BOTH	
Flaps10	IF NO RESTART	
Brakes SET		
Climb 56 TO 50'	Squawk	
Flans IJP	Lineigency DECLARE	

Fuel ShutoffOUT

MixtureIDLE C/O

Mags **OFF**

Master OFF

DoorsUNLATCH

Landing EXECUTE

SOFT

Flaps10

Nosewheel LIGHT

Ground Effect 60

Climb65