C172SP GROUND PROCEDURES

C172SP GROUND PROCEDURES		
DISPATCH	AvionicsBUS 1 OFF	Amps/Volts CHECK
Weather BRIEF	AvionicsBUS 2 ON	OilCHECK
NOTAMsCHECK	Avionics AFT FAN	Mags CHECK
W&B CHECK	AvionicsBUS 2 OFF	Throttle 1000 RPM
Perf. Reqs CHECK	BeaconON	Throttle FrictionSET
SquawksCHECK	HOT: SKIP PRIME	SWITCH TO FLIGHT
IMSAFE CHECK	Throttle 1 "	SHUTDOWN
Devices CHARGED	Mixture RICH	XPDR SET
INSPECTION	Fuel Pump ON	Brakes SET
AV1ATE CHECK	Fuel Pump OFF	Electrical OFF
FuelSTICK	END PRIME	Avionics OFF
AROWCHECK	Mixture IDLE C/O	Mixture IDLE C/O
Scout SETUP	ThrottleSLIGHT	Mags OFF
Avionics OFF	Clear Prop . ANNOUNCE	Master OFF
Master ON	MagsSTART	Fuel LEFT
Fuel GaugeTRUE	Mixture BEST POWER	ForeFlight STOP REC
Flaps EXTEND	Throttle 1000 RPM	Flight Plan CLOSE
Electrics TEST	Oil Pressure CHECK	SECURING
ElectricsOFF	Master ALT ON	ScoutREMOVE
Master OFF	Mixture LEAN	Control LockSET
Oil 6-8 QTS	Flaps	
Fuel DRAIN	Lights ON	Hobbs/TachNOTE
Exterior CHECK	Avionics ON	Squawks NOTE
Ties/Chocks REMOVE	Radios SET	Sun Shade REPLACE
BaggageCHECK	ATIS GET	Pitot Cover REPLACE
Walkaround EXECUTE	BarometerSET	WheelsCHOCK
Seat ADJUST	XPDRSET	TiesTIE
	TAXI	Doors LOCK
START	BrakesTEST	FIRE ON START
Passengers BRIEF	Controls WIND	IF START
Seatbelts CHECK	Taxi Turns EXECUTE	Run 5 sec
iPad CONN SCOUT		Mixture IDLE C/O
ForeFlight START REC	RUNUP	EvacuateGO
Circuit Breakers . CHECK	Brakes SET	IF NO START
Standby Battery TEST	Controls CORRECT	Crank CONTINUE
Standby Battery ARM	PFD NO RED XS	Mixture IDLE C/O
Engine Ind CHECK	Flight Inst CHECK	Throttle FULL
Bus E Volts 24 MIN	Fuel BOTH	Fuel ShutoffOUT
M Bus Volts 1.5 MAX	Autopilot CHECK	
BATT S Amps CHECK	Trim TAKEOFF	EvacuateGO
STBY BATTCHECK	GPS/NAVCONFIG	
Alt. Static CHECK	Heading Bug SET	
Fuel Shutoff IN	Radios SET	
Fuel Selector BOTH	XPDR SET	
Brakes SET	Mixture BEST POWER	
_ · · · · · · · · · · · · · · · · · · ·		

Throttle 1800 RPM

Annunciators ... CHECK

Vacuum CHECK

Master BATT ON AvionicsBUS 1 ON

Avionics FAN

C172SP FLIGHT PROCEDURES **TAKEOFF BRIEF** Runway CHECK HI .. SET TO COMPASS **APPROACH CFGS** Crosswind CHECK NORMAL/SOFT Abort Speed NOTE Flaps FULL Technique NOTE Speed65 Flaps **SET** SHORT Min. Ret. Alt. NOTE Best Glide 60-70 Flaps **FULL** Time **NOTE** Speed60 Mixture .. BEST POWER LOW VOLTAGE **CLIMB** Power GT 1000 RPM Lights/Pitot OFF Mixture LEAN >3k Avionics OFF HI .. SET TO COMPASS Master ALT OFF Engine Inst. CHECK Alt CHECK **PRE-DESCENT** Master ALT ON HI .. SET TO COMPASS Avionics ESSENTIAL Engine Inst. CHECK Lights/Pitot . ESSENTIAL ATIS **GET** Flight TERMINATE BarometerSET CYCLE ONCE ONLY Tower CONTACT **OVERVOLTAGE** Fuel **BOTH** Mixture ENRICH Master ALT OFF Lights ON Alt PULL Avionics OFF **AFTER LANDING** Lights/Pitot Essential Flight TERMINATE Trim TAKEOFF **ENGINE FAILURE** Mixture LEAN Taxi Diag. OPEN Best Glide 60-70 Landing Site FIND **SWITCH TO GROUND** Fuel Shutoff ON TAKEOFF CFGS Throttle HALF NORMAL Throttle FULL Mixture VARY Rotate55 Fuel Pump ON Mags TEST BOTH SHORT IF NO RESTART Flaps10 Brakes SET Emergency DECLARE Climb 56 TO 50' Fuel ShutoffOUT Mixture IDLE C/O SOFT Mags **OFF** Flaps10 Master OFF Nosewheel LIGHT DoorsUNLATCH

Landing **EXECUTE**

Ground Effect 60

ENGINE FIRE

IDLE C/O

Mixture

ELECTRICAL FIRE

Master	OFF
Vents/Air	CLOSE
Extinguisher	USE
Vents	OPEN
Breakers	CHECK
Master . ON IF C	RITICAL
Flight TER	MINATE