C172SP GROUND PROCEDURES		
DISPATCH Weather BRIEF	BATT S Amps CHECK STBY BATT CHECK	Trim TAKEOFF GPS/NAV CONFIG
NOTAMSCHECK W&BCHECK	Alt. Static CHECK Fuel ShutoffIN	Heading Bug SET Radios SET
Perf. Reqs CHECK	Fuel Selector BOTH	XPDRSET
SquawksCHECK	Brakes SET	Mixture BEST POWER
IMSAFE CHECK	Master BATT ON	Throttle 1800 RPM
Devices CHARGED	Avionics BUS 1 ON	Annunciators CHECK
PASSENGER BRIEF	Avionics FAN Avionics BUS 1 OFF	Vacuum CHECK Amps/Volts CHECK
PIC	Avionics BUS 2 ON	Oil CHECK
Ramp Safety	Avionics AFT FAN	Mags CHECK
Flight PlanSeatbelts	AvionicsBUS 2 OFF	Throttle 1000 RPM
Air Vents	BeaconON	Throttle Friction SET
Safety Equipment	HOT: SKIP PRIME	SWITCH TO FLIGHT
Traffic and Talking	Throttle1"	SHUTDOWN
Questions	MixtureRICH Fuel Pump ON	XPDRSET
INSPECTION	Fuel Pump OFF	Brakes SET Electrical OFF
AV1ATE CHECK	END PRIME	Avionics OFF
FuelSTICK	Mixture IDLE C/O	Mixture IDLE C/O
AROW CHECK Scout SETUP	ThrottleSLIGHT	Mags OFF
Avionics OFF	Clear Prop . ANNOUNCE	Master OFF
7 17 10 11 100 1 1 1 1 1 1 1 1 1 1 1 1 1		Fuol IEET
Master ON	MagsSTART	FuelLEFT
Master ON Fuel Gauge TRUE	Mixture BEST POWER	ForeFlight STOP REC
Fuel Gauge TRUE Flaps EXTEND	Mixture BEST POWER Throttle 1000 RPM	ForeFlight STOP REC Flight Plan CLOSE
Fuel GaugeTRUE Flaps EXTEND ElectricsTEST	Mixture BEST POWER Throttle 1000 RPM Oil Pressure CHECK	ForeFlight STOP REC Flight Plan CLOSE SECURING
Fuel Gauge TRUE Flaps EXTEND Electrics TEST Electrics OFF	Mixture BEST POWER Throttle 1000 RPM Oil Pressure CHECK Master ALT ON	ForeFlight STOP REC Flight Plan CLOSE SECURING Scout REMOVE
Fuel Gauge TRUE Flaps EXTEND Electrics TEST Electrics OFF Master OFF	Mixture BEST POWER Throttle 1000 RPM Oil Pressure CHECK	ForeFlight STOP REC Flight Plan CLOSE SECURING
Fuel Gauge TRUE Flaps EXTEND Electrics TEST Electrics OFF Master OFF Oil 6-8 QTS	Mixture BEST POWER Throttle 1000 RPM Oil Pressure CHECK Master ALT ON Mixture LEAN Flaps UP Lights ON	ForeFlight STOP REC Flight Plan CLOSE SECURING Scout REMOVE Control Lock SET Hobbs/Tach NOTE Squawks NOTE
Fuel Gauge TRUE Flaps EXTEND Electrics TEST Electrics OFF Master OFF	Mixture BEST POWER Throttle 1000 RPM Oil Pressure CHECK Master ALT ON Mixture LEAN Flaps UP Lights ON Avionics ON	ForeFlight STOP REC Flight Plan CLOSE SECURING Scout REMOVE Control Lock SET Hobbs/Tach NOTE Squawks NOTE Sun Shade REPLACE
Fuel Gauge	Mixture BEST POWER Throttle 1000 RPM Oil Pressure CHECK Master ALT ON Mixture LEAN Flaps UP Lights ON Avionics ON Radios SET	ForeFlight STOP REC Flight Plan CLOSE SECURING Scout REMOVE Control Lock SET Hobbs/Tach NOTE Squawks NOTE Sun Shade REPLACE Pitot Cover REPLACE
Fuel Gauge TRUE Flaps EXTEND Electrics TEST Electrics OFF Master OFF Oil 6-8 QTS Fuel DRAIN Exterior CHECK Ties/Chocks REMOVE Baggage CHECK	Mixture . BEST POWER Throttle 1000 RPM Oil Pressure CHECK Master ALT ON Mixture LEAN Flaps UP Lights ON Avionics ON Radios SET ATIS GET	ForeFlight STOP REC Flight Plan CLOSE SECURING Scout REMOVE Control Lock SET Hobbs/Tach NOTE Squawks NOTE Sun Shade REPLACE Pitot Cover REPLACE Wheels CHOCK
Fuel Gauge TRUE Flaps EXTEND Electrics OFF Master OFF Oil 6-8 QTS Fuel DRAIN Exterior CHECK Ties/Chocks REMOVE Baggage CHECK Walkaround EXECUTE	Mixture . BEST POWER Throttle 1000 RPM Oil Pressure CHECK Master ALT ON Mixture LEAN Flaps UP Lights ON Avionics ON Radios SET ATIS	ForeFlight STOP REC Flight Plan CLOSE SECURING Scout REMOVE Control Lock SET Hobbs/Tach NOTE Squawks NOTE Sun Shade REPLACE Pitot Cover REPLACE Wheels CHOCK Ties TIE
Fuel Gauge TRUE Flaps EXTEND Electrics OFF Master OFF Oil 6-8 QTS Fuel DRAIN Exterior CHECK Ties/Chocks REMOVE Baggage CHECK Walkaround EXECUTE Seat ADJUST	Mixture . BEST POWER Throttle 1000 RPM Oil Pressure CHECK Master ALT ON Mixture LEAN Flaps UP Lights ON Avionics ON Radios SET ATIS GET	ForeFlight STOP REC Flight Plan CLOSE SECURING Scout REMOVE Control Lock SET Hobbs/Tach NOTE Squawks NOTE Sun Shade REPLACE Pitot Cover REPLACE Wheels CHOCK
Fuel Gauge TRUE Flaps EXTEND Electrics OFF Master OFF Oil 6-8 QTS Fuel DRAIN Exterior CHECK Ties/Chocks REMOVE Baggage CHECK Walkaround EXECUTE Seat ADJUST START	Mixture . BEST POWER Throttle . 1000 RPM Oil Pressure . CHECK Master . ALT ON Mixture . LEAN Flaps . UP Lights . ON Avionics . ON Radios . SET ATIS . GET Barometer . SET XPDR . SET	ForeFlight STOP REC Flight Plan CLOSE SECURING Scout REMOVE Control Lock SET Hobbs/Tach NOTE Squawks NOTE Sun Shade REPLACE Pitot Cover REPLACE Wheels CHOCK Ties TIE Doors LOCK
Fuel Gauge TRUE Flaps EXTEND Electrics OFF Master OFF Oil 6-8 QTS Fuel DRAIN Exterior CHECK Ties/Chocks REMOVE Baggage CHECK Walkaround EXECUTE Seat ADJUST START Passengers BRIEF	Mixture . BEST POWER Throttle	ForeFlight STOP REC Flight Plan CLOSE SECURING Scout REMOVE Control Lock SET Hobbs/Tach NOTE Squawks NOTE Sun Shade REPLACE Pitot Cover REPLACE Wheels CHOCK Ties TIE Doors LOCK
Fuel Gauge TRUE Flaps EXTEND Electrics TEST Electrics OFF Master OFF Oil 6-8 QTS Fuel DRAIN Exterior CHECK Ties/Chocks REMOVE Baggage CHECK Walkaround EXECUTE Seat ADJUST START Passengers BRIEF Seatbelts CHECK iPad CONN SCOUT	Mixture . BEST POWER Throttle 1000 RPM Oil Pressure CHECK Master ALT ON Mixture LEAN Flaps	ForeFlight STOP REC Flight Plan CLOSE SECURING Scout REMOVE Control Lock SET Hobbs/Tach NOTE Squawks NOTE Sun Shade REPLACE Pitot Cover REPLACE Wheels CHOCK Ties TIE Doors LOCK FIRE ON START IF START Run 5 sec Mixture IDLE C/O
Fuel Gauge TRUE Flaps EXTEND Electrics TEST Electrics OFF Master OFF Oil 6-8 QTS Fuel DRAIN Exterior CHECK Ties/Chocks REMOVE Baggage CHECK Walkaround EXECUTE Seat ADJUST START Passengers BRIEF Seatbelts CHECK iPad CONN SCOUT ForeFlight START REC	Mixture . BEST POWER Throttle	ForeFlight STOP REC Flight Plan CLOSE SECURING Scout REMOVE Control Lock SET Hobbs/Tach NOTE Squawks NOTE Sun Shade REPLACE Pitot Cover REPLACE Wheels CHOCK Ties TIE Doors LOCK FIRE ON START IF START Run 5 sec Mixture IDLE C/O Evacuate GO
Fuel Gauge TRUE Flaps EXTEND Electrics OFF Master OFF Oil 6-8 QTS Fuel DRAIN Exterior CHECK Ties/Chocks REMOVE Baggage CHECK Walkaround EXECUTE Seat ADJUST START Passengers BRIEF Seatbelts CHECK iPad CONN SCOUT ForeFlight START REC Circuit Breakers CHECK	Mixture . BEST POWER Throttle	ForeFlight STOP REC Flight Plan CLOSE SECURING Scout REMOVE Control Lock SET Hobbs/Tach NOTE Squawks NOTE Sun Shade REPLACE Pitot Cover REPLACE Wheels CHOCK Ties TIE Doors LOCK FIRE ON START IF START Run 5 sec Mixture IDLE C/O Evacuate GO
Fuel Gauge TRUE Flaps EXTEND Electrics OFF Master OFF Oil 6-8 QTS Fuel DRAIN Exterior CHECK Ties/Chocks REMOVE Baggage CHECK Walkaround EXECUTE Seat ADJUST START Passengers BRIEF Seatbelts CHECK iPad CONN SCOUT ForeFlight START REC Circuit Breakers CHECK Standby Battery TEST	Mixture . BEST POWER Throttle 1000 RPM Oil Pressure CHECK Master ALT ON Mixture LEAN Flaps UP Lights ON Avionics ON Radios SET ATIS GET Barometer SET XPDR SET XPDR	ForeFlight STOP REC Flight Plan CLOSE SECURING Scout REMOVE Control Lock SET Hobbs/Tach NOTE Squawks NOTE Sun Shade REPLACE Pitot Cover REPLACE Wheels CHOCK Ties TIE Doors LOCK FIRE ON START IF START Run 5 sec Mixture IDLE C/O Evacuate GO IF NO START Crank CONTINUE
Fuel Gauge TRUE Flaps EXTEND Electrics OFF Master OFF Oil 6-8 QTS Fuel DRAIN Exterior CHECK Ties/Chocks REMOVE Baggage CHECK Walkaround EXECUTE Seat ADJUST START Passengers BRIEF Seatbelts CHECK iPad CONN SCOUT ForeFlight START REC Circuit Breakers CHECK Standby Battery TEST Standby Battery ARM	Mixture . BEST POWER Throttle	ForeFlight STOP REC Flight Plan CLOSE SECURING Scout REMOVE Control Lock SET Hobbs/Tach NOTE Squawks NOTE Sun Shade REPLACE Pitot Cover REPLACE Wheels CHOCK Ties TIE Doors LOCK FIRE ON START IF START Run 5 sec Mixture IDLE C/O Evacuate GO IF NO START Crank CONTINUE Mixture IDLE C/O
Fuel Gauge TRUE Flaps EXTEND Electrics TEST Electrics OFF Master OFF Oil 6-8 QTS Fuel DRAIN Exterior CHECK Ties/Chocks REMOVE Baggage CHECK Walkaround EXECUTE Seat ADJUST START Passengers BRIEF Seatbelts CHECK iPad CONN SCOUT ForeFlight START REC Circuit Breakers CHECK Standby Battery TEST Standby Battery ARM Engine Ind CHECK	Mixture BEST POWER Throttle 1000 RPM Oil Pressure CHECK Master ALT ON Mixture LEAN Flaps UP Lights ON Avionics ON Radios SET ATIS GET Barometer SET XPDR SET TAXI Brakes TEST Controls WIND Taxi Turns EXECUTE RUNUP Brakes SET Controls CORRECT PFD NO RED XS Flight Inst CHECK	ForeFlight STOP REC Flight Plan CLOSE SECURING Scout REMOVE Control Lock SET Hobbs/Tach NOTE Squawks NOTE Sun Shade REPLACE Pitot Cover REPLACE Wheels CHOCK Ties TIE Doors LOCK FIRE ON START IF START Run 5 sec Mixture IDLE C/O Evacuate GO IF NO START Crank CONTINUE Mixture IDLE C/O Throttle FULL
Fuel Gauge TRUE Flaps EXTEND Electrics OFF Master OFF Oil 6-8 QTS Fuel DRAIN Exterior CHECK Ties/Chocks REMOVE Baggage CHECK Walkaround EXECUTE Seat ADJUST START Passengers BRIEF Seatbelts CHECK iPad CONN SCOUT ForeFlight START REC Circuit Breakers CHECK Standby Battery TEST Standby Battery ARM	Mixture . BEST POWER Throttle	ForeFlight STOP REC Flight Plan CLOSE SECURING Scout REMOVE Control Lock SET Hobbs/Tach NOTE Squawks NOTE Sun Shade REPLACE Pitot Cover REPLACE Wheels CHOCK Ties TIE Doors LOCK FIRE ON START IF START Run 5 sec Mixture IDLE C/O Evacuate GO IF NO START Crank CONTINUE Mixture IDLE C/O

C172SP FLIGHT PROCEDURES **TAKEOFF BRIEF** Runway CHECK HI .. SET TO COMPASS **APPROACH CFGS** Crosswind CHECK NORMAL/SOFT Abort Speed NOTE Flaps FULL Technique NOTE Speed65 Flaps **SET** SHORT Min. Ret. Alt. NOTE Best Glide 60-70 Flaps **FULL** Time **NOTE** Speed60 Mixture .. BEST POWER LOW VOLTAGE **CLIMB** Power GT 1000 RPM Lights/Pitot OFF Mixture LEAN >3k Avionics OFF HI .. SET TO COMPASS Master ALT OFF Engine Inst. CHECK Alt CHECK **PRE-DESCENT** Master ALT ON HI .. SET TO COMPASS Avionics ESSENTIAL Engine Inst. CHECK Lights/Pitot . ESSENTIAL ATIS **GET** Flight TERMINATE BarometerSET CYCLE ONCE ONLY Tower CONTACT **OVERVOLTAGE** Fuel **BOTH** Mixture ENRICH Master ALT OFF Lights ON Alt PULL Avionics OFF **AFTER LANDING** Lights/Pitot Essential Flight TERMINATE Trim TAKEOFF **ENGINE FAILURE** Mixture LEAN Taxi Diag. OPEN Best Glide 60-70 Landing Site FIND **SWITCH TO GROUND** Fuel Shutoff ON TAKEOFF CFGS Throttle HALF NORMAL Throttle FULL Mixture VARY Rotate55 Fuel Pump ON Mags TEST BOTH SHORT IF NO RESTART Flaps10 Brakes SET Emergency DECLARE Climb 56 TO 50' Fuel ShutoffOUT Mixture IDLE C/O SOFT Mags **OFF** Flaps10 Master OFF Nosewheel LIGHT DoorsUNLATCH

Landing **EXECUTE**

Ground Effect 60

ENGINE FIRE

IDLE C/O

Mixture

ELECTRICAL FIRE

Master	OFF
Vents/Air	CLOSE
Extinguisher	USE
Vents	OPEN
Breakers	CHECK
Master . ON IF C	RITICAL
Flight TER	MINATE