C172SP GROUND PROCEDURES		
DISPATCH	BATT S Amps CHECK	Trim TAKEOFF
Weather BRIEF	STBY BATTCHECK	GPS/NAV CONFIG
NOTAMsCHECK	Alt. Static CHECK	Heading BugSET
W&B CHECK	Fuel Shutoff IN	Radios SET
Perf. Reqs CHECK	Fuel Selector BOTH	XPDR SET
SquawksCHECK	Brakes SET	Mixture BEST POWER
IMSAFE CHECK	Master BATT ON	Throttle 1800 RPM
Devices CHARGED	Avionics BUS 1 ON	Annunciators CHECK
PASSENGER BRIEF	AvionicsFAN	Vacuum CHECK
PIC NOTE	Avionics BUS 1 OFF Avionics BUS 2 ON	Amps/Volts CHECK Oil CHECK
Ramp Safety NOTE	Avionics AFT FAN	Mags CHECK
Flight Plan NOTE	AvionicsBUS 2 OFF	Throttle 1000 RPM
Seatbelts NOTE	BeaconON	Throttle Friction SET
Air Vents NOTE	HOT: SKIP PRIME	SWITCH TO FLIGHT
Safety Equipment . NOTE	Throttle1"	SHUTDOWN
Traffic & Talking NOTE	MixtureRICH	XPDRSET
Questions NOTE	Fuel Pump ON	Brakes SET
INSPECTION	Fuel Pump OFF	ElectricalOFF
AV1ATE CHECK	END PRIME	Avionics OFF
FuelSTICK		Mixture IDLE C/O
AROW CHECK	Mixture IDLE C/O ThrottleSLIGHT	MagsOFF
Scout SETUP	Clear Prop . ANNOUNCE	Master OFF
Avionics OFF	MagsSTART	Fuel LEFT
Master ON	Mixture BEST POWER	ForeFlight STOP REC
Fuel Gauge TRUE Flaps EXTEND	Throttle 1000 RPM	Flight Plan CLOSE
Electrics TEST	Oil Pressure CHECK	SECURING
ElectricsOFF	Master ALT ON	Scout REMOVE
Master OFF	Mixture LEAN	Control LockSET
Oil 6-8 QTS	Flaps	Hobbs/TachNOTE
Fuel DRAIN	Lights ON	Squawks NOTE
Exterior CHECK	Avionics ON	Sun Shade REPLACE
Ties/Chocks REMOVE	Radios SET	Pitot Cover REPLACE
BaggageCHECK	ATIS GET	WheelsCHOCK
Walkaround EXECUTE	Barometer SET	TiesTIE
Seat ADJUST	XPDRSET	Doors LOCK
START	TAXI	FIRE ON START
Passengers BRIEF	Brakes TEST Controls WIND	IF START
Seatbelts CHECK	Taxi Turns EXECUTE	Run 5 sec
iPad CONN SCOUT		Mixture IDLE C/O
ForeFlight START REC	RUNUP	EvacuateGO
Circuit Breakers . CHECK	Brakes SET	IF NO START
Standby Battery TEST	Controls CORRECT	Crank CONTINUE Mixture IDLE C/O
Standby Battery ARM	PFDNO RED XS	Throttle FULL
Engine Ind CHECK Bus E Volts 24 MIN	Flight Inst CHECK Fuel BOTH	Fuel ShutoffOUT
LUB L VUIB 24 IVIIN		
M Bus Volts 1.5 MAX	Autopilot CHECK	EvacuateGO

C172SP FLIGHT PROCEDURES **TAKEOFF BRIEF ENGINE FIRE** Flaps **UP** RunwayCHECK Mixture IDLE C/O HI .. SET TO COMPASS Fuel ShutoffOUT **APPROACH CFGS** Crosswind CHECK Master **OFF** NORMAL/SOFT Cabin AirCLOSE Abort Speed NOTE Flaps **FULL** Vents OPEN Technique NOTE Speed65 Speed INCREASE Flaps **SET** SHORT Flight TERMINATE Min. Ret. Alt. NOTE Best Glide 60-70 **ELECTRICAL FIRE** Flaps **FULL** Time **NOTE** Speed60 Master **OFF** Mixture .. BEST POWER Vents/Air CLOSE LOW VOLTAGE **CLIMB** Extinguisher USE Power GT 1000 RPM Vents OPEN Lights/Pitot OFF Mixture LEAN >3k BreakersCHECK Avionics OFF HI .. SET TO COMPASS Master . ON IF CRITICAL Master ALT OFF Engine Inst. CHECK Flight TERMINATE Alt CHECK **PRE-DESCENT** IMPORTANT NUM. Master ALT ON HI .. SET TO COMPASS Avionics ESSENTIAL Engine Inst. CHECK Lights/Pitot . ESSENTIAL V_s48 ATIS **GET** Flight TERMINATE BarometerSET CYCLE ONCE ONLY Tower CONTACT **OVERVOLTAGE** Fuel **BOTH** Mixture ENRICH Master ALT OFF Lights ON Alt PULL V_a 105 Avionics OFF V_{no} 129 **AFTER LANDING** Lights/Pitot Essential Flight TERMINATE Best Glide65 Trim TAKEOFF Max Gross2550 **ENGINE FAILURE** Mixture LEAN Max Crosswind 15 Taxi Diag. OPEN Best Glide 60-70 Fuel53 Landing Site FIND **SWITCH TO GROUND** Fuel Shutoff ON **TAKEOFF CFGS** Throttle HALF NORMAL Throttle FULL

Mixture VARY

Fuel Pump ON

Mags TEST BOTH

IF NO RESTART

Emergency DECLARE

Fuel ShutoffOUT

Mixture IDLE C/O

Mags **OFF**

Master OFF

DoorsUNLATCH

Landing EXECUTE

Rotate55

SHORT

Flaps10

Brakes SET

Climb 56 TO 50'

SOFT

Flaps10

Nosewheel LIGHT

Ground Effect 60