CITABRIA 7ECA GROUND PROCEDURES			
DISPATCH	Mixture LEAN	FIRE ON START	
Weather BRIEF NOTAMS CHECK W&B CHECK Perf. Reqs CHECK Squawks CHECK	Lights ON Radios SET ATIS GET Barometer SET XPDR SET Taxi Diag. OPEN	IF START  Run 5 sec  Mixture IDLE C/O  Evacuage GO  IF NO START	
IMSAFE CHECK		Crank CONTINUE	
INSPECTION  AV1ATE CHECK  Fuel STICK  AROW CHECK	TAXI  Brakes TEST  Controls WIND	Mixture IDLE C/O Throttle FULL Fuel ShutoffOUT	
Mags <b>OFF</b>	RUNUP	Evacuage GO	
Fuel Gauges TRUE Fuel Shutoff IN Master ON Lights CHECK Stall Horn CHECK Master OFF ELT ARMED Oil 5-6 qts Fuel DRAIN Exterior CHECK Ties/Chocks REMOVE Walkaround EXECUTE	Doors CLOSED Seatbelts CHECK Brakes SET Controls CORRECT Trim TAKEOFF Flight Inst. CHECK Fuel Shutoff IN Mixture BEST POWER Throttle 1800 RPM Mags CHECK Carb. Heat CHECK Engine Inst. CHECK Throttle 1000 RPM		
Passengers BRIEF	SWITCH TO FLIGHT		
Seatbelts CHECK Breakers CHECK	SHUTDOWN		
Fuel Shutoff IN  Electrical OFF  Door CLOSED  Stick FULL AFT  Carb. Heat COLD  Mixture RICH  HOT: SKIP PRIME  Prime 2x	Brakes SET Lights OFF GPS OFF XPDR SET, OFF Mixture IDLE C/O Mags OFF Master OFF Flight Plan CLOSE		
Primer LOCKED Master Switch ON	SECURING		
Mags ON Beacon ON Throttle SLIGHT Brakes SET Clear Prop ANNOUNCE Starter PUSH Throttle 1000 RPM Oil Pressure CHECK Ammeter CHECK	Front Lap BeltSTICK Back Lap Belt . BUCKLE Hobbs/TachNOTE SquawksNOTE Sun ShadesREPLACE WheelsCHOCK Tail WheelREORIENT TiesTIE DoorsLOCK		

CITABRIA 7ECA FLIGHT PROCEDURES			
TAKEOFF BRIEF	APPROACH CFGS	NOTES	
Runway CHECK Crosswind CHECK Abort Speed NOTE Technique NOTE Min. Ret. Alt NOTE Best Glide NOTE Time NOTE Mixture BEST POWER	NORMAL  Speed	<ul> <li>All airspeeds in MPH</li> <li>Carb. heat always on if icing suspected, indicated by gradual loss of RPM</li> <li>Use only rudder on takeoff and landing (no</li> </ul>	
CLIMB	Master CYCLE	brakes)	
ThrottleOPEN	Nonessentials OFF Flight TERMINATE	Mixture should be leaned at any altitude when un-	
IF BELOW 5000	OVERVOLTAGE	der 75% power. Lean	
Mixture BEST POWER Engine Inst CHECK Speed 75-80	Master CYCLE Flight TERMINATE ENGINE FAILURE	until engine roughness, then enrichen to smoothness.	
PRE-DESCENT	Best Glide <b>65</b>	IMPORTANT NUM.	
Engine Inst CHECK ATIS GET Barometer SET Tower CONTACT Mixture ENRICH Lights ON	Fuel Shutoff ON Throttle HALF Throttle FULL Mixture VARY Primer TRY Carb. Heat HOT Mags TEST BOTH	Vso       50         Vrotate       .55         Vx       58         Vy       69         Va       120         Vno       120         Vne       162	
AFTER LANDING	IF NO RESTART	Best Glide65	
Carb. Heat COLD Trim TAKEOFF Mixture LEAN Taxi Diag OPEN  SWITCH TO GROUND	Squawk	Max Gross1750 Max Crosswind15 Fuel35	
TAKEOFF CFGS	ENGINE FIRE		
NORMAL	Mixture IDLE C/O		
Rotate	Fuel Shutoff OUT Switches ALL OFF Cabin Heat OFF Extinguisher USE Flight TERMINATE		
Climb 58	ELECTRICAL FIRE		
SOFT	Electrical OFF Vents OPEN Extinguisher USE		
Attitude TAIL LOW After Liftoff LEVEL	IF FIRE CONTINUES		

Flight ..... **TERMINATE**