CATAOR OROLING RECOEDURES			
	72SP GROUND PROCEDUR		
DISPATCH	Throttle 1000 RPM	SECURING	
Weather BRIEF	Oil Pressure CHECK	Control LockSET	
NOTAMsCHECK	MasterALT ON	Hobbs/TachNOTE	
W&B CHECK	Mixture LEAN	Squawks NOTE	
Perf. Reqs CHECK	Flaps UP	Sun Shade REPLACE	
SquawksCHECK	Lights ON Avionics ON	Pitot Cover REPLACE	
INSPECTION	Radios SET	WheelsCHOCK	
Fuel DRAIN, CHECK	ATIS GET	Ties	
AV1ATE CHECK	BarometerSET	Doors LOCK	
AROWCHECK	XPDRSET	FIRE ON START	
Avionics OFF	Taxi Diag OPEN	IF START	
Master ON	TAXI	Run 5 sec	
Fuel GaugeTRUE		Mixture IDLE C/O	
Flaps EXTEND	Brakes TEST	Evacuate	
Electrics TEST	Controls WIND Taxi Turns EXECUTE	IF NO START	
Electrics OFF		CrankCONTINUE	
Master OFF	RUNUP	Mixture IDLE C/O	
Oil 6-8 qts	Brakes SET	Throttle FULL	
Exterior CHECK	Controls CORRECT	Fuel ShutoffOUT	
Ties/Chocks REMOVE	Flight Inst CHECK	EvacuateGO	
BaggageCHECK	Fuel BOTH		
Walkaround EXECUTE	AutopilotCHECK		
Seat ADJUST	Trim TAKEOFF GPS/NAV CONFIG		
START	Heading Bug SET		
Passengers BRIEF	Radios SET		
Seatbelts CHECK	XPDRSET		
Circuit Breakers . CHECK	MixtureRICH		
Alt. Static CHECK	Throttle 1800 RPM		
Fuel Shutoff IN	Annunciators CHECK		
Fuel Selector BOTH	Vacuum CHECK		
Brakes SET	Amps/Volts CHECK		
Master BATT ON	Oil CHECK		
Avionics FAN	Mags CHECK		
Avionics OFF	Throttle 1000 RPM		
BeaconON	Throttle Friction SET		
HOT: SKIP PRIME	SWITCH TO FLIGHT		
Throttle1"	SHUTDOWN		
MixtureRICH	XPDR SET		
Fuel Pump ON	Brakes SET		
Fuel Pump OFF	Electrical OFF		
END PRIME	Avionics OFF		
Mixture IDLE C/O	Mixture IDLE C/O		
ThrottleSLIGHT	Mags OFF		
Clear Prop . ANNOUNCE	Master OFF		
MagsSTART	Fuel LEFT		
MixtureRICH	Flight Plan CLOSE		

C1	172SP FLIGHT PROCEDURE	ES
TAKEOFF BRIEF Runway	Climb .65 Flaps .UP APPROACH CFGS NORMAL/SOFT Flaps .FULL Speed .65	Mixture IDLE C/O Fuel Shutoff OUT Master OFF Cabin Air CLOSE Vents OPEN Speed INCREASE Flight TERMINATE
Min. Ret. Alt NOTE Best Glide 60-70	SHORT Flaps FULL	ELECTRICAL FIRE
Time NOTE	Speed 60	Master OFF Vents/Air CLOSE
MixtureRICH	LOW VOLTAGE	ExtinguisherUSE
CLIMB Flaps	Power GT 1000 RPM Lights/Pitot OFF Avionics OFF Master ALT OFF Alt CHECK Master ALT ON Avionics ESSENTIAL	Vents OPEN Breakers CHECK Master .ON IF CRITICAL Flight TERMINATE
Engine Inst CHECK ATIS GET	Lights/Pitot . ESSENTIAL Flight TERMINATE	
BarometerSET	CYCLE ONCE ONLY	
Tower CONTACT Fuel BOTH Mixture ENRICH	OVERVOLTAGE Master ALT OFF Alt PULL	
AFTER LANDING	AvionicsOFF Lights/PitotEssential	
	Avionics OFF	
AFTER LANDING Flaps UP Trim TAKEOFF Mixture LEAN Taxi Diag. OPEN SWITCH TO GROUND TAKEOFF CFGS NORMAL Flaps UP	Avionics OFF Lights/Pitot Essential Flight TERMINATE ENGINE FAILURE Best Glide 60-70 Landing Site FIND Fuel Shutoff ON Throttle HALF Throttle FULL Mixture VARY Fuel Pump ON	
AFTER LANDING Flaps UP Trim TAKEOFF Mixture LEAN Taxi Diag. OPEN SWITCH TO GROUND TAKEOFF CFGS NORMAL Flaps UP Rotate 55 Climb 74	Avionics OFF Lights/Pitot Essential Flight TERMINATE ENGINE FAILURE Best Glide 60-70 Landing Site FIND Fuel Shutoff ON Throttle HALF Throttle FULL Mixture VARY Fuel Pump ON Mags TEST BOTH	
AFTER LANDING Flaps UP Trim TAKEOFF Mixture LEAN Taxi Diag. OPEN SWITCH TO GROUND TAKEOFF CFGS NORMAL Flaps UP Rotate 55	Avionics OFF Lights/Pitot Essential Flight TERMINATE ENGINE FAILURE Best Glide 60-70 Landing Site FIND Fuel Shutoff ON Throttle HALF Throttle FULL Mixture VARY Fuel Pump ON	

ENGINE FIRE

Ground Effect 60