C172SP GROUND PROCEDURES		
DISPATCH	Baggage Door Closed Ties/Chocks Removed	RUNUP
Weather Brief	Walk Around	Brakes Set Fuel Both
W&BCheck	vancona	ControlsFree & Correct
Perf. ReqsCheck	START	Annunciators Check
NOTAMs Check		Instruments Check
IMSAFECheck	Passengers Brief	Mixture Best Power
Charts Pack	Brakes Set	Throttle1,800 RPM
Squawks Check	Seat Track Locked Seatbelts Check	Mags<150↓ <50∆
INTERIOR	Circuit BreakersIn	Vacuum Sys Green
INTERIOR	Avionics Off	Electric. Sys Check
Pitot Cover Remove	Throttle1/4"	Oil Pressure Green
PapersAROW	Mixture Lean	Oil Temperature Green
Fuel Selector Both	Prop Clear	Throttle1,000 RPM
Fuel ShutoffIn TrimTakeoff	Master On	Mixture Lean
Master On	Beacon On	Throttle Friction Set
Flaps30°		Radios Set
Fuel Gauges Note	Aux Fuel Pump On	SWITCH TO FLIGHT
Fuel Annunciators Off	MixtureRich	SHUTDOWN
Annuciators Test	Fuel Flow 3-5 GPH	ELT Check 121.5
Avionics Fan Audible	MixtureIdle C/O	Avionics Off
Alternate Static Check	Aux Fuel Pump Off	Mixture C/O
Int. Lights Check		Mags Off
Ext. Lights Check	Mags Start	MasterOff
Pitot Heat Check	MixtureRich	Fuel Left
Master Off	Oil Pressure Green Throttle 1,000 RPM	Lights Off
Hobbs & Tach Record	Mixture Lean	SECURING
Seat Adjust	Wilkland Edan	Hobbs & Tach Record
EXTERIOR	PRE-TAXI	Control LockSet
Fuel Quantity	Cook Dolla	Tie Downs Secure
Fuel Quality	Seat Belts Check	Pitot Cover Replace Sun Shades Replace
Static PortClear	Flaps Up Heat/Vent/Defrost . Check	DoorsLock
Leading Edges Check	Avionics On	Squawks Record
Stall Indicator Clear	Atis Get	Flight PlanClose
Fuel VentClear	Altimeter Set	FIRE ON START
Ailerons Check	XPDR Alt. & Sqwk	IF START
FlapsCheck	ADS-BOn	Throttle1,800 RPM
Elevator Check	Radio Test	Run
Rudder Check Trim Tab Check	Taxi Lights As Req'd	MixtureIdle C/O
Exhaust Secure	Brakes Test	IF NO START
Intake	TAX	Crank Continue
Prop Check	TAXI	Throttle Full
Engine Cowl., Belt	Controls	MixtureIdle C/O
Oil6–8 Qt.	Attitude Indicator Check	Fuel ShutoffOut
Fuel Caps Secure	Turn Coordinator Check	Master & Mags Off
Windscreen Clean	Heading IndicatorSet	

C172SP FLIGHT PROCEDURES

C172SP FLIGHT PROCEDURES			
PRE-TAKEOFF	ENGINE FAILURE	ELECTRICAL FIRE	
RunwayCheck	Best Glide 68	All Switches Off	
TechniqueNote	Landing Site Find	Vents/AirClose	
CrosswindCheck	WindIdentify	Extinguisher Use	
Abort Plan Brief	Fuel Cutoffin	Ensure Fire Extinguished	
TPA Brief	Fuel Selector Both	Vents Open	
Time	Aux Fuel Pump On	Breakers Check	
HI Set To Compass	MixtureRich	Master On If Critical	
FlapsSet	Mags Test Both	Flight Terminate	
Trim Takeoff	Master On	IMPORTANT NUM.	
Lights On		V _X 62 V _Y 74	
XPDR Set	FORCED LANDING	$V_{S_0} \dots 40 V_{S_1} \dots 48$	
Mixture Best Power	Best Glide 68	V _{FE 10} 110 V _{FE} 85	
CLIMB	Squawk 7700	V _{NO} 129 V _{NE} 163	
	Emergency Declare	V _{ROT} 55 V _{A₂₅₅₀} 105	
70-85 KIAS	MixtureIdle C/O	$V_{A_{2200}} \dots 98 V_{A_{1900}} \dots 90$	
Flaps Up Power Set	Fuel Shutoff Out	Fuel 56 Usable 53	
MixtureLean >3k	Mags Off	Best Glide68	
	Flaps As Req'd	Max Gross2550	
Engine Inst Check	Master Off	Max Crosswind15	
CRUISE	Seatbelts Secure		
Power Set	DoorsUnlatch	TAKEOFF CFGS	
MixtureLean >3k	Landing Execute	NORMAL	
Instruments Check	LOW VOLTAGE	Flaps	
Flaps		Rotate55	
Switches (Pump)	Power>1000 RPM	Climb74	
DESCENT Fuel Both	Avionics Master OFF	SHORT	
	Alt. CBCHECK IN	Flaps 10 °	
Power Set	Master Switch CYCLE	Brakes Apply	
MixtureLean >3k	"VOLTS" CHECK OFF	Climb 56	
Instruments Check	Avionics MasterON	Flaps Up at >60 KIAS	
LightsOn	If "VOLTS" illumniated:	APPROACH	
ATIS Get	Master ALT OFF	NORMAL	
Altimeter Set	Nonessential Equip OFF	Downwind 85	
Tower Contact	Flight TERMINATE	Base	
PRE-LANDING	OVERVOLTAGE	Final60 - 70	
Autopilot Off	Master Alt. Off		
Seat BeltsSecured	Nonessential Equip Off		
Fuel Both	Flight Terminate		
Brakes Test	Beware Compass Deviat'n		
Mixture Best Power	<u> </u>		
Flaps As Req'd	ENGINE FIRE		
LightsOn	MixtureIdle C/O		
AFTER LANDING	Fuel ShutoffOut		
Flace Uni	Maria		

Master Off

Heat & Air Close

Airspeed100+ Forced Landing . Execute

Flaps **Up**

Trim Takeoff

Switches Off

Mixture Lean