C172SP G1000 GROUND PROCEDURES		
DISPATCH	BATT S Amps CHECK	Radios SET
Weather BRIEF	Alt. Static CHECK	Transponder SET
NOTAMs CHECK	Fuel Shutoff IN	Mixture BEST POWER
W&BCHECK	Fuel Selector BOTH	Throttle 1800 RPM
Perf. Reqs CHECK	Brakes SET	AnnunciatorsCHECK
	Master BATT ON	VacuumCHECK
SquawksCHECK	Avionics BUS 1 FAN	Amps/VoltsCHECK
IMSAFE CHECK	Avionics BUS 2 FAN	Oil CHECK
Devices CHARGE	Avionics OFF	Mags CHECK
PASSENGER BRIEF	BeaconON	Throttle 1000 RPM
PIC <b>NOTE</b>		Throttle FrictionSET
Ramp Safety NOTE	HOT: SKIP PRIME	
Flight PlanNOTE	Throttle1"	SWITCH TO FLIGHT
Seatbelts NOTE	Mixture RICH	SHUTDOWN
Air Vents NOTE	Fuel Pump ON	Transponder SET
Safety Equipment NOTE	Fuel Pump OFF	Brakes SET
Traffic & Talking NOTE	END PRIME	Electrical OFF
Questions NOTE	MixtureIDLE C/O	Avionics OFF
INSPECTION	ThrottleSLIGHT	MixtureIDLE C/O
AV1ATECHECK	Prop CLEAR	Mags <b>OFF</b>
	Mags START	Master OFF
AROW CHECK	Mixture BEST POWER	Standby Batt OFF
FuelSTICK	Throttle 1000 RPM	Fuel <b>LEFT</b>
ScoutSETUP	Oil Pressure CHECK	ForeFlight STOP REC
Avionics OFF Master ON	Master ALT ON	Flight Plan CLOSE
Macter ()N		
Fuel Gauges TRUE	Mixture LEAN	SECURING
Fuel GaugesTRUE Flaps EXTEND	Mixture LEAN Flaps UP	SECURING Scout REMOVE
Fuel GaugesTRUE Flaps EXTEND ElectricsTEST	Mixture LEAN Flaps UP Lights ON	SECURING Scout REMOVE Control LockSET
Fuel GaugesTRUE FlapsEXTEND ElectricsTEST ElectricsOFF	Mixture LEAN Flaps UP Lights ON Avionics ON	SECURING Scout REMOVE Control Lock SET Hobbs/Tach NOTE
Fuel Gauges TRUE Flaps EXTEND Electrics TEST Electrics OFF Master OFF	Mixture LEAN Flaps UP Lights ON Avionics ON Radios SET	SECURING Scout REMOVE Control Lock SET Hobbs/Tach NOTE Squawks NOTE
Fuel Gauges TRUE Flaps EXTEND Electrics TEST Electrics OFF Master OFF Oil 6–8 QTS	Mixture LEAN Flaps UP Lights ON Avionics ON Radios SET ATIS GET	SECURING  Scout REMOVE Control Lock SET Hobbs/Tach NOTE Squawks NOTE Sun Shade REPLACE
Fuel GaugesTRUE FlapsEXTEND ElectricsOFF MasterOFF Oil6-8 QTS FuelDRAIN	MixtureLEANFlapsUPLightsONAvionicsONRadiosSETATISGETBarometerSET	SECURING  Scout REMOVE Control Lock SET Hobbs/Tach NOTE Squawks NOTE Sun Shade REPLACE Pitot Cover REPLACE
Fuel GaugesTRUE FlapsEXTEND ElectricsOFF MasterOFF Oil6-8 QTS FuelDRAIN ExteriorCHECK	Mixture LEAN Flaps UP Lights ON Avionics ON Radios SET ATIS GET Barometer SET Transponder SET	SECURING  Scout REMOVE Control Lock SET Hobbs/Tach NOTE Squawks NOTE Sun Shade REPLACE Pitot Cover REPLACE Wheels CHOCK
Fuel Gauges TRUE Flaps EXTEND Electrics TEST Electrics OFF Master OFF Oil 6–8 QTS Fuel DRAIN Exterior CHECK Ties/Chocks REMOVE	Mixture LEAN Flaps UP Lights ON Avionics ON Radios SET ATIS GET Barometer SET Transponder SET Totalizer SET	SECURING Scout REMOVE Control Lock SET Hobbs/Tach NOTE Squawks NOTE Sun Shade REPLACE Pitot Cover REPLACE Wheels CHOCK Ties TIE
Fuel Gauges TRUE Flaps EXTEND Electrics TEST Electrics OFF Master OFF Oil 6–8 QTS Fuel DRAIN Exterior CHECK Ties/Chocks REMOVE Baggage CHECK	Mixture LEAN Flaps UP Lights ON Avionics ON Radios SET ATIS GET Barometer SET Transponder SET Totalizer SET TAXI	SECURING  Scout REMOVE Control Lock SET Hobbs/Tach NOTE Squawks NOTE Sun Shade REPLACE Pitot Cover REPLACE Wheels CHOCK Ties TIE Doors LOCK
Fuel Gauges TRUE Flaps EXTEND Electrics TEST Electrics OFF Master OFF Oil 6-8 QTS Fuel DRAIN Exterior CHECK Ties/Chocks REMOVE Baggage CHECK Walkaround EXECUTE	Mixture LEAN Flaps UP Lights ON Avionics ON Radios SET ATIS GET Barometer SET Transponder SET Totalizer SET  TAXI Brakes TEST	SECURING  Scout REMOVE Control Lock SET Hobbs/Tach NOTE Squawks NOTE Sun Shade REPLACE Pitot Cover REPLACE Wheels CHOCK Ties TIE Doors LOCK
Fuel Gauges TRUE Flaps EXTEND Electrics TEST Electrics OFF Master OFF Oil 6–8 QTS Fuel DRAIN Exterior CHECK Ties/Chocks REMOVE Baggage CHECK	Mixture LEAN Flaps UP Lights ON Avionics ON Radios SET ATIS GET Barometer SET Transponder SET Totalizer SET  TAXI Brakes TEST Controls WIND	SECURING Scout REMOVE Control Lock SET Hobbs/Tach NOTE Squawks NOTE Sun Shade REPLACE Pitot Cover REPLACE Wheels CHOCK Ties TIE Doors LOCK FIRE ON START IF START
Fuel Gauges TRUE Flaps EXTEND Electrics TEST Electrics OFF Master OFF Oil 6-8 QTS Fuel DRAIN Exterior CHECK Ties/Chocks REMOVE Baggage CHECK Walkaround EXECUTE Seat ADJUST	Mixture LEAN Flaps UP Lights ON Avionics ON Radios SET ATIS GET Barometer SET Transponder SET Totalizer SET  TAXI Brakes TEST	SECURING Scout REMOVE Control Lock SET Hobbs/Tach NOTE Squawks NOTE Sun Shade REPLACE Pitot Cover REPLACE Wheels CHOCK Ties TIE Doors LOCK FIRE ON START IF START Run 5 sec
Fuel Gauges TRUE Flaps EXTEND Electrics TEST Electrics OFF Master OFF Oil 6-8 QTS Fuel DRAIN Exterior CHECK Ties/Chocks REMOVE Baggage CHECK Walkaround EXECUTE Seat ADJUST	Mixture LEAN Flaps UP Lights ON Avionics ON Radios SET ATIS GET Barometer SET Transponder SET Totalizer SET  TAXI Brakes TEST Controls WIND Taxi Turns EXECUTE	SECURING Scout REMOVE Control Lock SET Hobbs/Tach NOTE Squawks NOTE Sun Shade REPLACE Pitot Cover REPLACE Wheels CHOCK Ties TIE Doors LOCK FIRE ON START IF START Run 5 sec Mixture IDLE C/O
Fuel Gauges TRUE Flaps EXTEND Electrics TEST Electrics OFF Master OFF Oil 6-8 QTS Fuel DRAIN Exterior CHECK Ties/Chocks REMOVE Baggage CHECK Walkaround EXECUTE Seat ADJUST  START Passengers BRIEF	Mixture LEAN Flaps UP Lights ON Avionics ON Radios SET ATIS GET Barometer SET Transponder SET Totalizer SET  TAXI Brakes TEST Controls WIND Taxi Turns EXECUTE RUNUP	SECURING Scout REMOVE Control Lock SET Hobbs/Tach NOTE Squawks NOTE Sun Shade REPLACE Pitot Cover REPLACE Wheels CHOCK Ties TIE Doors LOCK FIRE ON START IF START Run 5 sec
Fuel Gauges TRUE Flaps EXTEND Electrics TEST Electrics OFF Master OFF Oil 6-8 QTS Fuel DRAIN Exterior CHECK Ties/Chocks REMOVE Baggage CHECK Walkaround EXECUTE Seat ADJUST  START  Passengers BRIEF Seatbelts CHECK	Mixture LEAN Flaps UP Lights ON Avionics ON Radios SET ATIS GET Barometer SET Transponder SET Totalizer SET  TAXI Brakes TEST Controls WIND Taxi Turns EXECUTE  RUNUP Brakes SET	SECURING Scout REMOVE Control Lock SET Hobbs/Tach NOTE Squawks NOTE Sun Shade REPLACE Pitot Cover REPLACE Wheels CHOCK Ties TIE Doors LOCK FIRE ON START IF START Run 5 sec Mixture IDLE C/O Evacuate GO
Fuel Gauges TRUE Flaps EXTEND Electrics TEST Electrics OFF Master OFF Oil 6-8 QTS Fuel DRAIN Exterior CHECK Ties/Chocks REMOVE Baggage CHECK Walkaround EXECUTE Seat ADJUST  START  Passengers BRIEF Seatbelts CHECK iPad CONN SCOUT	Mixture LEAN Flaps UP Lights ON Avionics ON Radios SET ATIS GET Barometer SET Transponder SET Totalizer SET  TAXI Brakes TEST Controls WIND Taxi Turns EXECUTE  RUNUP Brakes SET Controls SET Controls SET Controls CORRECT	SECURING Scout REMOVE Control Lock SET Hobbs/Tach NOTE Squawks NOTE Sun Shade REPLACE Pitot Cover REPLACE Wheels CHOCK Ties TIE Doors LOCK FIRE ON START IF START Run 5 sec Mixture IDLE C/O Evacuate GO
Fuel Gauges TRUE Flaps EXTEND Electrics TEST Electrics OFF Master OFF Oil 6–8 QTS Fuel DRAIN Exterior CHECK Ties/Chocks REMOVE Baggage CHECK Walkaround EXECUTE Seat ADJUST  START  Passengers BRIEF Seatbelts CHECK iPad CONN SCOUT ForeFlight START REC	Mixture LEAN Flaps UP Lights ON Avionics ON Radios SET ATIS GET Barometer SET Transponder SET Totalizer SET  TAXI Brakes TEST Controls WIND Taxi Turns EXECUTE  RUNUP Brakes SET Controls CORRECT PFD NO RED XS	SECURING Scout REMOVE Control Lock SET Hobbs/Tach NOTE Squawks NOTE Sun Shade REPLACE Pitot Cover REPLACE Wheels CHOCK Ties TIE Doors LOCK FIRE ON START IF START Run 5 sec Mixture IDLE C/O Evacuate GO  IF NO START Crank CONTINUE
Fuel Gauges TRUE Flaps EXTEND Electrics TEST Electrics OFF Master OFF Oil 6–8 QTS Fuel DRAIN Exterior CHECK Ties/Chocks REMOVE Baggage CHECK Walkaround EXECUTE Seat ADJUST  START  Passengers BRIEF Seatbelts CHECK iPad CONN SCOUT ForeFlight START REC Circuit Breakers CHECK	Mixture LEAN Flaps UP Lights ON Avionics ON Radios SET ATIS GET Barometer SET Transponder SET Totalizer SET  TAXI Brakes TEST Controls WIND Taxi Turns EXECUTE  RUNUP Brakes SET Controls CORRECT PFD NO RED XS Flight Inst. CHECK	SECURING Scout REMOVE Control Lock SET Hobbs/Tach NOTE Squawks NOTE Sun Shade REPLACE Pitot Cover REPLACE Wheels CHOCK Ties TIE Doors LOCK FIRE ON START IF START Run 5 sec Mixture IDLE C/O Evacuate GO  IF NO START Crank CONTINUE Mixture IDLE C/O
Fuel Gauges TRUE Flaps EXTEND Electrics TEST Electrics OFF Master OFF Oil 6–8 QTS Fuel DRAIN Exterior CHECK Ties/Chocks REMOVE Baggage CHECK Walkaround EXECUTE Seat ADJUST  START Passengers BRIEF Seatbelts CHECK iPad CONN SCOUT ForeFlight START REC Circuit Breakers CHECK Standby Battery TEST	Mixture LEAN Flaps UP Lights ON Avionics ON Radios SET ATIS GET Barometer SET Transponder SET Totalizer SET  TAXI Brakes TEST Controls WIND Taxi Turns EXECUTE  RUNUP Brakes SET Controls CORRECT PFD NO RED XS Flight Inst. CHECK Fuel BOTH	SECURING Scout REMOVE Control Lock SET Hobbs/Tach NOTE Squawks NOTE Sun Shade REPLACE Pitot Cover REPLACE Wheels CHOCK Ties TIE Doors LOCK FIRE ON START IF START Run 5 sec Mixture IDLE C/O Evacuate GO  IF NO START Crank CONTINUE Mixture IDLE C/O Throttle FULL
Fuel Gauges TRUE Flaps EXTEND Electrics TEST Electrics OFF Master OFF Oil 6–8 QTS Fuel DRAIN Exterior CHECK Ties/Chocks REMOVE Baggage CHECK Walkaround EXECUTE Seat ADJUST  START Passengers BRIEF Seatbelts CHECK iPad CONN SCOUT ForeFlight START REC Circuit Breakers CHECK Standby Battery TEST Standby Battery ARM	Mixture LEAN Flaps UP Lights ON Avionics ON Radios SET ATIS GET Barometer SET Transponder SET Totalizer SET  TAXI Brakes TEST Controls WIND Taxi Turns EXECUTE  RUNUP Brakes SET Controls CORRECT PFD NO RED XS Flight Inst. CHECK Fuel BOTH Autopilot CHECK	SECURING  Scout REMOVE Control Lock SET Hobbs/Tach NOTE Squawks NOTE Sun Shade REPLACE Pitot Cover REPLACE Wheels CHOCK Ties TIE Doors LOCK  FIRE ON START IF START  Run 5 sec Mixture IDLE C/O Evacuate GO  IF NO START Crank CONTINUE Mixture IDLE C/O Throttle FULL Fuel Shutoff OUT
Fuel Gauges TRUE Flaps EXTEND Electrics TEST Electrics OFF Master OFF Oil 6–8 QTS Fuel DRAIN Exterior CHECK Ties/Chocks REMOVE Baggage CHECK Walkaround EXECUTE Seat ADJUST  START  Passengers BRIEF Seatbelts CHECK iPad CONN SCOUT ForeFlight START REC Circuit Breakers CHECK Standby Battery TEST Standby Battery ARM Engine Ind CHECK	Mixture LEAN Flaps UP Lights ON Avionics ON Radios SET ATIS GET Barometer SET Transponder SET Totalizer SET  TAXI Brakes TEST Controls WIND Taxi Turns EXECUTE  RUNUP Brakes SET Controls CORRECT PFD NO RED XS Flight Inst. CHECK Fuel BOTH Autopilot CHECK Trim TAKEOFF	SECURING Scout REMOVE Control Lock SET Hobbs/Tach NOTE Squawks NOTE Sun Shade REPLACE Pitot Cover REPLACE Wheels CHOCK Ties TIE Doors LOCK FIRE ON START IF START Run 5 sec Mixture IDLE C/O Evacuate GO  IF NO START Crank CONTINUE Mixture IDLE C/O Throttle FULL
Fuel Gauges TRUE Flaps EXTEND Electrics TEST Electrics OFF Master OFF Oil 6–8 QTS Fuel DRAIN Exterior CHECK Ties/Chocks REMOVE Baggage CHECK Walkaround EXECUTE Seat ADJUST  START Passengers BRIEF Seatbelts CHECK iPad CONN SCOUT ForeFlight START REC Circuit Breakers CHECK Standby Battery TEST Standby Battery ARM	Mixture LEAN Flaps UP Lights ON Avionics ON Radios SET ATIS GET Barometer SET Transponder SET Totalizer SET  TAXI Brakes TEST Controls WIND Taxi Turns EXECUTE  RUNUP Brakes SET Controls CORRECT PFD NO RED XS Flight Inst. CHECK Fuel BOTH Autopilot CHECK	SECURING  Scout REMOVE Control Lock SET Hobbs/Tach NOTE Squawks NOTE Sun Shade REPLACE Pitot Cover REPLACE Wheels CHOCK Ties TIE Doors LOCK  FIRE ON START IF START  Run 5 sec Mixture IDLE C/O Evacuate GO  IF NO START Crank CONTINUE Mixture IDLE C/O Throttle FULL Fuel Shutoff OUT

C172SP G1000 FLIGHT PROCEDURES			
TAKEOFF BRIEF	Flaps	ENGINE FIRE	
Runway CHECK HI SET TO COMPASS Crosswind CHECK Abort Speed NOTE Technique NOTE Flaps SET Min. Ret. Alt NOTE Best Glide 60-70 Timer START	APPROACH CFGS NORMAL/SOFT Flaps .FULL Speed .65 SHORT Flaps .FULL Speed .60	Mixture	
Mixture BEST POWER	LOW VOLTAGE	Vents/Air CLOSE	
CLIMB  Flaps UP  Mixture LEAN > 3k  HI SET TO COMPASS  Engine Inst CHECK  PRE-DESCENT  HI SET TO COMPASS  Engine Inst CHECK  ATIS GET  Barometer SET  Tower CONTACT  Fuel BOTH  Mixture ENRICH  Lights ON  AFTER LANDING  Flaps UP  Trim TAKEOFF	Power GT 1000 RPM Lights/Pitot OFF Avionics OFF Master ALT OFF Alt CHECK Master ALT ON Avionics ESSENTIAL Lights/Pitot ESSENTIAL Flight TERMINATE  CYCLE ONCE ONLY OVERVOLTAGE  Master ALT OFF Alt PULL Avionics OFF Lights/Pitot Essential Flight TERMINATE	Extinguisher USE  Vents OPEN  Breakers CHECK  Master ON IF CRITICAL  Flight TERMINATE  IMPORTANT NUM.  V <sub>so</sub> 40  V <sub>s</sub> 48  V <sub>rotate</sub> 55  V <sub>x</sub> 62  V <sub>y</sub> 74  V <sub>fe</sub> 85  V <sub>fe-10</sub> 110  V <sub>a</sub> 105  V <sub>no</sub> 129  V <sub>ne</sub> 163  Best Glide 60–70  May Gross 2550	
Mixture LEAN Taxi Diag. OPEN  SWITCH TO GROUND TAKEOFF CFGS NORMAL  Flaps UP Rotate 55 Climb 74  SHORT	ENGINE FAILURE  Best Glide	Max Gross       2550         Max Crosswind       15         Fuel       56         Usable Fuel       53	
Flaps	IF NO RESTART  Squawk		

Mixture .....IDLE C/O

Mags ..... **OFF** 

Master ..... OFF

Doors .........UNLATCH

Landing ..... EXECUTE

SOFT

Flaps ......10

Nosewheel ......LIGHT

Ground Effect ...... 60

Climb ......65