C172SP GROUND PROCEDURES			
DISPATCH	Baggage Door CLOSED	RUNUP	
Weather BRIEF W&B CHECK Perf. Reqs. CHECK NOTAMS CHECK IMSAFE CHECK Charts PACK Squawks CHECK	Ties/Chocks REMOVED Walk Around  START  Passengers	Brakes SET Fuel BOTH Controls FREE & CORR Annunciators CHECK Instruments CHECK Mixture BEST POWER Throttle 1,800 RPM Mags <150↓ <50△	
INTERIOR  Pitot Cover REMOVE Papers AROW Fuel Selector BOTH Fuel Shutoff IN Trim TAKEOFF Master ON	Seatbelts CHECK Circuit Breakers IN Avionics OFF Throttle 1/4" Mixture LEAN Prop CLEAR Master ON Beacon ON	Vacuum Sys GREEN Electric. Sys CHECK Oil Pressure GREEN Oil Temperature GREEN Throttle1,000 RPM MixtureLEAN Throttle Friction SET RadiosSET	
Flaps	Aux Fuel Pump ON Mixture RICH Fuel Flow 3-5 GPH Mixture IDLE C/O Aux Fuel Pump OFF  Mags START Mixture RICH Oil Pressure GREEN Throttle 1,000 RPM Mixture LEAN	SWITCH TO FLIGHT SHUTDOWN  ELT CHECK 121.5  Avionics OFF Mixture C/O  Mags OFF Master OFF Fuel LEFT Lights OFF  SECURING  Hobbs & Tach RECORD	
Fuel QUANTITY Fuel QUALITY Static Port CLEAR Leading Edges CHECK Stall Indicator CLEAR Fuel Vent CLEAR Ailerons CHECK Flaps CHECK Elevator CHECK Rudder CHECK Trim Tab CHECK Exhaust SECURE Intake CLEAR Prop CHECK Engine COWL,, BELT Oil 6-8 QT. Fuel Caps SECURE Windscreen CLEAN	Seat Belts CHECK Flaps UP Heat/Vent/Defrost CHECK Avionics ON ATIS GET Altimeter SET XPDR ALT. & SQWK ADS-B ON Radio TEST Taxi Lights AS REQ'D Brakes TEST  TAXI  Controls WIND Attitude Indicator . CHECK Turn Coordinator . CHECK Heading Indicator SET	Control Lock SET Tie Downs SECURE Pitot Cover REPLACE Sun Shades REPLACE Doors LOCK Squawks RECORD Flight Plan CLOSE FIRE ON START IF START Throttle 1,800 RPM Run Mixture IDLE C/O IF NO START Crank CONTINUE Throttle FULL Mixture IDLE C/O Fuel Shutoff OUT Master & Mags OFF	

## **C172SP FLIGHT PROCEDURES**

PRE-TAKEOFF	ENGINE FAILURE	ELECTRICAL FIRE
RunwayCHECK	Best Glide68	All Switches OFF
Technique NOTE		Vents/Air CLOSE
Crosswind CHECK	Landing SiteFIND	ExtinguisherUSE
Abort Plan BRIEF	Wind IDENTIFY	Ensure Fire Extinguished
TPA/Departure BRIEF	Fuel CutoffIN	Vents OPEN
——————————————————————————————————————	Fuel Selector BOTH	Breakers CHECK
HI <b>SET &amp; BUG</b>	Aux Fuel Pump ON	Master ON IF CRITICAL
FlapsSET	MixtureRICH	Flight TERMINATE
Trim TAKEOFF	MagsTEST BOTH	
Lights ON	Master <b>ON</b>	IMPORTANT NUM.
XPDR SET	FORCED LANDING	V <sub>X</sub> 74
Mixture BEST POWER	Best Glide68	S <sub>0</sub> 40 V <sub>S1</sub> 48
TimeNOTE	Squawk	V <sub>FE 10</sub> 110 V <sub>FE</sub> 85
CLIMB	Emergency DECLARE	V <sub>NO</sub> 129 V <sub>NE</sub> 163
	MixtureIDLE C/O	V <sub>ROT</sub> 55 V <sub>A2550</sub> 105
Speed <b>70-85</b> Flaps <b>UP</b>	Fuel ShutoffOUT	V <sub>A2200</sub> 98 V <sub>A1900</sub> 90
PowerFULL	MagsOFF	Fuel <b>56</b> Usable <b>53</b>
	Flaps AS REQ'D	Best Glide68
Mixture LEAN >3K Engine Inst CHECK	Master OFF	Max Gross2550
	Seatbelts SECURE	Max Crosswind15
CRUISE	Doors UNLATCH	NORMAL TAKEOFF
Power SET	Landing EXECUTE	Flaps <b>0</b> °
Mixture LEAN >3K		Rotate <b>55</b> Climb <b>74</b>
Instruments CHECK	LOW VOLTAGE	SHORT TAKEOFF
Flaps <b>UP</b> Switches (Pump)	Power>1000 RPM	Flaps <b>10</b> °
	Avionics Master OFF	Use Entire Pavement
DESCENT FuelBOTH	Alt. CBCHECK IN	Brakes APPLY
Power SET	Master Switch CYCLE	Climb56
Mixture ENRICH	"VOLTS" CHECK OFF	Flaps <b>UP &gt;60 KIAS</b>
Instruments CHECK	Avionics Master ON	SOFT TAKEOFF
Lights ON	If "VOLTS" illumniated:	Flaps10°
ATIS GET	Master ALT OFF	Elevator FULL UP
AltimeterSET	Nonessential Equip OFF	Ground Effect
Tower CONTACT	Flight <b>TERMINATE</b>	Climb
PRE-LANDING	OVERVOLTAGE	Flaps UP >60 KIAS
AutopilotOFF		NORMAL LANDING
Seat Belts SECURED	Master ALT. OFF	Downwind85
Fuel BOTH	Nonessential Equip OFF	
Brakes TEST	Flight <b>TERMINATE</b>	Base
Mixture RICH	Beware Compass Deviat'n	Final 60 - 70
Lights ON	ENGINE FIRE	SHORT LANDING
Flaps AS REQ'D	MixtureIDLE C/O	Short Final 61
AFTER LANDING	Fuel ShutoffOUT	Touchdown
Flaps UP	Master OFF	Flaps
Trim TAKEOFF	Heat & AirCLOSE	Breaks HEAVY
Switches OFF	Airspeed100+	YokeBACK
Mixture LEAN	Forced Landing	v1.2
WIIALUIG LEAN	i orded Landing	V1.2