

Skye

A four-band broadcast parametric equaliser with wide, overlapping band ranges, shelving end bands and high-pass and low-pass filters.



Overview

Skye is a four-band fully parametric equaliser in the spirit of the classic broadcast rack EQs. Each band has its own frequency, bandwidth and gain, and the ranges overlap widely, so any band can reach almost anywhere: band 1 covers 20 - 800 Hz, band 2 80 Hz - 3 kHz, band 3 300 Hz - 10 kHz and band 4 1 - 20 kHz. BAND 1 and BAND 4 can also be switched to low and high shelves, and a high-pass and a low-pass filter, each with a choice of three slopes, bracket the four bands.

Bandwidth is set in octaves, from a deep, narrow notch (0.1 octave) to a broad tilt (4 octaves), with up to 16 dB of boost or cut per band. A response window on the left draws each band in its own colour with the total curve over the top.

Behind the EQ sits a model of the unit's op-amp headroom: it is transparent until a very hot signal nears the rail, and then softens it a little. The DRIFT dial lets the supply voltage wander, as on real hardware.

Reach for it for

- Broad tone shaping of vocals, instruments and buses
- Notching out hum and single resonances with a narrow bandwidth
- Gentle mastering curves (wide bandwidths, small gains)
- Telephone and radio-voice effects
- Shaping kick and bass with overlapping low bands

- Clearing rumble and taming hiss with the HPF and LPF

Controls

The header

Preset display	Shows the preset number and name. Click it for the full preset list. While you move a control, it shows that control's name and value for a moment.
< / >	Step to the previous or next preset (wrapping round).
EQ IN	Switches the whole equaliser, filters included, in or out. The output level and the output stage stay in either way.
DRIFT	How much the virtual supply voltage wanders, 0 to 100% (20% by default). See Drift below.
OFF / CLIP / LIMIT	The final stage: nothing, a soft clipper at -0.3 dBFS (no latency), or a lookahead limiter that holds the peaks at -0.3 dBFS (3 ms latency, compensated by REAPER). While the output clips, the CLIP key flashes red.
S / M / L	Panel size: small, medium or large. The panel also scales to fit the plugin window.
?	Opens a pop-up with the design credit, the GFX website address and the address of this manual. Click anywhere to close it.

Response window

Shows the EQ curve from 20 Hz to 20 kHz, plus and minus 18 dB. Each band that is in is drawn faintly in its own colour (brown, blue, green, red), and the HPF and LPF in yellow and grey, with the total curve as the bright line. The window reads EQ OUT and the curve goes flat when EQ IN is off.

FILTERS

A high-pass filter (HPF, yellow cap) before the four bands and a low-pass filter (LPF, black cap) after them. Both are out by default.

HPF	The high-pass corner, 10 Hz - 1 kHz (30 Hz by default).
LPF	The low-pass corner, 1 - 22 kHz (18 kHz by default).
x1 / x2 / x4	The slope of each filter: x1 = 12 dB per octave, x2 = 24 dB per octave, x4 = 48 dB per octave. Each is a clean Butterworth filter with no bump at the corner.
IN	Switches that filter in or out.

BAND 1 to BAND 4

The four bands have the same controls; only the frequency range differs. The bands work in series, band 1 first.

FREQ	The centre of the band. BAND 1: 20 - 800 Hz (100 Hz by default). BAND 2: 80 Hz - 3 kHz (500 Hz). BAND 3: 300 Hz - 10 kHz (2.5 kHz). BAND 4: 1 - 20 kHz (8 kHz).
GAIN (coloured cap)	Boost or cut, -16 to +16 dB; 0 dB by default.
BW	The bandwidth in octaves, 0.1 to 4 (1 by default). Small values make a narrow, deep notch or a sharp peak; large values a broad, gentle tilt.
SHELF	BAND 1 and BAND 4 only. Turns the band into a low shelf (BAND 1) or a high shelf (BAND 4) at FREQ. In SHELF mode BW sets the slope of the shelf: lower values give a steeper shelf with a slight bump, higher values a gentler one. BW 1 gives a classic shelf.
IN	Switches the band in or out.

OUTPUT

LEVEL	Output level after the EQ, -12 to +12 dB.
OUT meter	A 20-segment output level meter.

Drift

DRIFT lets the supply voltage wander slowly and smoothly, as on a real rack unit. As it moves, the band gains ease by up to 2.5% and the band centres by up to 0.6% (at 100%), and the op-amp headroom rises and falls by up to 2.5 dB, so a hot signal softens a little more when the rail sags. At 0% the EQ stays exactly where you set it.

Knobs: drag up or down (Shift for fine moves); double-click or Ctrl-click to reset a knob to its default.

Presets

Presets set the four bands and the output level, switch every band in as a bell, and switch both filters out. EQ IN, DRIFT and the output stage are left as they are.

Flat	All four bands at 0 dB in their default positions, output 0 dB.
Vocal Presence	A little cut at 120 Hz and 350 Hz, +3 dB at 3.2 kHz and +2 dB of air at 10 kHz.
Kick and Bass	+4 dB at 60 Hz, -4 dB at 300 Hz and a broad +3 dB at 2.8 kHz for the click.
Air Lift	A gentle lift at 5 kHz and +4 dB around 14 kHz, both broad.
Telephone	Deep, broad cuts at 200 Hz and 6 kHz with a boost at 1.2 and 2.4 kHz: a narrow phone-line voice.
Hum Notch 50 Hz	Very narrow cuts at 50 Hz (-16 dB) and 100 Hz (-12 dB) to remove mains hum.
Mastering Smile	Broad, small moves: +2 dB at 50 Hz and 12 kHz, a slight dip in the mids.
Broadcast Voice	Low end trimmed at 90 Hz, a touch of warmth at 250 Hz, presence at 2.5 kHz and a little less at 7 kHz.

Tips

- To clean up a vocal, put the HPF in at x2 around 80 - 100 Hz before reaching for any of the bands.

- For hum, use BW 0.1 and sweep FREQ slowly with a big cut until the hum disappears, then back the gain off as far as you can.
- Because the ranges overlap, you can stack two bands on the same area - for example two narrow cuts on neighbouring resonances.
- Use EQ IN to compare: the output level stays in circuit, so set LEVEL to match the loudness before judging.
- Set DRIFT to 0 for a static, repeatable EQ; leave a little in for a less clinical, hardware-like feel.

File: gfx-skye.jsfx