Android Developers

Bluetooth Low Energy

Android 4.3 (API level 18) introduces built-in platform support for Bluetooth Low Energy (BLE) in the *central role* and provides APIs that apps can use to discover devices, query for services, and transmit information.

Common use cases include the following:

- Transferring small amounts of data between nearby devices.
- Interacting with proximity sensors like Google Beacons
 (https://developers.google.com/beacons/) to give users a customized
 experience based on their current location.

In contrast to Classic Bluetooth (https://developer.android.com/guide /topics/connectivity/bluetooth.html), Bluetooth Low Energy (BLE) is designed to provide significantly lower power consumption. This allows Android apps to communicate with BLE devices that have stricter power requirements, such as proximity sensors, heart rate monitors, and fitness devices.

Key Terms and Concepts

Here is a summary of key BLE terms and concepts:

- Generic Attribute Profile (GATT)—The GATT profile is a
 general specification for sending and receiving short pieces
 of data known as "attributes" over a BLE link. All current Low
 Energy application profiles are based on GATT.
 - The Bluetooth SIG defines many profiles
 (https://www.bluetooth.org/en-us/specification/adopted-specifications) for
 Low Energy devices. A profile is a specification for how a device works in a particular application. Note that a

In this document

Key Terms and Concepts
Roles and Responsibilities

BLE Permissions

Requesting User Permissions

Setting Up BLE

Finding BLE Devices

Connecting to a GATT Server

Reading BLE Attributes

Receiving GATT Notifications

Closing the Client App

Key classes

BluetoothGatt

BluetoothGattCallback

BluetoothGattCharacteris tic

BluetoothGattService

Related samples

Android BluetoothLeGatt Sample

Android

BluetoothAdvertisements Sample

See Also

This site uses cookies to store your preferences for site-specific language and display options.

 example, a device could contain a heart rate monitor and a battery level detector.

Best Practices for Bluetooth Development (video)

• Attribute Protocol (ATT)—GATT is built on top of the Attribute Protocol (ATT). This is also referred to as GATT/ATT. ATT is optimized to run on BLE devices. To this end, it uses as few bytes as possible. Each attribute is uniquely identified by a Universally Unique Identifier (UUID), which is a standardized 128-bit format for a string ID used to uniquely identify information. The attributes transported by ATT are formatted as characteristics and services.

VIDEO

DevBytes: Bluetooth Low Energy API

(http://www.voutube.com

/watch?v=vUbFB1Qvpq8)

- Characteristic A characteristic contains a single value and 0-n descriptors that describe the characteristic's value. A characteristic can be thought of as a type, analogous to a class.
- Descriptor—Descriptors are defined attributes that describe a characteristic value. For example, a descriptor might specify a human-readable description, an acceptable range for a characteristic's value, or a unit of measure that is specific to a characteristic's value.
- Service—A service is a collection of characteristics. For example, you could have a service called "Heart Rate Monitor" that includes characteristics such as "heart rate measurement." You can find a list of existing GATT-based profiles and services on bluetooth.org (https://www.bluetooth.org/enus/specification/adopted-specifications).

Roles and Responsibilities

Here are the roles and responsibilities that apply when an Android device interacts with a BLE device:

- Central vs. peripheral. This applies to the BLE connection itself. The device in the central role scans, looking for advertisement, and the device in the peripheral role makes the advertisement.
- GATT server vs. GATT client. This determines how two devices talk to each other once they've established the connection.

To understand the distinction, imagine that you have an Android phone and an activity tracker that is a BLE device. The phone supports the central role; the activity tracker supports the peripheral role (to establish a BLE connection you need one of each-two things that only support peripheral couldn't talk to each other, nor could two things that only support central).

Once the phone and the activity tracker have established a connection, they start transferring GATT metadata to one another. Depending on the kind of data they transfer, one or the other might act as

This site uses cookies to store your preferences for site-specific language and display options.

make sense for the activity tracker to act as the server. If the activity tracker wants to receive updates from the phone, then it might make sense for the phone to act as the server.

In the example used in this document, the Android app (running on an Android device) is the GATT client. The app gets data from the GATT server, which is a BLE heart rate monitor that supports the Heart Rate Profile (http://developer.bluetooth.org/TechnologyOverview/Pages/HRP.aspx). But you could alternatively design your Android app to play the GATT server role. See BluetoothGattServer (https://developer.android.com/reference/android/bluetooth/BluetoothGattServer.html) for more information.

BLE Permissions

In order to use Bluetooth features in your application, you must declare the Bluetooth permission BLUETOOTH (https://developer.android.com/reference/android/Manifest.permission.html#BLUETOOTH). You need this permission to perform any Bluetooth communication, such as requesting a connection, accepting a connection, and transferring data.

If you want your app to initiate device discovery or manipulate Bluetooth settings, you must also declare the BLUETOOTH_ADMIN (https://developer.android.com/reference/android
/Manifest.permission.html#BLUETOOTH_ADMIN) permission. Note: If you use the BLUETOOTH_ADMIN
(https://developer.android.com/reference/android/Manifest.permission.html#BLUETOOTH_ADMIN)
permission, then you must also have the BLUETOOTH (https://developer.android.com/reference/android
/Manifest.permission.html#BLUETOOTH) permission.

Declare the Bluetooth permission(s) in your application manifest file. For example:

```
<uses-permission android:name="android.permission.BLUET00TH"/>
<uses-permission android:name="android.permission.BLUET00TH_ADMIN"/>
```

If you want to declare that your app is available to BLE-capable devices only, include the following in your app's manifest:

```
<uses-feature android:name="android.hardware.bluetooth_le" android:required="tru</pre>
```

However, if you want to make your app available to devices that don't support BLE, you should still include this element in your app's manifest, but set required="false". Then at run-time you can determine BLE availability by using PackageManager.hasSystemFeature()

(https://developer.android.com/reference/android/content

This site uses cookies to store your preferences for site-specific language and display options.

Note: LE Beacons are often associated with location. In order to use BluetoothLeScanner (https://developer.android.com/reference/android/bluetooth/le/BluetoothLeScanner.html) Without a filter, you must request the user's permission by declaring either the ACCESS_COARSE_LOCATION (https://developer.android.com/reference/android/Manifest.permission.html#ACCESS_COARSE_LOCATION) or ACCESS_FINE_LOCATION (https://developer.android.com/reference/android /Manifest.permission.html#ACCESS_FINE_LOCATION) permission in your app's manifest file. Without these permissions, scans won't return any results.

Setting Up BLE

Before your application can communicate over BLE, you need to verify that BLE is supported on the device, and if so, ensure that it is enabled. Note that this check is only necessary if <uses-feature.../> is set to false.

If BLE is not supported, then you should gracefully disable any BLE features. If BLE is supported, but disabled, then you can request that the user enable Bluetooth without leaving your application. This setup is accomplished in two steps, using the BluetoothAdapter (https://developer.android.com/reference/android/bluetooth/BluetoothAdapter.html).

1. Get the BluetoothAdapter (https://developer.android.com/reference/android/bluetooth/BluetoothAdapter.html)

The BluetoothAdapter (https://developer.android.com/reference/android/bluetooth/bluetooth/bluetoothAdapter.html) is required for any and all Bluetooth activity. The BluetoothAdapter (https://developer.android.com/reference/android/bluetooth/BluetoothAdapter.html) represents the device's own Bluetooth adapter (the Bluetooth radio). There's one Bluetooth adapter for the entire system, and your application can interact with it using this object. The snippet below shows how to get the adapter. Note that this approach uses getSystemService()

(https://developer.android.com/reference/android/content

/context.html#getSystemService(java.lang.class<T>)) to return an instance of BluetoothManager (https://developer.android.com/reference/android/bluetooth/BluetoothManager.html), which is then used to get the adapter. Android 4.3 (API Level 18) introduces BluetoothManager

This site uses cookies to store your preferences for site-specific language and display options.

2. Enable Bluetooth

Next, you need to ensure that Bluetooth is enabled. Call isEnabled()
(https://developer.android.com/reference/android/bluetooth/BluetoothAdapter.html#isEnabled()) to check whether Bluetooth is currently enabled. If this method returns false, then Bluetooth is disabled. The following snippet checks whether Bluetooth is enabled. If it isn't, the snippet displays an error prompting the user to go to Settings to enable Bluetooth:

```
// Ensures Bluetooth is available on the device and it is enabled. If not,
// displays a dialog requesting user permission to enable Bluetooth.
if (mBluetoothAdapter == null || !mBluetoothAdapter.isEnabled()) {
    Intent enableBtIntent = new Intent(BluetoothAdapter.ACTION_REQUEST_ENABLE
    startActivityForResult(enableBtIntent, REQUEST_ENABLE_BT);
}
```

```
Note: The REQUEST_ENABLE_BT constant passed to startActivityForResult(android.content.Intent, int) (https://developer.android.com/reference/android/app/Activity.html#startActivityForResult(android.content.Intent, int)) is a locally-defined integer (which must be greater than 0) that the system passes back to you in your onActivityResult(int, int, android.content.Intent) (https://developer.android.com/reference/android/app/Activity.html#onActivityResult(int, int, android.content.Intent)) implementation as the requestCode parameter.
```

Finding BLE Devices

To find BLE devices, you use the startLeScan() (https://developer.android.com/reference/android /bluetooth/BluetoothAdapter.html#startLeScan(android.bluetooth.BluetoothAdapter.LeScanCallback)) method. This method takes a BluetoothAdapter.LeScanCallback (https://developer.android.com/reference/android/bluetooth/BluetoothAdapter.LeScanCallback.html) as a parameter. You must implement this callback, because that is how scan results are returned. Because scanning is battery-intensive, you should observe the following guidelines:

As soon as you find the desired device, stop scanning.

This site uses cookies to store your preferences for site-specific language and display options.

may have moved out of range, and continuing to scan drains the battery.

The following snippet shows how to start and stop a scan:

```
/**
 * Activity for scanning and displaying available BLE devices.
public class DeviceScanActivity extends ListActivity {
    private BluetoothAdapter mBluetoothAdapter;
    private boolean mScanning;
    private Handler mHandler;
    // Stops scanning after 10 seconds.
    private static final long SCAN_PERIOD = 10000;
    private void scanLeDevice(final boolean enable) {
        if (enable) {
            // Stops scanning after a pre-defined scan period.
            mHandler.postDelayed(new Runnable() {
                @Override
                public void run() {
                    mScanning = false;
                    mBluetoothAdapter.stopLeScan(mLeScanCallback);
                }
            }, SCAN_PERIOD);
            mScanning = true;
            mBluetoothAdapter.startLeScan(mLeScanCallback);
        } else {
            mScanning = false;
            mBluetoothAdapter.stopLeScan(mLeScanCallback);
        }
        . . .
    }
. . .
}
```

If you want to scan for only specific types of peripherals, you can instead call startLeScan(UUID[], BluetoothAdapter.LeScanCallback) (https://developer.android.com/reference/android/bluetooth

/BluetoothAdapter.html#startLeScan(android.bluetooth.BluetoothAdapter.LeScanCallback)), providing an array of UUID (https://developer.android.com/reference/java/util/UUID.html) objects that specify the GATT services your app supports.

Here is an implementation of the BluetoothAdapter. LeScanCallback $\begin{tabular}{ll} \textbf{(https://developer.android.com/reference/android/bluetooth/BluetoothAdapter.LeScanCallback.html),} \end{tabular}$

This site uses cookies to store your preferences for site-specific language and display options.

```
private LeDeviceListAdapter mLeDeviceListAdapter;
// Device scan callback.
private BluetoothAdapter.LeScanCallback mLeScanCallback =
        new BluetoothAdapter.LeScanCallback() {
    @Override
    public void onLeScan(final BluetoothDevice device, int rssi,
            byte[] scanRecord) {
        runOnUiThread(new Runnable() {
           @Override
           public void run() {
               mLeDeviceListAdapter.addDevice(device);
               mLeDeviceListAdapter.notifyDataSetChanged();
           }
       });
   }
};
```

Note: You can only scan for Bluetooth LE devices *or* scan for Classic Bluetooth devices, as described in Bluetooth (https://developer.android.com/guide/topics/connectivity/bluetooth.html). You cannot scan for both Bluetooth LE and classic devices at the same time.

Connecting to a GATT Server

The first step in interacting with a BLE device is connecting to it— more specifically, connecting to the GATT server on the device. To connect to a GATT server on a BLE device, you use the connectGatt() (https://developer.android.com/reference/android/bluetooth/BluetoothDevice.html#connectGatt(android.content.Context, boolean, android.bluetooth.BluetoothGattcallback)) method. This method takes three parameters: a Context (https://developer.android.com/reference/android/content/Context.html) object, autoConnect (boolean indicating whether to automatically connect to the BLE device as soon as it becomes available), and a reference to a BluetoothGattCallback (https://developer.android.com/reference/android/bluetooth/BluetoothGattCallback.html):

```
mBluetoothGatt = device.connectGatt(this, false, mGattCallback);
```

This connects to the GATT server hosted by the BLE device, and returns a BluetoothGatt (https://developer.android.com/reference/android/bluetooth/BluetoothGatt.html) instance, which you can then use to conduct GATT client operations. The caller (the Android app) is the GATT client. The BluetoothGattCallback (https://developer.android.com/reference/android/bluetooth

This site uses cookies to store your preferences for site-specific language and display options.

as any further GATT client operations.

In this example, the BLE app provides an activity (DeviceControlActivity) to connect, display data, and display GATT services and characteristics supported by the device. Based on user input, this activity communicates with a Service (https://developer.android.com/reference/android /app/Service.html) called BluetoothLeService, which interacts with the BLE device via the Android BLE API:

```
// A service that interacts with the BLE device via the Android BLE API.
public class BluetoothLeService extends Service {
    private final static String TAG = BluetoothLeService.class.getSimpleName();
    private BluetoothManager mBluetoothManager;
    private BluetoothAdapter mBluetoothAdapter;
    private String mBluetoothDeviceAddress;
    private BluetoothGatt mBluetoothGatt;
    private int mConnectionState = STATE_DISCONNECTED;
    private static final int STATE DISCONNECTED = 0;
    private static final int STATE_CONNECTING = 1;
    private static final int STATE_CONNECTED = 2;
    public final static String ACTION_GATT_CONNECTED =
            "com.example.bluetooth.le.ACTION_GATT_CONNECTED";
    public final static String ACTION_GATT_DISCONNECTED =
            "com.example.bluetooth.le.ACTION_GATT_DISCONNECTED";
    public final static String ACTION GATT SERVICES DISCOVERED =
            "com.example.bluetooth.le.ACTION GATT SERVICES DISCOVERED";
    public final static String ACTION_DATA_AVAILABLE =
            "com.example.bluetooth.le.ACTION_DATA_AVAILABLE";
    public final static String EXTRA_DATA =
            "com.example.bluetooth.le.EXTRA_DATA";
    public final static UUID UUID_HEART_RATE_MEASUREMENT =
            UUID.fromString(SampleGattAttributes.HEART_RATE_MEASUREMENT);
    // Various callback methods defined by the BLE API.
    private final BluetoothGattCallback mGattCallback =
            new BluetoothGattCallback() {
        @Override
        public void onConnectionStateChange(BluetoothGatt gatt, int status,
                int newState) {
            String intentAction;
            if (newState == BluetoothProfile.STATE_CONNECTED) {
                intentAction = ACTION_GATT_CONNECTED;
                mConnectionState = STATE_CONNECTED;
                broadcastUpdate(intentAction);
                Log.i(TAG, "Connected to GATT server.");
                Lon i/TAG "Attempting to start service discovery." +
```

This site uses cookies to store your preferences for site-specific language and display options.

```
mBluetoothGatt.discoverServices());
            } else if (newState == BluetoothProfile.STATE DISCONNECTED) {
                intentAction = ACTION_GATT_DISCONNECTED;
                mConnectionState = STATE_DISCONNECTED;
                Log.i(TAG, "Disconnected from GATT server.");
                broadcastUpdate(intentAction);
            }
        }
        @Override
        // New services discovered
        public void onServicesDiscovered(BluetoothGatt gatt, int status) {
            if (status == BluetoothGatt.GATT_SUCCESS) {
                broadcastUpdate(ACTION_GATT_SERVICES_DISCOVERED);
            } else {
                Log.w(TAG, "onServicesDiscovered received: " + status);
            }
        }
        @Override
        // Result of a characteristic read operation
        public void onCharacteristicRead(BluetoothGatt gatt,
                BluetoothGattCharacteristic characteristic,
                int status) {
            if (status == BluetoothGatt.GATT_SUCCESS) {
                broadcastUpdate(ACTION_DATA_AVAILABLE, characteristic);
            }
        }
     . . .
    };
}
```

When a particular callback is triggered, it calls the appropriate broadcastUpdate() helper method and passes it an action. Note that the data parsing in this section is performed in accordance with the Bluetooth Heart Rate Measurement profile specifications (http://developer.bluetooth.org/gatt/characteristics/Pages/CharacteristicViewer.aspx?u=org.bluetooth.characteristic.heart_rate_measurement.xml):

This site uses cookies to store your preferences for site-specific language and display options.

```
// parsing is carried out as per profile specifications.
    if (UUID_HEART_RATE_MEASUREMENT.equals(characteristic.getUuid())) {
        int flag = characteristic.getProperties();
        int format = -1;
        if ((flag & 0x01) != 0) {
            format = BluetoothGattCharacteristic.FORMAT_UINT16;
            Log.d(TAG, "Heart rate format UINT16.");
        } else {
            format = BluetoothGattCharacteristic.FORMAT_UINT8;
            Log.d(TAG, "Heart rate format UINT8.");
        final int heartRate = characteristic.getIntValue(format, 1);
        Log.d(TAG, String.format("Received heart rate: %d", heartRate));
        intent.putExtra(EXTRA_DATA, String.valueOf(heartRate));
    } else {
        // For all other profiles, writes the data formatted in HEX.
        final byte[] data = characteristic.getValue();
        if (data != null && data.length > 0) {
            final StringBuilder stringBuilder = new StringBuilder(data.length);
            for(byte byteChar : data)
                stringBuilder.append(String.format("%02X ", byteChar));
            intent.putExtra(EXTRA_DATA, new String(data) + "\n" +
                    stringBuilder.toString());
        }
    }
    sendBroadcast(intent);
}
```

Back in DeviceControlActivity, these events are handled by a BroadcastReceiver (https://developer.android.com/reference/android/content/BroadcastReceiver.html):

```
// Handles various events fired by the Service.
// ACTION_GATT_CONNECTED: connected to a GATT server.
// ACTION_GATT_DISCONNECTED: disconnected from a GATT server.
// ACTION_GATT_SERVICES_DISCOVERED: discovered GATT services.
// ACTION DATA AVAILABLE: received data from the device. This can be a
// result of read or notification operations.
private final BroadcastReceiver mGattUpdateReceiver = new BroadcastReceiver() {
    @Override
    public void onReceive(Context context, Intent intent) {
        final String action = intent.getAction();
        if (BluetoothLeService.ACTION_GATT_CONNECTED.equals(action)) {
            mConnected = true;
            updateConnectionState(R.string.connected);
            invalidateOptionsMenu();
        } else if (BluetoothLeService.ACTION GATT DISCONNECTED.equals(action)) {
            mConnected = false;
            updateConnectionState(R.string.disconnected);
            invalidateOptionsMenu();
```

This site uses cookies to store your preferences for site-specific language and display options.

Reading BLE Attributes

Once your Android app has connected to a GATT server and discovered services, it can read and write attributes, where supported. For example, this snippet iterates through the server's services and characteristics and displays them in the UI:

```
public class DeviceControlActivity extends Activity {
   // Demonstrates how to iterate through the supported GATT
   // Services/Characteristics.
   // In this sample, we populate the data structure that is bound to the
   // ExpandableListView on the UI.
    private void displayGattServices(List<BluetoothGattService> gattServices) {
        if (gattServices == null) return;
        String uuid = null;
        String unknownServiceString = getResources().
                getString(R.string.unknown_service);
        String unknownCharaString = getResources().
                getString(R.string.unknown_characteristic);
        ArrayList<HashMap<String, String>> gattServiceData =
                new ArrayList<HashMap<String, String>>();
        ArrayList<ArrayList<HashMap<String, String>>> gattCharacteristicData
                = new ArrayList<ArrayList<HashMap<String, String>>>();
        mGattCharacteristics =
                new ArrayList<ArrayList<BluetoothGattCharacteristic>>();
        // Loops through available GATT Services.
        for (BluetoothGattService gattService : gattServices) {
           HashMap<String, String> currentServiceData =
                    new HashMap<String, String>();
            uuid = gattService.getUuid().toString();
            currentServiceData.put(
                    LIST_NAME, SampleGattAttributes.
                            lookup(uuid, unknownServiceString));
           currentServiceData nut(LIST HHID unid).
```

This site uses cookies to store your preferences for site-specific language and display options.

```
ArrayList<HashMap<String, String>> gattCharacteristicGroupData =
                    new ArrayList<HashMap<String, String>>();
            List<BluetoothGattCharacteristic> gattCharacteristics =
                    gattService.getCharacteristics();
            ArrayList<BluetoothGattCharacteristic> charas =
                    new ArrayList<BluetoothGattCharacteristic>();
           // Loops through available Characteristics.
            for (BluetoothGattCharacteristic gattCharacteristic :
                    gattCharacteristics) {
                charas.add(gattCharacteristic);
                HashMap<String, String> currentCharaData =
                        new HashMap<String, String>();
                uuid = gattCharacteristic.getUuid().toString();
                currentCharaData.put(
                        LIST_NAME, SampleGattAttributes.lookup(uuid,
                                unknownCharaString));
                currentCharaData.put(LIST UUID, uuid);
                gattCharacteristicGroupData.add(currentCharaData);
            mGattCharacteristics.add(charas);
            gattCharacteristicData.add(gattCharacteristicGroupData);
         }
   }
}
```

Receiving GATT Notifications

It's common for BLE apps to ask to be notified when a particular characteristic changes on the device. This snippet shows how to set a notification for a characteristic, using the setCharacteristicNotification() (https://developer.android.com/reference/android/bluetooth/BluetoothGatt.html#setCharacteristicNotification(android.bluetooth.BluetoothGattCharacteristic, boolean)) method:

This site uses cookies to store your preferences for site-specific language and display options.

the remote device:

Once notifications are enabled for a characteristic, an onCharacteristicChanged()

(https://developer.android.com/reference/android/bluetooth

/BluetoothGattCallback.html#onCharacteristicChanged(android.bluetooth.BluetoothGatt,

android.bluetooth.BluetoothGattCharacteristic)) callback is triggered if the characteristic changes on

Closing the Client App

Once your app has finished using a BLE device, it should call close() (https://developer.android.com/reference/android/bluetooth/BluetoothGatt.html#close()) so the system can release resources appropriately:

```
public void close() {
   if (mBluetoothGatt == null) {
      return;
   }
   mBluetoothGatt.close();
   mBluetoothGatt = null;
}
```



Follow @AndroidDev on Twitter



Follow Android Developers on Google+

This site uses cookies to store your preferences for site-specific language and display options.



Check out Android Developers on YouTube

This site uses cookies to store your preferences for site-specific language and display options.