User manual - Ultrasonic sensor

Technical characteristics:

Measuring range: 0-5 Meter

Blind in the area closest to the sensor: approx. 0.5 meter

Unpredictability: 0.3% (default)
Pressure: Atmospheric Pressure
Analogue output: 4-20MA
Power supply: 16 - 24V DC

• Ambient temperature: -20°C ~ 65°C

Protection class: IP65
Response time: 1.5S
Spread angle:> = 6 degrees

INSTALLATION:






Figure 1: Installation.

SETTINGS:


1. Connect the solar panel with the sensor power connector.



2. Turn on the sensor with the switch and press the setting button at the same time.



3. On a PC or cell phone search for the wifi signal "US-sensor" and connect, the password is 12345678.



- 4. In a web browser, enter the ip: 192.168.4.1.
- 5. Enter the ssid and password of the wifi signal that the sensor will connect to, press the save button.





- 6. When you finish, press save and exit.
- 7. Enter the web panel and add a new device, enter the mac address from step 5 so that the system accepts this device.