Installing ESP8266 Board in Arduino IDE (Windows, Mac OS X, Linux)

The ESP8266 community created an add-on for the Arduino IDE that allows you to program the ESP8266 using the Arduino IDE and its programming language.

This tutorial shows how to install the ESP8266 board in Arduino IDE whether you're using Windows, Mac OS X or Linux.

Watch the Video Tutorial

This tutorial is available in video format (watch below) and in written format (continue reading this page).

https://youtu.be/OC9wYhv6juM

If you like the ESP8266 and want to build more projects, you can get my eBook: Home Automation using ESP8266.

Prerequisites: Arduino IDE Installed

Before starting this installation procedure, make sure you have the latest version of the Arduino IDE installed in your computer. If you don't, uninstall it and install it again. Otherwise, it may not work.


Having the latest Arduino IDE software installed from arduino.cc/en/Main/Software, continue with this tutorial.

Do you need an ESP8266 board? You can buy it here.

Install ESP8266 Add-on in Arduino IDE

To install the ESP8266 board in your Arduino IDE, follow these next instructions:

1. In your Arduino IDE, go to File> Preferences



3. Enter


http://arduino.esp8266.com/stable/package_esp8266com_ind ex.json into the "Additional Boards Manager URLs" field as shown in the figure below. Then, click the "OK" button:

Settings Network				
Sketchbook location:				
C:\Users\rui_s\Documents\Ar	duino			Browse
Editor language:	System Default	~	(requires restart of Arduino)	
Editor font size:	22			
Interface scale:	✓ Automatic 100 🕏 % (requires restart of Ardu	uino)		
Theme:	Default theme V (requires restart of Arduino)			
Show verbose output during:	compilation upload			
Compiler warnings:	None 🗸			
Display line numbers				
Enable Code Folding				
✓ Verify code after upload				
Use external editor				
Aggressively cache compi	led core			
Check for updates on sta	tup			
Update sketch files to nev	v extension on save (.pde -> .ino)			
Save when verifying or up	ploading			
Additional Boards Manager UR	Ls: 1/dl/package_esp32_index.json <mark>, http://arduino.es</mark>	sp82	266.com/stable/package_esp8266com_inde	x.json
More preferences can be edite	ed directly in the file			
C:\Users\rui_s\AppData\Local				
(edit only when Arduino is not	running)			


5. **Note:** if you already have the ESP32 boards URL, you can separate the URLs with a comma as follows:

```
https://dl.espressif.com/dl/package_esp32_index.j
son,
http://arduino.esp8266.com/stable/package_esp8266
com index.json
```


6. Open the Boards Manager. Go to **Tools** > **Board** > **Boards Manager...**



8. Search for **ESP8266** and press install button for the "**ESP8266 by ESP8266 Community**":



10. That's it. It should be installed after a few seconds.



Report this ad

M° MEDIAVINE

Testing the Installation

To test the ESP8266 add-on installation, let's see if we can blink an LED with the ESP8266 using the Arduino programming language.

Parts Required

Report this ad

M° MEDIAVINE

Here's the hardware that you need to complete this project:

- ESP8266 read Best ESP8266 Wi-Fi Development Boards
- LED
- 330 Ohm resistor

- Breadboard
- Jumper wires


If you're using an ESP8266-01, you also need an FTDI programmer to upload code.

You can use the preceding links or go directly to MakerAdvisor.com/tools to find all the parts for your projects at the best price!

Uploading the Sketch

Uploading the Sketch to the ESP-12E


If you're using an ESP-12E NodeMCU Kit, uploading the sketch is very simple, since it has built-in programmer. Plug your board to your computer. Make sure you have the right board selected:



Report this ad

M°MEDIAVINE

You also need to select the Port:



Then, copy the code provided:

```
/******
Rui Santos
  Complete project details at https://randomnerdtutorials.com
*******/
```

```
int pin = 2;

void setup() {
    // initialize GPIO 2 as an output.
    pinMode(pin, OUTPUT);
}

// the loop function runs over and over again forever
void loop() {
    digitalWrite(pin, HIGH); // turn the LED on (HIGH is the voltage level)
    delay(1000); // wait for a second
    digitalWrite(pin, LOW); // turn the LED off by making the voltage LOW
    delay(1000); // wait for a second
}
```

Report this ad

MEDIAVINE


View raw code

Click the "Upload" button in the Arduino IDE and wait a few seconds until you see the message "Done uploading." in the bottom left corner.

```
ESP8266_Blinking_an_LED | Arduino 1.8.5
                                                                                  X
File Edit Sketch Tools Help
 ESP8266_Blinking_an_LED
/******
 Rui Santos
 Complete project details at http://randomnerdtutorials.com
*******
int pin = 2;
void setup() {
  // initialize GPIO 2 as an output.
 pinMode (pin, OUTPUT);
// the loop function runs over and over again forever
void loop() {
 digitalWrite(pin, HIGH); // turn the LED on (HIGH is the voltage level)
 delay(1000);
                       // wait for a second
Done uploading.
```

Uploading the Sketch to the ESP-01

Uploading code to the ESP-01 requires establishing a serial communication between your ESP8266 and a FTDI Programmer as shown in the schematic diagram below.



The following table shows the connections you need to make between the ESP8266 and the FTDI programmer.

ESP8266	FTDI programmer
RX	TX
TX	RX
CH_PD	3.3V
GPIO 0	GND
VCC	3.3V
GND	GND


If you have a brand new FTDI Programmer and you need to install your FTDI drivers on Windows PC, visit this website for the official drivers: http://www.ftdichip.com/Drivers/VCP.htm.

Then, you just need to connect the FTDI programmer to your computer, and upload the sketch to your ESP8266 board. You should see the "Done Uploading" message after a few seconds.

Schematic


If you're using an ESP8266-12E

Connect an LED to your ESP8266, as shown in the following schematic diagram. The LED should be connected to GPIO 2 (D4).



If you're using an ESP8266-01

If you're using the ESP8266-01 assemble the following circuit.



fritzing

If everything went well, your LED should be blinking every 1 second.

Troubleshooting

If you try to upload a new sketch to your ESP8266 and you get this error message "esptool.FatalError: Failed to connect to ESP8266: Timed out waiting for packet header". It means that your ESP8266 is not in flashing/uploading mode.

```
esptool.FatalError: Failed to connect to ESP8266: Timed out waiting for packet header esptool.FatalError: Failed to connect to ESP8266: Timed out waiting for packet header esptool.FatalError: Failed to connect to ESP8266: Timed out waiting for packet header
```

Having the right board name and COM port selected, follow these steps:

- Hold-down the "BOOT/FLASH" button in your ESP8266 development board
- Press the "Upload" button in the Arduino IDE to upload your sketch:



- When you see the "Connecting...." message in your Arduino
 IDE, release the finger from the "BOOT/FLASH" button
- After that, you should see the "Done uploading" message

Your ESP8266 should have the new sketch running. Press the "ENABLE/RESET" button to restart the ESP8266 and run the new uploaded sketch.

Wrapping Up

This is a quick guide that illustrates how to prepare your Arduino IDE for the ESP8266 on a Windows PC, Mac OS X, or Linux computer.

Next, you might want to read: Getting started with ESP8266.

That's it, you're ready to start building your own IoT projects with the ESP8266!

- Home Automation Using ESP8266
- ESP8266 Web Server Step-by-step
- ESP8266 Wi-Fi Button DIY Amazon Dash Button Clone
- ESP8266 Daily Task Publish Temperature Readings to ThingSpeak
- ESP8266 Weather Forecaster
- Nextion Display with ESP8266 Touchscreen User Interface for Node-RED
- More ESP8266 projects...