


Drawing:		Description:	
N°	Rev: 00.0724	ELECTRICAL SYSTEM	

CAP 03

#	DRAWING	DESCRIPTION	PAG.
1	03.001	BATTERIES AND ISOLATOR SWITCH	3.03
2	03.002	FUSE BOX	3.06
3	03.003	ELECTRICAL LAYOUT - ENGINE	3.08
4	03.004	ELECTRICAL LAYOUT - CHASSIS	3.10
5	03.005	CONTROL UNITS	3.12
6	03.006	JOYSTICK, LEVERS AND SWITCHES	3.14
7	03.007	PEDAL ACELERATOR	3.16
8	03.008	LIFT CONTROL	3.18
9	03.009	BOOM MOUNTED WORKING LIGHTS	3.21
10	03.010	FLASHING BEACON	3.23
11	03.011	ELECTRICAL SPREADER	3.25

(this page intentionally left blank)

Drawing:		Description:		
N°	03.001	Rev:	00.0724	
CAB CARRIER AND WHEELS				




Drawing:		Description:		
N°	03.001	Rev:	00.0724	
		CAB CARRIER AND WHEELS		

Pos.	Part-No.	Designation	Quantity	replaced by	Remarks
1	03.01.934999987	battery 12v 150ah	2		
2	03.01.546939857	cable electric battery link	1		
3	03.01.546839859	cable electric starter cable	1		
4	03.01.546939858	cable electric batt +ve to isolator	1		
5	03.01.546939898	cable electric isolator/fuse box	1		
6	03.01.934969998	main switch	1		
7	03.01.984969383	hexagon head screw ISO 4017M6x16-8.8-A2C	2		
8	03.01.944949996	hexagon nut ISO 4032DIN 934-M6-8A2C	2		
9	03.01.974999981	washer ISO 7093B6,4-ST-A2C	2		
10	03.01.546967683	retainer plate battery	1		
11	03.01.984989965	bolt hook battery	4		
12	03.01.944949987	nut	4		
13	03.01.974999992	washer SCH-A8.4x16x1.6-125A2C	4		
14	03.01.096939898	cable assy	1		
15	03.01.984968983	hexagon head screw ISO 4017M10x16-8.8-A2C	1		
16	03.01.974999993	washer DIN 7349DIN 7349-10,5x25x4	1		
17	03.01.546967655	battery holder	2		
18	03.01.984969183	hexagon head screw ISO 4017M8x16-8.8-A2C	4		
19	03.01.974999992	washer ISO 7089A8,4-ST50-A2C	4		

Drawing:		Description:		
N°	03.001	Rev:	00.0724	
		CAB CARRIER AND WHEELS		

Pos.	Part-No.	Designation	Quantity	replaced by	Remarks
20		fuse carrier	1		POS 3
21	03.01.546939897	cable electric starter-earth	1		
22	03.01.944949987	nut ISO 4032934-M8-8A2C	4		
24	03.01.546939076	clip cable double /13-14	2		
25	03.01.934949992	chain	1		
26	03.01.934949984	lock ring	1		
29	03.01.096939055	type fuse-link 125A	1		


Drawing:		Description:		
N°	03.002	Rev:	00.0724	
FUSE BOX				



Drawing:		Description:		
N°	03.002	Rev:	00.0724	
		FUSE BOX		

Pos.	Part-No.	Designation	Quantity	replaced by	Remarks
1	03.01.546939598	Fuse box 1			
2	03.01.546939597	Fuse box 2			
3	03.01.096939067	Relay JD281A 24V 150A			
4	03.01.096739597	FLASHER UNIT			
5	03.01.096739596	relay 10A 24V			
6	03.01.546439064	Fuse 1A			
6	03.01.096739089	Fuse 3A			
6	03.01.096739099	Fuse 5A			
6	03.01.546439061	Fuse 10A			
6	03.01.546439060	Fuse 15A			
6	03.01.546439059	Fuse 20A			
6	03.01.546439058	Fuse 25A			
6	03.01.096739098	Fuse 30A			

Drawing:		Description:		
N°	03.003	Rev:	00.0724	
		ELECTRICAL LAYOUT - ENGINE		



Drawing:		Description:		
N°	03.003	Rev:	00.0724	
		ELECTRICAL LAYOUT - ENGINE		

Pos.	Part-No.	Designation	Quantity	replaced by	Remarks
1	03.01.546839865	harness engine	1		
2	03.01.954999972	clip DIN 3016-1D1-32x25-W1-1	3		
3	03.01.984969174	hexagon head screw ISO 4017M8x25-8.8-A2C	1		
4	03.01.944949987	nut ISO 4032934-M8-8A2C	1		
5	03.01.984968969	hexagon head screw ISO 4017M10x30-8.8-A2C	1		
6	03.01.974999994	washer ISO 7090B10,5x20x2-HV200-A2C	1		
7	03.01.944949992	nut ISO 7040M10-8-A2C	1		
8	03.01.984968979	hexagon head screw ISO 4017M10x20-8.8-A2C	2		
9	03.01.974999994	washer ISO 7090B10,5x20x2-HV200-A2C	2		
10	03.01.546867590	support start relay	1		
11	03.01.096939044	contactor start solenoid	1		
12	03.01.984989532	hexagon head screw ISO 4017M4x12-8.8-A2C	2		
14	03.01.944949987	nut ISO 4032934-M8-8A2C	1		
15	03.01.974999994	washer ISO 7090B10,5x20x2-HV200-A2C	1		
16	03.01.954999972	clip DIN 3016-1D1-32x25-W1-1	1		

Drawing:		Description:		
N°	03.004	Rev:	00.0724	
		ELECTRICAL LAYOUT - CHASSIS		


Hierzu ist keine Graphik hinterlegt !
 Bitte Stückliste unten benutzen !

There is no graphic available !
 Please use BOM below !

Drawing:		Description:		
N°	03.004	Rev:	00.0724	
		ELECTRICAL LAYOUT - CHASSIS		

Pos.	Part-No.	Designation	Quantity	replaced by	Remarks
1	03.01.546939862	Harness chassis	1		
2	03.01.546939863	harness cab-chassis multicore link	1		
3	03.01.546939861	harness cab-boom 12core spreader c	1		
4	03.01.546839871	ZF Transmission Harness	1		
5	03.01.546839863	Engine harness QSM11	1		
6	03.01.546839869	Dana 36000 harness 14.7	1		
6A	03.01.546839870	Dana 36000 harness 15.5 kal	1		
7	03.01.546539863	Engine harness X12 t4f	1		
8	03.01.542639870	Cab CABLE harness 001	1		
9	03.01.542639868	Cab CABLE harness 002	1		




Drawing:		Description:		
N°	03.005	Rev:	01.0526	
CONTROL UNITS				



Drawing:		Description:		
N°	03.005	Rev:	00.0724	
		CONTROL UNITS		

Pos.	Part-No.	Designation	Quantity	replaced by	Remarks
1	03.01.546539895	dana -TCU	1		
2	03.01.546967692	plate trans control box	1		
3	03.01.546964594	protective cover apc 200	1		
4	03.01.984989978	button grip knob	4		
5	03.01.984969389	hexagon head screw ISO 4017M6x10-8.8-A2C	4		
6	03.01.984968979	hexagon head screw ISO 4017M10x20-8.8-A2C	4		
7	03.01.546747697	control iqan-XA2 2020	1		
8	03.01.546747697	control iqan-XA2 2020	2		used from sn 1286002 to ...005
	03.01.546739895	control iqan-XS2 2025	2		used from sn 1286006 to next
9	03.01.944949996	hexagon nut ISO 4032DIN 934-M6-8A2C	2		
10	03.01.984959988	ZS-M6x16-912-8.8-A2C	2		
11	03.01.546747699	controller iqan md4 display	1		
12	03.01.984989989	cutting screw	4		
13	03.01.984989966	bolt	2		
14	03.01.546964593	protective cover	1		
15	03.01.984969379	hexagon head screw ISO 4017M6x20-8.8-A2C	2		


Drawing:		Description:		
N°	03.006	Rev:	01.0526	
JOYSTICK, LEVERS AND SWITCHES				



Drawing:		Description:		
N°	03.006	Rev:	00.0724	
		JOYSTICK, LEVERS AND SWITCHES		

Pos.	Part-No.	Designation	Quantity	replaced by	Remarks
1	03.01.096748898	gearbox lever	1		
2	03.01.096739593	lights lever	1		
3	03.01.546739583	joystick "elobau type 1"	1		
	03.01.546739582	joystick "elobau type 2"	1		
4		brake pedal			
5	03.01.096739583	acelerator pedal	1		
6	03.01.096767391	emergency switch	1		
7	03.01.096767392	wiper switch	2		
8	03.01.096767390	parking brake switch	1		
9	03.01.934949983	Beeper	1		
10	03.01.546739054	switch for cabin displacement	1		
11		switch for armrest	1		
12	03.01.546739055	override boton	1		


Drawing:		Description:		
N°	03.007	Rev:	00.0724	
PEDAL ACELERATOR				



Drawing:		Description:		
N°	03.007	Rev:	00.0724	
		PEDAL ACELERATOR		

Pos.	Part-No.	Designation	Quantity	replaced by	Remarks
1	03.01.096739583	Accelerator Pedal assy 37 degree 2020	1		
2	03.01.096767692	plate accelerator pedal	1		
3	03.01.984989148	hexagon head screw ISO 4017M8x12-8.8-A2C	4		
4	03.01.984929997	countersunk screw ISO 10642M6x16-8.8-A2C	3		
5	03.01.984989986	screw M6x20-A2R	2		

Drawing:		Description:		
N°	03.008	Rev:	00.0724	
LIFT CONTROL				




Drawing:		Description:		
N°	03.008	Rev:	00.0724	
		LIFT CONTROL		

Pos.	Part-No.	Designation	Quantity	replaced by	Remarks
1	03.01.542639195	Potentiometer Pull box boom extension	1		
2	03.01.980290979	cable assy.	1		
3	03.01.542667570	bracket potentiometer	1		
4	03.01.974999992	washer	2		
5	03.01.984968974	SKS-M10x25-933-8.8A2C	2		
6	03.01.974999990	washer DIN 7349DIN 7349-13x30x6-A2C	2		
7	03.01.974999992	washer ISO 7089A8,4-ST50-A2C	4		
8	03.01.984969183	hexagon head screw ISO 4017M8x16-8.8-A2C	4		
9	03.01.984989147	hexagon head screw ISO 4017M8x40-8.8-A2C	1		
10	03.01.944949987	spacer bush	1		
11	03.01.974999976	washer ISO 7093-18-200HV-A2C	1		
12	03.01.984969179	hexagon head screw ISO 4017M8x20-8.8-A2C	1		
13	03.01.542667569	bracket ext pot cable	1		
14	03.01.542639195	potentiometer assy.	1		
15	03.01.546967548	bracket boom angle potentiometer	1		
16	03.01.974999994	washer ISO 7090B10,5x20x2-HV200-A2C	2		
17	03.01.984969174	hexagon head screw ISO 4017M8x25-8.8-A2C	2		
18	03.01.984989906	rod	1		
19	03.01.944949987	nut ISO 4032934-M8-8A2C	1		

Drawing:		Description:		
N°	03.008	Rev:	00.0724	
		LIFT CONTROL		

Pos.	Part-No.	Designation	Quantity	replaced by	Remarks
20	03.01.984969487	hexagon head screw ISO 4017M5x12-8.8-A2C	3		
21	03.01.974999975	washer DIN 7349DIN 7349-5,3-ST-A2A	3		
22	03.01.954999943	clip DIN 3016-1D1-8x12-W1-1	3		
23	03.01.944949175	hexagon nut ISO 4032DIN 934-M8-8A2C LH.	1		
24	03.01.984969174	socket-head screw ISO 4762M6x45-8.8-A2C	1		
25	03.01.546939197	potentiometer boom angle	1		
26	03.01.546967554	joint ball ang. DIN 71802	1		
27	03.01.546967583	ball joint DIN 71802CS13L-Y71802-A2C	1		


Drawing:		Description:		
N°	03.009	Rev:	00.0724	
BOOM MOUNTED WORKING LIGHTS				



Drawing:		Description:		
N°	03.009	Rev:	00.0724	
		BOOM MOUNTED WORKING LIGHTS		

Pos.	Part-No.	Designation	Quantity	replaced by	Remarks
1	03.01.546939894	cable tree	1		
2	03.01.096939790	LED light	4		
6	03.01.954999955	clip pipe DIN 3016-1D1-12X20-W1-1	5		
7	03.01.984989110	stud DIN 939M8X25-939-8.8A2C	5		
8	03.01.974999997	washer ISO 7089A8,4-ST50-A2C	5		
9	03.01.944949987	nut ISO 4032934-M8-8A2C	5		
10	03.01.984989998	hexagon head screw M5x12-St-A3B	14		
11	03.01.954999965	tie cable 6,3x4,8x198-SW	14		
12	03.01.974999992	washer ISO 7089A8,4-ST50-A2C	2		
13	03.01.984969183	hexagon head screw ISO 4017M8x16-8.8-A2C	2		


Drawing:		Description:		
N°	03.010	Rev:	00.0724	
FLASHING BEACON				



Drawing:		Description:		
N°	03.010	Rev:	00.0724	
		FLASHING BEACON		

Pos.	Part-No.	Designation	Quantity	replaced by	Remarks
1	03.01.984968979	hexagon head screw ISO 4017M10x20-8.8-A2C	2		
2	03.01.974999994	washer ISO 7090B10,5x20x2-HV200-A2C	2		
3	03.01.984989998	hexagon head screw M5x12-St-A3B	12		
4	03.01.540446969	tie cable 6,3x4,8x198-SW	12		
5	03.01.096739795	warning flashing light	1		rotating beacon
5A	03.01.096739795T	warning flashing light (without relay)	1		flashing beacon
6	03.01.984999394	hexagon head screw ISO 4017M6x25-8.8-A2C	3		
7	03.01.542639078	bracket BEACON	1		
8	03.01.542639077	bracket BEACON	1		
9	03.01.934999972	rubber steel mounting AM8x15-55	3		
10	03.01.944949992	nut ISO 7040M10-8-A2C	3		
11	03.01.944949998	hexagon nut EN 10511M8-8-A2C	3		
12	03.01.096739084	receptacle faston 0,5-1,5-red	2		
13	03.01.096939083	contact pin	2		
14	03.01.096939892	cable DIN 47732DIN 47732-H05VV-F2x1,0	3		

Drawing:		Description:		
N°	03.011	Rev:	00.0724	
ELECTRICAL SPREADER				



Drawing:		Description:		
N°	03.011	Rev:	00.0724	
		ELECTRICAL SPREADER		

Pos.	Part-No.	Designation	Quantity	replaced by	Remarks
1	03.01.093514779	housing	1		
2	03.01.545386688	bracket housing	2		
3	03.01.093514793	damper	4		
4	03.01.944999198	locknut	8		
5	03.01.974989965	washer	8		
6	03.01.984989350	hexagon head screw ISO 4017M6x40-8.8-A2C	4		
7	03.01.944999984	nut clamp	4		
8	03.01.944949999	nut hexagon ISO 4032DIN 934-M10-8A2C	2		
9	03.01.974999994	washer ISO 7090B10,5x20x2-HV200-A2C	2		
10	03.01.092939795	indicator light red led	1		
10	03.01.092939796	indicator light yellow led	1		
10	03.01.092939797	indicator light green led	1		
10a	03.01.092939786	Yellow signal lamp (without bulb)	1		
10a	03.01.092939785	Green signal lamp (without bulb)	1		
10a	03.01.092939784	Red signal lamp (without bulb)	1		
10a	03.01.092939783	24V * 21W bulb	1		
11	03.01.542667593	bracket ELME LED LIGHTS	1		
12	03.01.934979999	mounting assy.	2		
13	03.01.546939893	harness TRAFFIC LIGHT	1		

Drawing:		Description:		
N°	03.011	Rev:	00.0724	
		ELECTRICAL SPREADER		

Pos.	Part-No.	Designation	Quantity	replaced by	Remarks
14	03.01.984969179	hexagon head screw ISO 4017M8x20-8.8-A2C	a.req.		
15	03.01.974999992	washer ISO 7089A8,4-ST50-A2C	a.req.		
16	03.01.954999955	clip pipe DIN 3016-1D1-12X20-W1-1	a.req.		