

Drawing:		Description:	
N°	Rev: 00.0724	INDICE	

#	DRAWING	DESCRIPTION	PAG.
01	06.001	GEARBOX INSTALATION T4 & Eu5 - part 1 to part 3	6.03
02	06.004	GEARBOX OIL PIPE T4 & Eu5	6.09
03	06.005	ASSY-TRANSMISSION TE30	6.11
04	06.006	GROUP-CONVERTER HOUSING	6.13
05	06.007	GROUP-TRANSMISSION CASE	6.15
06	06.008	GROUP-REAR COVER	6.17
07	06.009	GROUP-TURBINE SHAFT	6.19
08	06.010	PUMP DRIVE	6.21
09	06.011	GROUP-15.7 WHEEL	6.23
10	06.012	GROUP-FLEX PLATE	6.25
11	06.013	GROUP - FORWARD CLUTCH SHAFT	6.27
12	06.014	GROUP - 1ST DRIVE SHAFT	6.29
13	06.015	GROUP-HIGH IDLER	6.31
14	06.016	GROUP-REV/2ND CLUTCH SHAFT	6.33
15	06.017	GROUP-1ST SPEED CLUTCH SHAFT	6.35
16	06.018	GROUP-HI/3RD SPEED CLUTCH SHAFT	6.37
17	06.019	GROUP-OUTPUT SHAFT	6.39
18	06.020	GROUP-OUTPUT FLANGE	6.41
19	06.021	GROUP-REGULATOR VALVE	6.43
20	06.022	ASSY-VALVE REGULATOR	6.45
21	06.023	GROUP-CONTROL VALVE	6.47
22	06.024	ASSY-CONTROL VALVE	6.49
23	06.025	GROUP-BACKING PRESSURE REGULATOR VALVE	6.51
24	06.026	ASSY-BACKING PRESSURE REGULATOR	6.53
25	06.027	SHIPPING COVER GROUP	6.55
26	06.028	ASSEMBLY-OIL FILTER	6.57

(this page intentionally left blank)


Drawing:			Description:
N°	06.001	Rev:	00.0724
			GEARBOX INSTALATION T4 & Eu5 – part 1



Drawing:		Description:		
N°	06.001	Rev:	00.0724	
		GEARBOX INSTALATION T4 & Eu5 – part 1		

Pos.	Part-No.	Designation	Quantity	replaced by	Remarks
1	06.01.546882897	DANA Transmission	1		
2	06.01.984968959	Screw SKS-M10X40-933-8.8A2C	12		
3	06.01.546867549	T4F Transmission Bracket LHS	1		
4	06.01.546867548	T4F Transmission Bracket RHS	1		
5	06.01.984988521	Hexagon Screw ZS-M14X45-912-8.8A2C	4		
6	06.01.974999918	Washer SCH-A15x28x2.5-125A2C	4		
7	06.01.984989904	U.S Screw	8		
8	06.01.974999998	Washer SCH-B21X37X3-125A2C7090	8		
9	06.01.984999905	DIN912 M10*1.25*30Screw	12		


Drawing:			Description:	
N°	06.002	Rev:	00.0724	
			GEARBOX INSTALATION T4 & Eu5 – part 2	



Drawing:		Description:		
N°	06.002	Rev:	00.0724	
		GEARBOX INSTALATION T4 & Eu5 – part 2		

Pos.	Part-No.	Designation	Quantity	replaced by	Remarks
1	06.01.994979872	Union	4		
2	06.01.994969959	Adapter	1		
3	06.01.546839094	Pressure Sensor	1		
4	06.01.546839093	Temperature Sensor	1		
5	06.01.994969960	Adapter	1		

Drawing:			Description:	
N°	06.003	Rev:	00.0724	
			GEARBOX INSTALATION T4 & Eu5 – part 3	



Drawing:		Description:		
N°	06.003	Rev:	00.0724	
		GEARBOX INSTALATION T4 & Eu5 – part 3		

Pos.	Part-No.	Designation	Quantity	replaced by	Remarks
1		Low speed Sensor (see gearbox)	1		
2		Not Used On This Model	1		
3	06.01.546839870	T4F Transmission Harness	1		
4	06.01.954999961	Clamp 10*15	1		

Drawing:			Description:	 Tecport
N°	06.004	Rev:	00.0724	
			GEARBOX OIL PIPE T4 & Eu5	



Drawing:		Description:		
N°	06.004	Rev:	00.0724	
		GEARBOX OIL PIPE T4 & Eu5		

Pos.	Part-No.	Designation	Quantity	replaced by	Remarks
1	06.01.546824280	Hose Assy. (Outlet Oil Hose)	1		
2	06.01.954999942	Clamp	2		
3	06.01.984969179	Screw SKS-M8x20-933-8.8A2C	2		
4	06.01.944949998	Nut SGM-M8-985-8A2C	2		