SCRAM Instructions II

Philipp Koehn

23 February 2018




Reminder



- Fully work through a computer
 - circuit
 - assembly code
- Simple but Complete Random Access Machine (SCRAM)
 - every instruction is 8 bit
 - 4 bit for op-code: 9 different operations (of 16 possible)
 - 4 bit for address: 16 bytes of memory
- Background reading on web page
 - The Random Access Machine
 - The SCRAM

Circuit (At This Point)





Instruction Fetch



- Retrieve instruction from memory
- Increase program counter

 $\texttt{t}_2 \qquad \texttt{IR} \; \leftarrow \; \texttt{MBR}$

Micro Program for STA




• Store value from accumulator

Op Code	Time	Command
\mathbf{q}_3	t_3	$MAR \leftarrow IR(D)$
\mathbf{q}_3	t_4	$ exttt{M} \leftarrow exttt{AC}$


q_3 t_3 : MAR \leftarrow IR(D)














arithmetic logic unit

Arithmetric Logic Unit





• Adds two numbers: S=A+B


• With subtraction flag: S=A-B

• Overflow handling with carry in (CI) and carry out (CO)

• Zero flag: set if result of operation is 0

Accumulator






• Store result of ALU operation in accumulator (AC)

$$AC = AC \pm B$$






- Accumulator feeds back into ALU
- \bullet Operations are AC = AC + B or AC = AC B

ALU in Circuit







add

ADD: Add to Accumulator



• Add value from memory address to accumulator

• Steps

- load value of specified memory address
- use that value as a memory address (second lookup)
- store value from second lookup into accumulator

Micro Program for ADD




• Load indirectly into accumulator

Op Code	Time	Command
${\bf q}_5$	t_3	$\texttt{MAR} \leftarrow \texttt{IR(D)}$
\mathbf{q}_5	t_4	$\mathtt{MBR} \leftarrow \mathtt{M}$
q_5	t_{5}	$AC \leftarrow AC + MBR$


q_5 t_3 : MAR \leftarrow IR(D)












q_5 t_5 : AC \leftarrow AC + MBR







sub

SUB: Subtract from Accumulator



• Subtract from accumulator the value from memory

• Same as ADD, just set subtraction flag of ALU

Micro Program for SUB




• Load indirectly into accumulator

Op Code	Time	Command
\mathbf{q}_{5}	t_3	$MAR \leftarrow IR(D)$
\mathbf{q}_5	t_4	$\mathtt{MBR} \leftarrow \mathtt{M}$
9 5	t_{5}	$AC \leftarrow AC - MBR$















$q_5 \ t_5 \text{:} \quad \textbf{AC} \ \leftarrow \ \textbf{AC} \ + \ \textbf{MBR}$







jmp

Program Counter (PC)



- Position of the next instruction is stored in program counter
- This gets updated during instruction fetch

	Time	Command	
	t_0	$\texttt{MAR} \leftarrow \texttt{PC}$	
	t_1	$\mathtt{MBR} \leftarrow \mathtt{M}$	
	${\sf t}_2$	$\texttt{IR} \; \leftarrow \; \texttt{MBR}$	
\Rightarrow	t_3	$PC \leftarrow PC + 1$	

JMP: Jump



- Assign value to position of the next instruction
- Sequencing of micro program
 - instruction fetch (includes program counter inc)
 - command-specific micro instructions
- No problem that program counter gets modified twice

Micro Program for JMP




• Change program counter to specified address

Op Code	Time	Command
q_7	t_3	$PC \leftarrow IR(D)$

$q_7 t_3$: PC \leftarrow IR(D)








jpz

Zero Flag




- Zero flag
 - set when result of a ALU operation is 0
 - stored in flag



Z Flag in Circuit





Micro Program for JPZ



• Z flag is a condition for executing a micro program (same as JMP)

Zero Op Code Time Command
$$1 \qquad q_7 \qquad t_3 \quad PC \leftarrow IR(D)$$

• If not set, no micro program is executed