6502 Introduction

Philipp Koehn

28 February 2018






some history



• First microprocessor on an integrated circuit: Intel 4004



• 4-bit central processing unit, 12 bit address space (4KB)



• MOS Technology 6502



• Dominant CPU in home computers for a decade

(Atari, Apple II, Nintendo Entertainment System, Commodore PET)



• Atari 2600



• Video game console: Pong, Pac Man, ... connected to TV



• Commodore VIC20



• 1 MHz, 5KB RAM, BASIC, 3.5KB RAM, 176x184 3 bit color video



• Commodore C64



• 64KB RAM, 320x200 4 bit color video

Commodore C64



**** COMMODORE 64 BASIC V2 ****
64K RAM SYSTEM 38911 BASIC BYTES FREE
READY.

- BASIC programming language, but serious programs written in assembly
- No fancy stuff like multi-process, user accounts, virtual memory, etc.
- Machine itself had no mass storage had to buy tape drive, then floppy disk drive, machine was obsolete once hard drives came around

BASIC Demo



- Commands get executed (just like Python interpreter)
 PRINT "HELLO WORLD"
 HELLO WORLD
- Program with line numbers
 10 PRINT "HELLO WORLD"
 20 GOTO 10
- List program LIST
- Execute program RUN
- Another example (takes about 1 second to run)
 20 FOR I = 1 TO 1000
 30 NEXT



6502 specification

6502 Specification



- 8-bit processor, using 16 bit address space (up to 64KB RAM)
- 3 registers: accumulator, X register, Y register
- Status register: contains flags
- Operating system in ROM (read only memory)
- Stack -- more on that later
- Interrupts -- more on that later

Assembly Code Instructions



- Load and store from A, X, and Y register
- Transfer between registers
- Arithmetric: add, subtract, increment, decrement
- ullet Shift and rotate, e.g., 00001111 o 00011110
- Logic: AND and OR
- Compare and test
- Branch (conditional jump)
- Set and clear flag values
- Jump and subroutines
- Interrupt: cause interrupt, return from interrupt
- Stack operations

Memory Organization



```
0000-00ff Zero page: used for variables
```

0100-01ff Stack

0200-03ff More variables [C64]

0400-07ff Screen memory (characters) [C64]

0800-9fff BASIC RAM [C64]

a000-bfff BASIC ROM [C64]

c000-cffff Upper RAM Area [C64]

d000-dfff Character shape ROM / Video and audio RAM [C64]

e000-ffff Kernel ROM [C64]

Can switch to RAM under ROM

Load and Store



• 3 Registers: Accumulator, X, Y

• Load from memory: LDA, LDX, LDY

• Store to memory: STA, STX, STY



ullet Immediate: load specified value LDA #\$22 o accumulator has now value \$22 (hex)



- Immediate: load specified value LDA $\#$22 \rightarrow accumulator has now value $22 (hex)$
- \bullet Absolute: load value from specified address LDA \$D010 \to accumulator has now value store in memory position \$D010



- Immediate: load specified value LDA $\#$22 \rightarrow accumulator has now value $22 (hex)$
- ullet Absolute: load value from specified address LDA \$D010 o accumulator has now value store in memory position \$D010
- \bullet Zero page: as above, but for memory addresses 0000-00FF LDA \$6A \to accumulator has now value store in memory position \$006A



- Immediate: load specified value LDA $\#$22 \rightarrow accumulator has now value $22 (hex)$
- \bullet Absolute: load value from specified address LDA \$D010 \to accumulator has now value store in memory position \$D010
- ullet Zero page: as above, but for memory addresses 0000-00FF LDA \$6A o accumulator has now value store in memory position \$006A
- ullet Relative: relative to current program counter BCC $\$06 \rightarrow \text{jump } 6 \text{ memory positions forward, if carry flag clear}$



• X and Y registers can be used as indexes for memory lookup



- X and Y registers can be used as indexes for memory lookup
- Indexed with X register
 - example: LDA \$0400,X
 - add value of register X to \$0400 (say, X= $\$05 \rightarrow \0405)
 - load value from that memory position (\$0405)



- X and Y registers can be used as indexes for memory lookup
- Indexed with X register
 - example: LDA \$0400,X
 - add value of register X to \$0400 (say, X= $\$05 \rightarrow \0405)
 - load value from that memory position (\$0405)
- Variants: Y register, zero page



- X and Y registers can be used as indexes for memory lookup
- Indexed with X register
 - example: LDA \$0400,X
 - add value of register X to \$0400 (say, $X=\$05 \rightarrow \0405)
 - load value from that memory position (\$0405)
- Variants: Y register, zero page
- Zero Page Indexed Indirect
 - example: LDA (\$15,X)
 - add value of register X to \$15 (say, X= $\$02 \rightarrow \0017)
 - treat resulting memory position as pointer (say, \$0017 contains \$E0, \$0018 contains \$FF)
 - load value from that address (\$FFE0)

Transfer Between Registers



• 3 Registers: Accumulator, X, Y

• Transfer from Accumulator: TAX, TAY

• Transfer to Accumulator: TXA, TXY

• Note: no TXY, TYX

Arithmetic



- Addition (to accumulator): ADC
 - ADC #\$02 \rightarrow add 2 to accumulator
 - ADC $\$4050 \rightarrow \text{add}$ value in memory at address \$4050 to accumulator
- Subtraction (from accumulator): SBC
- Increment by 1: INC, INX, INY
- Decrement by 1: DEC, DEX, DEY
- Sets carry, overflow, zero flag



- Carry: set iff
 - addition/increase results in value >255
 - subtraction/decrease results in value <0</pre>



- Carry: set iff
 - addition/increase results in value >255
 - subtraction/decrease results in value <0</pre>
- Overflow (V): same under assumption that numbers are signed



- Carry: set iff
 - addition/increase results in value >255
 - subtraction/decrease results in value <0</pre>
- Overflow (V): same under assumption that numbers are signed
- Zero: set iff result of operation/load/transfer is 0



- Carry: set iff
 - addition/increase results in value >255
 - subtraction/decrease results in value <0</pre>
- Overflow (V): same under assumption that numbers are signed
- Zero: set iff result of operation/load/transfer is 0
- Negative: set iff result of operation/load/transfer sets bit 7



- Carry: set iff
 - addition/increase results in value >255
 - subtraction/decrease results in value <0</pre>
- Overflow (V): same under assumption that numbers are signed
- Zero: set iff result of operation/load/transfer is 0
- Negative: set iff result of operation/load/transfer sets bit 7
- Other flags: Break, Interrupt, Decimal (more on these later)



- Carry: set iff
 - addition/increase results in value >255
 - subtraction/decrease results in value <0</pre>
- Overflow (V): same under assumption that numbers are signed
- Zero: set iff result of operation/load/transfer is 0
- Negative: set iff result of operation/load/transfer sets bit 7
- Other flags: Break, Interrupt, Decimal (more on these later)
- Clear flags: CLC, CLV, CLI, CLD
- Set flags: SEC, SED, SEI

Example Program



Address	Bytes	Command
4000	65 1C	(data: number 1)
4002	A0 9E	(data: number 2)
4004	00 00	(data: sum)
4006	AD 00 40	LDA 4000
4009	18	CLC
400A	6D 0 2 40	ADC 4002
400D	8D 04 40	STA 4004
4010	AD 01 40	LDA 4001
4013	6D 0 3 40	ADC 4003
4016	8D 05 40	STA 4005
4019	00	BRK

Example Program



Bytes	Command
65 1C	(data: number 1)
A0 9E	(data: number 2)
00 00	(data: sum)
AD 00 40	LDA 4000
18	CLC
6D 0 2 40	ADC 4002
8D 04 40	STA 4004
AD 01 40	LDA 4001
6D 03 40	ADC 4003
8D 0 5 40	STA 4005
00	BRK
	65 1C A0 9E 00 00 AD 00 40 18 6D 02 40 8D 04 40 AD 01 40 6D 03 40 8D 05 40

16 bit addition

Branch



• Simple jump: JMP

• Flags can be used for conditional jump ("branch")

```
BCC Branch if carry flag clear
BCS Branch if carry flag set
BEQ Branch if zero flag set
BMI Branch if negative flag set
BNE Branch if zero flag clear
BPL Branch if negative flag clear
BVC Branch if overflow flag clear
BVS Branch if overflow flag set
```

Shift and Rotate



• Rotate bits by one position

```
- ROL: Rotate left, i.e., 11110000 \rightarrow 11100001
```

- ROR: Rotate right, i.e., $11110000 \rightarrow 01111000$

Shift and Rotate



• Rotate bits by one position

```
- ROL: Rotate left, i.e., 11110000 \rightarrow 11100001
```

- ROR: Rotate right, i.e., $11110000 \rightarrow 01111000$

• ASL (Arithmetric Shift Left) / LSR (Logical Shift Right) use carry bit

```
- ASL: 11110000 (C=0) → 1110000 (C=1)
```

- LSR: 11110000 (C=1) \rightarrow 11111000 (C=0)



• Elementary school multiplication:

10101 x 1101













- Idea
 - shift second operand to right (get last bit)
 - if carry: add first operand to sum
 - rotate first operand to left (multiply with binary 10)

Code



Address	Bytes	Command
4100	0 3	(data: number 1)
4101	0 6	(data: number 2)
4102	00	(data: product)
4103	A9 00	LDA #00
4105	A2 08	LDX #08
4107	4E 01 41	LSR 4101
410A	90 04	BCC 4110
410C	18	CLC
410D	6D 00 41	ADC 4100
4110	2E 00 41	ROL 4100
4113	CA	DEX
4114	D0 F1	BNE 4107
4116	8D 02 41	STA 4102
4119	00	BRK