

## Installation guide "CW Keyer I/F and AK4951 audio codec board" for HL2b5 or later 5 July 2019 JI1UDD

- 1. Change FPGA IO Bank5 voltage to match AKM4951 IO voltage (3.3V). Supply 3.3V to  $V_{LVDS}$  instead of 2.5V.
  - 1-1. Remove FB28 from HL2.
  - 1-2. Install the removed Ferrite Bead between DB1-7pin and R72 (3.3V side).





2. Connect "CW Keyer I/F and AK4951 audio codec board" to HL2.

HL2b5 or later			codec board
signal	connector		connector
name	Pin #		Pin#
DIN	DB1-2		CN5-7
DOT	DB1-3		CN4-2
PTT	DB1-4		CN4-3
DASH	DB1-5		CN4-6
PDN	DB1-6		CN4-7
GND	DB1-13		CN4-1
	DB1-14		CN4-8
SCL1	DB1-16	$\rightarrow$	DB1-3
SDA1	DB1-18	$\rightarrow$	DB1-2
+3.3V	DB1-19		CN4-4
	DB1-20		CN4-5
BCK	DB12-1	$\rightarrow$	CN5-2
LRCK	DB12-2	$\rightarrow$	CN5-3
DOUT	DB12-6	<del>-</del>	CN5-6

