

### **ZJU-UIUC Institute**



Zhejiang University / University of Illinois at Urbana-Champaign Institute

# ECE 486 Control Systems

Lecture 18: Pl and lag, PID and lead-lag

Liangjing Yang
Assistant Professor, ZJU-UIUC Institute
liangjingyang@intl.zju.edu.cn



### Schedule check

Frequency Response

Wee k	Торіс	Ref.
1	Introduction to feedback control	Ch. 1
	State-space models of systems; linearization	Sections 1.1, 1.2, 2.1–2.4, 7.2, 9.2.1
2	Linear systems and their dynamic response	Section 3.1, Appendix A
	Transient and steady-state dynamic response with arbitrary initial conditions	Section 3.1, Appendix A
3	System modeling diagrams; prototype second-order system	Sections 3.1, 3.2, lab manual
	Transient response specifications	Sections 3.3, 3.14, lab manual
4	National Holiday Week	
5	Effect of zeros and extra poles; Routh-Hurwitz stability criterion	Sections 3.5, 3.6
	Basic properties and benefits of feedback control	Section 4.1, lab manual
6	Introduction to Proportional-Integral-Derivative (PID) control	Sections 4.1-4.3, lab manual
	Review A	
7	Term.Test.1	,
	Introduction to Root Locus design method	Ch. 5
8	Root Locus continued; introduction to dynamic compensation	Ch. 5
	Lead and lag dynamic compensation	Ch. 5
9	Introduction to frequency-response design method	Sections 5.1-5.4, 6.1
	Bode plots for three types of transfer functions	Section 6.1

	rrequency	Response
Week	Topic	Ref.
10	Stability from frequency response; gain and phase margins	Section 6.1
	Control design using frequency response	Ch. 6
11	Control design using frequency response continued; PI and lag, PID and lead-lag	Ch. 6
	Nyquist stability criterion	Ch. 6
12	Gain and phase margins from Nyquist plots	Ch. 6
	Term Test II (Review B)	
13	Introduction to state-space design	Ch. 7
	Controllability, stability, and pole-zero cancellations; similarity transformation; conversion of controllable systems to Controller Canonical Form	Ch. 7
14	Pole placement by full state feedback	Ch. 7
	Observer design for state estimation	Ch. 7
15	Joint observer and controller design by dynamic output feedback I; separation principle	Ch. 7
	Dynamic output feedback II (Review C)	Ch. 7
16	END OF LECTURES	
	Finals	

State-Space

**Root Locus** 


#### Plan of Lecture

- Review: Control design using frequency response: PD/lead
- Today: Control design using frequency response: PI/lag, PID/lead+lag

#### Goal:

- understand the effect of various types of controllers (PD/lead, PI/lag) on the closed-loop performance by reading the open-loop Bode plot;
- develop frequency-response techniques for shaping transient and steady-state response using dynamic compensation

### Review: Bode's Gain-Phase Relationship



Assuming that G(s) is minimum-phase (i.e., has no RHP zeros), we derived the following for the Bode plot of KG(s):



	low freq.	real zero/pole	complex zero/pole
mag. slope	n	up/down by 1	up/down by 2
phase	$n \times 90^{\circ}$	up/down by 90°	up/down by 180°

We can state this succinctly as follows:


Gain-Phase Relationship. Far enough from break-points,  ${\rm Phase} \approx {\rm Magnitude~Slope} \times 90^{\circ}$ 



Gain-Phase Relationship. Far enough from break-points,

Phase  $\approx$  Magnitude Slope  $\times$  90°

This suggests the following rule of thumb:




- ► M has slope -2 at  $\omega_c$ ⇒  $\phi(\omega_c) = -180^\circ$ ⇒ bad (no PM)
- ► M has slope -1 at  $\omega_c$ ⇒  $\phi(\omega_c) = -90^\circ$ ⇒ good (PM =  $90^\circ$ )
- this is an important design guideline!!

(Similar considerations apply when M-plot has positive slope – depends on the t.f.)


### Review: Bode's Gain-Phase Relationship

#### D-Control.



$$\uparrow^{Y} \begin{cases}
|KG(j\omega_c)| = 1 \\
\angle G(j\omega_c) = -90^{\circ}
\end{cases} \Rightarrow KG(j\omega_c) = -j$$

M-plot for open-loop t.f. KG:




$$T(j\omega_c) = \frac{KG(j\omega_c)}{1 + KG(j\omega_c)} = \frac{-j}{1 - j}$$
$$|T(j\omega_c)| = \left|\frac{-j}{1 - j}\right| = \frac{1}{\sqrt{2}}$$
$$|KG(j\omega)| = \frac{|KG(j\omega)|}{1 + j}$$

Closed-loop t.f.:

Note:  $|KG(j\omega)| \to \infty$  as  $\omega \to 0$ 

$$|T(0)| = \lim_{\omega \to 0} \frac{|KG(j\omega)|}{|1 + KG(j\omega)|} = 1$$
  
 $\implies \omega_c = \omega_{\text{BW}} \text{ (bandwidth)}$ 

- ▶ If PM = 90°, then  $\omega_c = \omega_{\rm BW}$
- ▶ If  $PM < 90^{\circ}$ , then  $\omega_c < \omega_{\rm BW} < 2\omega_c$  (see FPE)



Bode's Gain-Phase Relationship suggests that we can shape the time response of the *closed-loop* system by choosing K (or, more generally, a dynamic controller KD(s)) to tune the Phase Margin.


In particular, from the quantitative Gain-Phase Relationship,

Magnitude slope(
$$\omega_c$$
) = -1  $\Longrightarrow$  Phase( $\omega_c$ )  $\approx -90^{\circ}$ 

— which gives us PM of 90° and consequently good damping.

### Recall: Frequency Response Control Design

So far, .....



Bode plot relationship suggests that we can shape the time response of the closed-loop system by selecting K


### Lead Controller Design with Freq. Response

- 1. Choose K to get desired bandwidth spec w/o lead
- 2. Choose lead zero and pole to get desired PM
  - in general, we should first check PM with the K from 1, w/o lead, to see how much more PM we need
- 3. Check design and iterate until specs are met.

This is an intuitive procedure, but it's not very precise, requires trial & error.

#### Recall: Dynamic Compensation

Objectives: stabilize the system and satisfy given time response specs using a stable, causal controller



Characteristic equation:

$$1 + K \cdot \frac{s+z}{s+p} \cdot \mathcal{G}_{\rho} = 1 + KL(s) = 0$$

#### 浙江大学伊利诺伊大学厄巴纳香槟校区联合学院

#### Recall: Lead & Lag Compensation

Consider a general controller of the form

$$K\frac{s+z}{s+p}$$
 —  $K, z, p > 0$  are design parameters

Depending on the relative values of z and p, we call it:

- ▶ a lead compensator when z < p
- ▶ a lag compensator when z > p

Why the name "lead/lag?" — think frequency response 
$$\angle \frac{j\omega + z}{j\omega + p} = \angle (j\omega + z) - \angle (j\omega + p) = \psi - \phi$$

- if z < p, then  $\psi \phi > 0$ (phase lead)
- if z > p, then  $\psi \phi < 0$ (phase lag)



#### 浙江大学伊利诺伊大学厄巴纳香槟校区联合学院

#### Recall: PD and Lead Control



Controller transfer function is  $K \frac{s+z}{s+z}$ , where:

$$K = K_P + pK_D$$
,  $z = \frac{pK_P}{K_P + pK_D} \xrightarrow{p \to \infty} \frac{K_P}{K_D}$ 

so, as  $p \to \infty$ , z tends to a constant, so we get a lead controller.

We use lead controllers as dynamic compensators for approximate PD control.

To keep things simple, let's set  $K_P = K_D$ . Then:

$$K = K_P + pK_D = (1 + p)K_D$$
  

$$z = \frac{pK_P}{K_D + pK_D} = \frac{pK_D}{(1 + p)K_D} = \frac{p}{k_D} \xrightarrow{p \to \infty} 1$$


Since we can choose p and z directly, let's take

$$z = 1$$
 and  $p$  large.

We expect to get behavior similar to PD control.

From what we have seen so far:


- ▶ p large good damping, but bad noise suppression (too close to PD); the branches first break in (meet at the real axis), then break away.
- ▶ p small noise suppression is better, but RL is too close to  $j\omega$ -axis, which is not good; no break-in for small values of p.
- ▶ intermediate values of p transition between two types of RL: break-in and break-away points are the same.



#### Recall Pl and Lag Control


PI Control ret tracking, avoid ss error. Case study: plant transfer function  $G_p(s) = \frac{1}{s}$ 

Control objective: stability and constant reference tracking In earlier lectures, we saw that for perfect steady-state tracking we need PI control



Closed-loop poles are determined by:

$$1 + \left(K_{\mathrm{P}} + \frac{K_{\mathrm{I}}}{s}\right) \left(\frac{1}{s-1}\right) = 0$$



- (from Routh-Hurwitz)
- ► For very large K, we get a completely damped system, with negative real poles
- ► Perfect steady-state tracking of constant references:

$$\frac{D}{R} = \frac{1}{1 + G_c G_p}$$

$$= \frac{s(s - 1)}{s(s - 1) + K(s + 1)}$$
DC gain $(R \rightarrow E) = 0$  (for  $K > 1$ )

▶ However: 1/s is not a stable

How About:

replace  $K \frac{s+1}{s}$  by  $K \frac{s+1}{s+p}$ , where p is small

replace  $K \frac{s+z}{s}$  by  $K \frac{s+z}{s+p}$ , where p < z

This is lag compensation (or lag control)! We use lag controllers as dynamic compensators for approximate PI control.

Tracking a constant reference: if the stability conditions

$$K > 1 - p$$
,  $Kz > p$ 

$$e(\infty) = \frac{1 - \frac{Kz}{p}}{1 - \frac{Kz}{p}}$$

this will be close to zero (and negative) if Kz is large.

Lag compensation does not give perfect tracking (indeed, it does not change system type), but we can get as good a tracking as we want by playing with K, z, p. On the other hand, unlike PI, lag compensation gives a stable controller.

$$L(s) = \frac{s+1}{(s+p)(s-1)}$$

Intuition: By choosing p very close to zero, we can make the root locus arbitrarily close to PI root locus (stable for large




Compare to PI root locus

What do we see? Compared to PD vs. lead, there is no qualitative change in the shape of RL, since we are not changing #(poles) or #(zeros).

### Lag Compensation: Bode Plot

$$D(s) = \frac{s+z}{s+p} = \frac{z}{p} \frac{\frac{s}{z}+1}{\frac{s}{p}+1}, \qquad z \gg p$$



▶ 
$$\frac{j\omega + z}{j\omega + p} \xrightarrow{\omega \to \infty} 1$$
  
so  $M \to 1$  at high frequencies

▶ subtracts phase, hence the term "phase lag"

$$\frac{j\omega + z}{j\omega + p} \xrightarrow{\omega \to 0} \frac{z}{p}$$
steady-state tracking error

steady-state tracking error:

$$e(\infty) = \frac{sR(s)}{1 + D(s)G(s)}\Big|_{s=0}$$

large  $z/p \Longrightarrow$  better s.s. tracking

▶ lag decreases  $\omega_c \Longrightarrow$  slows down time response (to compensate, adjust K or add lead)

caution: lead increases PM, but adding lag can undo this

 $\blacktriangleright$  to mitigate this, choose both zand p very small, while maintaining desired ratio z/p

# Example (design).

$$G(s) = \frac{1}{(s+0.2)(s+0.5)} \stackrel{\text{Bode form}}{=} \frac{10}{\left(\frac{s}{0.2}+1\right)\left(\frac{s}{0.5}+1\right)}$$

#### Objectives:

- ▶  $PM > 60^{\circ}$
- ▶  $e(\infty) \le 10\%$  for constant reference (closed-loop tracking error)

#### Strategy:

▶ we will use lag

$$KD(s) = K\frac{s+z}{s+p}, \qquad z \gg p$$

- $\triangleright$  z and p will be chosen to get good tracking
- ightharpoonup PM will be shaped by choosing K
- $\triangleright$  this is different from what we did for lead (used p and z to shape PM, then chose K to get desired bandwidth spec)


### Example

$$G(s) = \frac{1}{(s+0.2)(s+0.5)} \stackrel{\text{Bode form}}{=} \frac{10}{\left(\frac{s}{0.2}+1\right)\left(\frac{s}{0.5}+1\right)}$$

$$(\frac{s}{0.2}+1)(\frac{s}{0.5}+1)$$
 Type  $\mathcal{I}$ 

#### Step 1: Choose K to Shape PM

Check Bode plot of G(s) to see how much PM it already has:



• from Matlab,  $\omega_c \approx 1$ 

- ▶  $PM \approx 40^{\circ}$
- we want  $PM = 60^{\circ} = \emptyset | \% \circ$

$$\phi = -120^{\circ}$$
 at  $\omega \approx 0.573$   $M = 2.16$ 

— need to decrease K to 1/2.16

A conservative choice (to allow some slack) is K = 1/2.5 = 0.4, gives  $\omega_c \approx 0.52$ , PM  $\approx 65^{\circ}$ 

ice, toleronne.

#### Step 2: Choose z & p to Shape Tracking Error

So far: 
$$KG(s) = \frac{0.4 \cdot 10}{\left(\frac{s}{0.2} + 1\right)\left(\frac{s}{0.5} + 1\right)}$$

$$e(\infty) = \frac{1}{1 + KG(s)} \Big|_{s=0} = \frac{1}{1+4} = \frac{1}{5} = 20\%$$
 (too high)

To have  $e(\infty) < 10\%$ , need KD(0)G(0) > 9:


$$e(\infty) = \frac{1}{1 + KD(0)G(0)} \le \frac{1}{1+9} = 10\%.$$

So, we need

$$D(0) = \frac{s+z}{s+p}\Big|_{s=0} = \frac{z}{p} \ge \frac{9}{4} = 2.25$$
 — say,  $z/p = 2.5$ 

Not to distort PM and  $\omega_c$ , let's pick z and p an order of magnitude smaller than  $\omega_c \approx 0.5$ : z = 0.05, p = 0.02


### Overall Design



— the design still needs a bit of refinement ...

Let's combine the advantages of PD/lead and PI/lag.

Back to our example: 
$$G(s) = \frac{10}{\left(\frac{s}{0.2} + 1\right)\left(\frac{s}{0.5} + 1\right)}$$



- from Matlab,  $\omega_c \approx 1$
- ▶  $PM \approx 40^{\circ}$


New objectives:

- $\sim \omega_{\rm BW} \geq 2$
- ▶  $PM \ge 60^{\circ}$
- ▶  $e(\infty) \le 1\%$  for const. ref.

What we got before, with lag only:

- ▶ Improved PM by adjusting K to decrease  $\omega_c$ .
- ► This gave  $\omega_c \approx 0.5$ , whereas now we want a larger  $\omega_c$  (recall:  $\omega_{\text{BW}} \in [\omega_c, 2\omega_c]$ , so  $\omega_c = 0.5$  is too small)

So: we need to reshape the phase curve using lead.



Step 1. Choose K to get  $\omega_c \approx 2$  (before lead)


Using Matlab, can check:

at 
$$\omega = 2$$
,  $M \approx 0.24$  (with  $K = 1$ )

— need 
$$K = \frac{1}{0.24} \approx 4.1667$$

— choose K = 4 (gives  $\omega_c$  slightly < 2, but still ok).





Step 2. Decide how much phase lead is needed, and choose  $z_{\text{lead}}$  and  $p_{\text{lead}}$ 

Using Matlab, can check:

at 
$$\omega = 2$$
,  $\phi \approx -160^{\circ}$ 

— so 
$$PM = 20^{\circ}$$

(in fact, choosing K = 4 made things worse: it increased  $\omega_c$  and consequently decreased PM)

We need at least 40° phase lead!!


The choice of lead pole/zero must satisfy

$$\sqrt{z_{\text{lead}} \cdot p_{\text{lead}}} \approx 2 \implies z_{\text{lead}} \cdot p_{\text{lead}} = 4$$

Need at least 40° phase lead, while satisfying

$$\sqrt{z_{\text{lead}} \cdot p_{\text{lead}}} \approx 2 \implies z_{\text{lead}} \cdot p_{\text{lead}} = 4$$

Let's try 
$$z_{\text{lead}} = 1$$
 and  $p_{\text{lead}} = 4$  
$$D(s) = \frac{s+1}{\frac{s}{4}+1}$$



Phase lead =  $37^{\circ}$  — not enough!!


Need at least 40° phase lead, while satisfying

$$\sqrt{z_{\text{lead}} \cdot p_{\text{lead}}} \approx 2 \implies z_{\text{lead}} \cdot p_{\text{lead}} = 4$$

The choice of  $z_{\text{lead}} = 1$ ,  $p_{\text{lead}} = 4$  gave phase lead  $= 37^{\circ}$ .

Need to space  $z_{\text{lead}}$  and  $p_{\text{lead}}$  farther apart:

$$\begin{cases} z_{\text{lead}} = 0.8 \\ p_{\text{lead}} = 5 \end{cases} \implies \text{phase lead } = 46^{\circ}$$



Step 3. Evaluate steady-state tracking and choose  $z_{\rm lag}, p_{\rm lag}$  to satisfy specs

So far:

$$K \underbrace{D(s)}_{\text{lead}} G(s) = 4 \frac{\frac{s}{0.8} + 1}{\frac{s}{5} + 1} \cdot \frac{10}{\left(\frac{s}{0.2} + 1\right) \left(\frac{s}{0.5} + 1\right)}$$

$$KD(0)G(0) = 40 \implies e(\infty) = \frac{1}{1 + KD(0)G(0)} = \frac{1}{1 + 40}$$

— this is not small enough: need 
$$1\% = \frac{1}{100} = \frac{1}{1+99}$$

We want 
$$D(0) \ge \frac{99}{40}$$
 with lag  $\frac{z_{\text{lag}}}{p_{\text{lag}}} \approx 2.5$  will do

Need to choose lag pole/zero that are sufficiently small (not to distort the phase lead too much) and satisfy  $\frac{z_{\text{lag}}}{p_{\text{lag}}} \approx 2.5$ .

We can stick with our previous design:

$$z_{\text{lag}} = 0.05, \qquad p_{\text{lag}} = 0.02$$

Overall controller:

$$\underbrace{4\frac{\frac{s}{0.8} + 1}{\frac{s}{5} + 1}}_{\substack{\text{lead (with} \\ \text{gain } K = 4 \text{ absorbed)}}} \cdot \underbrace{\frac{s + 0.03}{s + 0.03}}_{\substack{\text{lag (not in Bode form}}}$$

(Note: we don't rewrite lag in Bode form, because  $z_{\text{lag}}/p_{\text{lag}}$  is not incorporated into K.)


K-> lead param -> (cue pouram.

### Frequency Domain Design Pros & Cons

#### **Advantages**

Design based on Bode plots is good for:

• easily visualizing the concepts



- evaluating the design and seeing which way to change it
- ▶ using experimental data (frequency response of the uncontrolled system can be measured experimentally)

#### Disadvantages

Design based on Bode plots is not good for:

- exact closed-loop pole placement (root locus is more suitable for that)
- $\blacktriangleright$  deciding if a given K is stabilizing or not ...
  - ▶ we can only measure *how far* we are from instability (using GM or PM), if we know that we are stable
  - $\blacktriangleright$  however, we don't have a way of checking whether a given K is stabilizing from frequency response data

What we want is a frequency-domain substitute for the Routh-Hurwitz criterion — this is the Nyquist criterion, which we will discuss in the next lecture.