

我司部分无线网卡支持在国产操作系统安装使用，具体驱动的安装方法以 TL-XDN6000（免驱版）网卡为例。可选择通过双击驱动文件安装或使用命令行安装。

（适用型号：TL-XDN6000（免驱版） / TL-XDN6000H（免驱版） / TL-XDN7000（免驱版） / TL-XDN7000H（免驱版））

方法一：双击驱动文件安装

国产统信操作系统（UOS）和国产麒麟操作系统（Kylin）均支持 deb 格式的安装包进行软件安装。

1、从 TP-LINK 官网下载对应的网卡驱动程序：

首页/软件详情

Q 输入关键词检索

TL-XDN6000免驱版 V1.0 Linux系统驱动程序20250118

更新时间：2025-01-24 文件大小：802KB 文件格式：zip

收藏 下载 用手机查看

运行环境:	Linux 、国产UOS、麒麟V4/V10等系统
适用产品:	TL-XDN6000免驱版
更新日期:	2025-01-24
文件大小:	802KB
软件介绍:	适用于TL-XDN6000免驱版 V1.0版本的Linux系统驱动程序。

2、解压驱动文件压缩包后，可直接双击驱动（.deb 结尾），并输入当前帐号的密码（系统 Root 权限的账号密码）进行安装。

注：如果双击安装不成功，建议按照方法二使用命令行安装。

方法二：使用命令行安装

1、从 TP-LINK 官网下载对应的网卡驱动程序；

首页/软件详情

Q 输入关键词检索

TL-XDN6000免驱版 V1.0 Linux系统驱动程序20250118

更新时间: 2025-01-24 文件大小: 802KB 文件格式: zip

收藏 下载 用手机查看

运行环境:	Linux 、国产UOS、麒麟V4/V10等系统
适用产品:	TL-XDN6000免驱版
更新日期:	2025-01-24
文件大小:	802KB
软件介绍:	适用于TL-XDN6000免驱版 V1.0版本的Linux系统驱动程序。

2、解压驱动文件压缩包，在驱动所在文件夹，空白处右键选择 “在终端打开” ；



3、检查系统是否安装了 build-essential 包，如果没有，需要进行安装。检查和安装命令分别如下：

检查命令：dpkg -s build-essential

安装命令：sudo apt-get update

sudo apt-get install build-essential

4、安装驱动命令：sudo dpkg -i aic8800drvpackage.deb, -i 后面的是驱动包名称，需要根据实际名称修改。

5、等待打印最后出现 Install aic8800 wifi driver successful!!!!, 表示网卡驱动安装成功。

```
Install aic8800 wifi driver successful!!!!
```

6、安装完成驱动后，可以使用 ifconfig 确认网卡是否加载成功。如果有对应的网卡设备，说明加载成功，可以在 wifi 连接界面连接路由器。

```
al@al-ThinkPad-T470:~/workspace/aic8800_linux_driver_2023_0213/USB/driver_fw/drivers/aic8800$ ifconfig
eth0: flags=4099<UP,BROADCAST,MULTICAST> ntu 1500
    ether 52:54:00:12:34:56 txqueuelen 1000 (Ethernet)
    RX packets 0 bytes 0 (0.0 B)
    RX errors 0 dropped 0 overruns 0 frame 0
    TX packets 0 bytes 0 (0.0 B)
    TX errors 0 dropped 0 overruns 0 carrier 0 collisions 0
    device interrupt 16 memory 0xed100000-ed120000

lo: flags=73<UP,LOOPBACK,RUNNING> ntu 65536
    inet 127.0.0.1 netmask 255.0.0.0
    inet6 ::1 prefixlen 128 scopeid 0x10<host>
    loop txqueuelen 1000 (Local Loopback)
    RX packets 3613 bytes 261406 (261.4 KB)
    RX errors 0 dropped 0 overruns 0 frame 0
    TX packets 3613 bytes 261406 (261.4 KB)
    TX errors 0 dropped 0 overruns 0 carrier 0 collisions 0

wlan0: flags=4099<UP,BROADCAST,MULTICAST> ntu 1500
    ether 52:54:00:12:34:56 txqueuelen 1000 (Ethernet)
    RX packets 0 bytes 0 (0.0 B)
    RX errors 0 dropped 0 overruns 0 frame 0
    TX packets 0 bytes 0 (0.0 B)
    TX errors 0 dropped 0 overruns 0 carrier 0 collisions 0

wlan1: flags=4099<UP,BROADCAST,MULTICAST> ntu 1500
    ether 52:54:00:12:34:56 txqueuelen 1000 (Ethernet)
    RX packets 0 bytes 0 (0.0 B)
    RX errors 0 dropped 0 overruns 0 frame 0
    TX packets 0 bytes 0 (0.0 B)
    TX errors 0 dropped 0 overruns 0 carrier 0 collisions 0
```