14353120 14/11 1至一時

- 1. Port B 有8-bit; Port E有 bbit
- 2. 初始化并行端口.
 - 1. Turn on Port Foliak vin SY'SCTI_RCGCGPIO_R ①局部多量存在找中 warf two bus oydes
 - I. Unlock PFD. PD7
- I. Clear AMSEL to disable analog
- IV. Clear PCIL to select GPID
- V. Set DIR to D for input, I foroutput
- VI Clear AFSEL bits to 0 to select regular 1/0
- VII. Set PUE buts to 1 to enable internal pull-up

IXVIII. Set DEN bits to 1 to enable data pins

1x. Read/write CaPID_PORIF_DATA-R.

- 3. First read the entire port into a regrister AND or mask the Particular bit & we want.
- 4、LSR是逻辑右移,右移榜旅符号匠道接达补口; ASR 建算术方移,方移要考虑行移位,原来最长达为 是什么数字即科上什么数字。
- 5. Ont = In+1;
- 6. LDR RD,=1n

LDR RI. [RO]

ADD RI, RI, #1

LDR RZ,= Out

STR RI, [RI]

- 7. 科的应用 to 在C+种野中:

 - ② 参数分级中存在科中
 - ③调用函数时程序的弦符 以发生被存在我中门家连归 调用的时候。

 - ○一个程序中, 入我, 当我的攻鼓 金相差
 - ② 我的刀背、为科教作不能在 我和分派的空间引进行
 - ③读和修改城中的内容时不 能在科室间设使用过的地名 进行
 - 9. 如直接寻址、相对寻址 间接寻址等
 - 10.要先确定负载和以及要储存 教的英型,决定用哪一种:
- 1) LPR loads 32-bit signed or unsigned value from memory
- @ LPRH loads 16-bit unsigned value from monory
- 3 LDRSH loads 16-but sugned value from
- memory (P) LDRB Wads 8-but unsigned vollne from memory
- J. LDRSB bonds 8-but signed volue from memory