- 型號: DKMI1461SD
- 結構:機械式結構
- 軸: Cherry MX 機械軸
- 鍵帽材質:ABS
- 印字技術:雷雕
- LED燈光: 雙色燈
- 介面: USB
- 同時按鍵輸出數: USB全鍵輸出 (NKRO)
- PCB電路板:雙層電路板
- 尺寸: 295(L)x102(W)x38(H) mm
- 重量:730g
- 產地:台灣 - 本説明書韌體版本:
- 美規 V1.1.0;日規 V2.1.0;歐規 V3.1.0。

Ducky Mini 重點特色

- ☑小鍵盤可以按出全鍵盤的按鍵訊號。 ▼採用雙色燈設計,搭配出超越2種色彩,更加豐富有趣。
- ■加入滑鼠動作功能,雙手不離開鍵盤也能操作。
- ☑ 提供多種客製化功能設計,讓使用者決定鍵位配置符合更 多需求:
 - 3種ESC鍵。
 - 2種BackSpace鍵。

☑堅持採用德國Cherry機械軸,品質有保障。

- Caps Lock可切換成Fn鍵、Ctrl鍵。
- 使用者可以決定要採用1~3個Fn鍵,更提供多種
- 位置挑選。
- 可交換滑鼠左鍵與右鍵功能位置。



鍵盤配置圖(以美規舉例)

鍵盤配置圖 (以美規舉例)

Fn層



*先按住 Fn 鍵,再按下指定的按鍵,就能送出 Fn 層的鍵盤訊號,此層主要是輸出60%鍵盤主鍵位區以外的鍵盤訊號



*先按住 Fn 鍵再按住 Alt 鍵後,再按下指定的按鍵,就能送出 Fn + Alt 層的鍵盤指令,此層主要負責鍵盤的設定值


創新業界,「Ducky Advisor」設定設計,互動式切換鍵盤按鍵定義

雖然Ducky Mini能滿足全鍵盤的功能,但為了符合每一位使用者的操作需求,可依據玩家的想法特別針對特定 按鍵提供多種配置設定。在設定的過程中,不需要記憶太多步驟,只要順著Ducky背光鍵盤的按鍵,來引導使 用者設定儲存。從硬體設定的好處,即是無須受到不同類型連接裝置所影響,直接從鍵盤就能即時設定,支 援性最高。此外,創新的「Ducky Advisor」設定功能,領先業界充分發揮背光鍵盤的功能。

進入設定模式: Fn + Alt + H按住3秒鐘 進入設定模式後,只會亮燈Q、ESC、Backspace、 Fn、Caps Lock、M,共6個按鍵,當使用者按下不同按鍵




設定與操作過程



燈光操作模式

Ducky Mini使用雙色LED燈,依據不同版本定義提供2種燈光顏色Color A、Color B。透過Ducky混 燈技術,可以讓使用者依據2種不同顏色的搭配,組合出超越2色表現。



- *Fn相關功能提示顏色參照100%全亮模式的顏色而決定。

記憶區域背光 Ducky背光專利功能: 記憶區域背光,提供2組給使用者儲存鍵盤上想要背光的區域設定。並且每個

按鍵還能提供不同顏色儲存,更貼近使用者想要顯示的背光鍵盤理想。

Fn + Alt + V	顯示CM1記憶區域背光
Fn + Alt + B	顯示CM2記憶區域背光
Fn + Alt + Caps Lock 按住3秒	REC,可錄製CM1、CM2
Caps Lock + N	REC Over
	-

✓ 操作重點提示:先調整喜歡的燈色,再選擇要指定的按鍵。 操作過程: 1.按住 Fn + Alt + Caps Lock(REC) 3秒, Mini會只亮CM1、CM2, 如果想設定CM1請按下CM1, 反之想設定

- 2. 當進入錄製模式後, Caps Lock旁會顯示當前要設定的顯示顏色, 可以透過Caps Lock + Z/X/C調整顯示燈 色。當有喜歡的顏色出現時,直接在鍵盤上按下任意鍵,該鍵就會儲存成喜歡的顏色。
- 3.使用者可以重覆上一個步驟,讓Ducky Mini在同一組區域背光設定中,不同按鍵能擁有多種不同燈色。 4. 當完成錄製後,按下REC Over (Caps Lock + N)功能,結束錄製。
 - · Caps Lock旁的圓形處,主要用來顯示要設定區域的燈光顏色。



* 當進入錄製模式時,會先顯示上一回儲存的內容狀態。 * 錄製30秒無動作,不儲存後自動關閉。

店家櫥窗DEMO模式

展示多色DEMO,方便店家展示,但平時也能使用。 Fn+空白鍵 按住3秒 開啟與關閉

行動電源DEMO模式 可以支援Ducky Mini連接行動電源等非電腦提供的電源使用,不過此模式下無法記憶,因此需要

使用DEMO模式時,無法送出鍵盤訊號,皆需要重新插拔。 Ctrl + Shift + Caps Lock壓住按鍵不放,再輸入電源。

回復出廠設定 Fn + Alt + R 按住5秒

美規、歐規、日規 壓住5秒後,全鍵盤會閃3下表示完成回復 會將所按鍵模式,切換成預設的Mode 1

- Model Name: DKMI1461SD

- Type: Mechanical Keyboard
- Switch: Cherry MX mechanical switches - Keycap material: ABS
- Legend printing: Lasered - LED: Dual Color LEDs
- Interface: USB
- Simultaneous key input: USB N-Key Rollover (NKRO)
- PCB: Dual layer PCB - Dimensions: 295(L)x102(W)x38(H) mm - Weight: 730g
- Origin of Production: Taiwan - Manual for firmware version:
- ANSI V1.1.0, JIS V2.1.0, ISO V3.1.0

Ducky Mini Features ■ Using only genuine Cherry MX mechanical switches.

- ☑ Dual color LEDs allows you to customize the color to
- shades anywhere in between ✓ Mouse key function allows you to keep your hands on the keyboard without wasting time moving your hand to the
- mouse.
 - Multiple customization options allow you to customize the keyboard to the way you use your keyboard:
 - 3 different ESC keys.
 - 2 Backspace keys.


- User switchable left and right mouse button.

- Caps Lock switchable to Fn or Ctrl key.

- User can choose 1~3 Fn keys in the position they want.

Keyboard Layout Map (US ANSI keyboard as example)

Top Layer




Fn Layer



functional keys outside of the main 60% typing area.

Fn+Alt Layer



Introducing "Ducky Advisor" A brand new visually guided way to use and setup your keyboard

Ducky Mini encompass nearly all the functionality of a full-sized keyboard. To accommodate different preferences, there are multiple options in regarding the setup of the keyboard layouts. The Ducky Advisor visually guide the user through the setup process. Specific keys will light up during each step of the process guiding the user. The advantage of pure hardware setup is that it requires no complicated driver packages, and can be setup on any system that supports the usage of a keyboard. Ducky Advisor is a ground breaking way of integrating backlight into useful feature. Enter setup mode: Hold Fn + Alt + H for 3sec In setup mode, only 6 keys will be backlit: Q, ESC, Backspace, Fn, Caps Lock and M. Each denote a special

function key in this mode.

Setup and setup procedure display Display | Setup Procedure

	Q		N/A	Quit			
			1	Mode 1 Mode 2 Mode 3			
	ESC		2	Set Mode 1 ~ Mode 3			
			3				
	Backspace		1	Set Mode 1 ~ Mode 2			
	Баскэрасе		2	Set Mode 1 - Mode 2 - Del Del			
Hold			1	Set as Caps Lock			
Fn + Alt + H	+ Alt + H Caps Lock →	\rightarrow	2	Set as Fn Key			
for 3 seconds			3	Set as Ctrl			
ior o seconds	Fn		1 2	L_Ctrl L_Windows L_Alt Set as R_Alt R_Windows R_Apps R_Ctrl * Ducky Mini's factory default is Mode 1 * Ducky Mini's bottom row allows users configure 1 to 2 Fn Keys. The limitatic being that user cannot replace 2 key with the same function. For example, L_Ctrl is set as Fn Key, then R_C cannot be set as the Fn Key.			
	M		1	Mode 1, Q = Left mouse click, E = Right Mouse Click			
	IVI		2	Mode 2, Q = Right mouse click, E = Left Mouse Click			
LFD zone	customiz	ati	on mo	ode			

Lighting mode setup Ducky Mini uses dual color LEDs. Different versions may have different LED colors, so the manual will refer to the colors as Color A and Color B. The dual color LEDs allows you to mix the 2 colors to anything in between.

Fn + Alt + Z: Adjust Color A's brightness Fn + Alt + X: Adjust Color B's brightr First Mode: 100% Backlit Mode

	First Mode: 100% Backlit Mode	Fn + Alt + X: Adjust Color B's brightness
		Fn + Alt + C: Clear Color A,Color B's backlighting
		Fn + Alt + Z: Adjust Color A's brightness
	Second Mode: Reactive Mode	Fn + Alt + X: Adjust Color B's brightness
Fn + Alt +G		Fn + Alt + C: Clear Color A,Color B's backlighting
	Third Mode: Reactive Mode Advanced	Randomized color with each keypress
	Fourth Mode: Raindrop Mode	Randomized per key backlighting effect
	Fifth Mode: Wave Mode	Multicolored wave from left to right
	Sixth Mode: Color Cycling Mode	Automatic color blending effect
	Seventh Mode: Off	Turn off backlight
	mode and Reactive mode's colors are independ	
	s function display will follow 100% backlight mode sed in place of Alt on ISO layout keyboards.	e's color setting.
5411 50 40	and the plant of the plant has been determined as the plant has be	

- **Automatic Demo Display Mode**

Multi-color display mode for store displays or for fun at home.

Hold Fn+Space for 3sec On and Off

Mobile Power Demo Mode

This mode allows the keyboard to be powered by any USB power source. Normally, the keyboard requires a computer to be connected to turn on the backlighting. This mode will not send any keycodes and will not function as a keyboard. Please unplug and plug the keyboard to restart the keyboard in normal keyboard

Hold Ctrl+Shift+Caps Lock, then plug the keyboard into power source. Reset to factory defaults

Hold Fn + Alt + R for 5secUS_ANSI, EU_ISO, JP_JIS layouts. * Hold for 5 seconds. LED backlighting will blink three times after the keyboard have been reset.

allowing you to customizing individual key's backlighting and color. Fn + Alt + V Display CM1 User customized backlighting.

4. To finish recording, press REC Over (Caps Lock + N).

to customize CM2.

Fn + Alt + B Display CM2 User customized backlighting. Hold Fn + Alt + Caps Lock for 3sec REC. Mode to record CM1 and CM2

Ducky Mini uses Ducky's patented backlighting memory technology. This mode provides 2 sets of memory,

Tiola Till Tale Cape Ecol Tol Cooc	The of thous to record out I did out it
Caps Lock + N	REC Over. Stops the recording session.
✓ Adjust the color of the LED first, the	n eet individual kov's hacklighting
Adjust the color of the LED first, the	ii set iiluividual key s backligittiilg.
Recording Procedure:	
1. Hold Fn + Alt + Caps Lock (REC) for	3 seconds, CM1 and CM2 will be backlit. Press CM1 to custo

- 2. The LED on the side of Caps Lock will display the current LED color. The color to be set can be adjusted by hitting Caps Lock + Z/X/C. After setting the desired color, hitting any key on the keyboard will set that key to the selected color. 3. Repeating the above steps allows the user to set different keys to different colors.
- * The circle on the top right corner of Caps Lock is used to display the current color used for setting the next key's backlight color.
 - * Entering the recording mode will display the previously saved setting. * If no changes are made within 30 seconds in the recording mode, the recording session will terminated without saving.
- * All keys will be reset to factory setting under Mode 1.