
ATHENA Rev. 1.1.0
PCB by Rocky Hill
CoCo3RFModulator
Left Joystick
Right Joystick
RS232
Cassette
Reset Switch
CVIDEO
SOUND
J5B1001
J5A1001
open hardware
MC6809E
IC1
SN74LS245N
IC3
IC2
27C256
IC6
TCC1014
IC9
74LS138
W65C21N6TPG-14
IC4
IC5
IC7
SC77527P
IC8
IC10
74LS244
IC11
74LS374
IC12
IC13
IC14
74LS30
IC15
74LS04
IC16
IC17
IC18
TMS4464
IC19
J0971CS5VDC.45
RF1
RY1
CN1
CN2
CN4
CN5
CN6
CN7
SW1
SW2
SW3
H1
H2
Based on the Color Computer 3 Service Manual and the revised schematic by Ty Sopko
Rev. 1.1.0