

Endless Office Occupational Degression Chart

Degressions Chart

This chart shows the equivalences between distance and degression.

Add	Endless Office Occupational 1.3 m	Endless Office Occupational 2 m	Endless Office Occupational 4 m	Endless Office Occupational 6 m
0.75	-	0.25	0.50	0.75
1.00	0.25	0.50	0.75	1.00
1.25	0.50	0.75	1.00	1.25
1.50	0.75	1.00	1.25	1.50
1.75	1.00	1.25	1.50	1.75
2.00	1.25	1.50	1.75	2.00
2.25	1.50	1.75	2.00	2.25
2.50	1.75	2.00	2.25	2.50
2.75	2.00	2.25	2.50	2.75
3.00	2.25	2.50	2.75	3.00
3.25	2.50	2.75	3.00	-
3.50	2.75	3.00	-	-

FWD (m) = $\frac{1}{(\text{Add} - \text{Degression})}$

Power Range Chart

This chart is an approximation and the range can be wider or narrower depending on the blanks used. There is no limitation in the IOT software. The only limitation is at the production stage and this depends on the machinery and the blanks in use.

Materials	Endless Office Occupational Lenses
1.50	+5.00 to -6.00
TRIVEX®	+5.00 to -6.00
MID-INDEX	+5.00 to -6.00
POLY	+7.00 to -9.00
1.60	+8.00 to -6.00
1.67	+8.00 TO -6.00
1.74	+8.00 to -6.00