

Church lighting

Lightkey and Booth Check on the MacBook. Shut the MacBook down after every use.

Leave everything plugged in: the charger, and the USB cable from the MacBook to the blue ENTTEC Open DMX box.

Start

- 1** Open the MacBook and press the power button.
 - 2** Type the password.
It's written on the MacBook.
 - 3** Wait. Don't click anything yet.
A big sign says not to touch the Mac while Booth Check finds the DMX box and opens Lightkey by itself. If it says to unplug and replug, it means the USB cable in the blue box: pull it out and plug it back in.
 - 4** In Lightkey, click the most recent project: `BackupChurch_modular`
 - 5** Tap Authenticate on the Touch Bar, and type the password again.
- ✓ **The lights are working.**

Finish

- 1** Apple menu → Shut Down.
- 2** Close the lid.
Leave everything plugged in.

Something not working?

- 1** Restart the whole MacBook:
Apple menu → Restart.
Then follow Start again from step 2.
- 2** **Still not working?** Take a photo of the screen, write down the steps you tried, and send Fynn a message.

Sorry for the inconvenience, and thank you.