

Church lighting

Lightkey and Booth Check on the MacBook. Shut the MacBook down after every use.

Leave everything plugged in: the charger, and the USB cable from the MacBook to the blue ENTTEC Open DMX box.

Start

- 1** Open the MacBook and press the power button.
 - 2** Type the password.
It's written on the MacBook.
 - 3** Wait. Don't click anything yet.
Booth Check finds the DMX box, then opens Lightkey by itself. If it says to unplug and replug, it means the USB cable in the blue box: pull it out and plug it back in.
 - 4** In Lightkey, click the most recent project: `BackupChurch_modular`
 - 5** Tap Authenticate on the Touch Bar, and type the password again.
- ✓ **The lights are working.**

Finish

- 1** Apple menu → Shut Down.
- 2** Close the lid.
Leave everything plugged in.

Something not working?

- 1** Restart the whole MacBook:
Apple menu → Restart.
Then follow Start again from step 2.
- 2** **Still not working?** Take a photo of the screen, write down the steps you tried, and send Fynn a message.

Sorry for the inconvenience, and thank you.