

Networking > Networking Software > ... > Managing an Expansion ROM Image

Managing an Expansion ROM Image

To burn an Expansion ROM image, run the following command:

```
# flint -d <mst device> brom <image name>.mrom
```

The “brom” command installs the ROM image on the flash device or replaces an already existing one.

Example:

```
# flint -d /dev/mst/mt4099_pci_cr0 brom example.mrom Current ROM info on
flash: N/A New ROM info: type=PXE version=3.5.305 cpu=AMD64 Burning ROM
image - OK Restoring signature - OK #
```

To read an expansion ROM image to a file, run the following command:

```
# flint -d <mst device> rrom <image name>.rom
```

Example:

```
# flint -d /dev/mst/mt4099_pci_cr0 rromexample.mrom # flint -d
/dev/mst/mt4099_pci_cr0 q Image type: FS2 FW Version: 2.42.5000 FW
Release Date: 4.5.2017 Rom Info: type=PXE version=3.5.305 cpu=AMD64
Device ID: 4099 Description: Node Port1 Port2 Sys image GUIDs:
f45214030001b8a0 f45214030001b8a1 f45214030001b8a2
f45214030001b8a3 MACs: f4521401b8a1 f4521401b8a2 VSD: PSID:
MT_1090120019 #
```

To remove the expansion ROM, run the following command:

```
# flint -d <mst device> drom
```

Examples:

```
# flint -d /dev/mst/mt4099_pci_cr0 drom Removing ROM image - OK Restoring
signature - OK
```



Previous page

Performing Checksum

Calculation on Image/Device

Next page

Setting GUIDs and MACs



🔮 Use with AI ▾



[Privacy Policy](#)

[Your Privacy Choices](#)

[Terms of Service](#)

[Accessibility](#)

[Corporate Policies](#)

[Product Security](#)

[Contact](#)

Copyright © 2026 • Powered by Scroll Sites & Atlassian Confluence