

Verifying the Firmware Image

To verify the FW image on the Flash, use the following command line:

```
# flint -d <device> verify
```

To verify the FW image in a file, use the following command line:

```
# flint -i <image file> v
```

where:



device	Flash device to verify.
image file	Image file to verify.

Examples:

```
# flint -d /dev/mst/mt4099_pci_cr0 v # flint -i ./image_file.bin verify
```

Comparing the Binary Image

Binary comparison of the firmware image enables the user to verify that a given firmware image contains the image that matches the given device.

Since ConnectX-4/ConnectX-4 Lx devices have iTOC (image specific) and dTOC (device specific) sections at the beginning of the device flash, and the MFA2 archive does not have the dTOC information by its definition, the binary comparison will ignore the device specific sections on the device.

```
#flint -d <device> -i <fw image> --silent (optional) bc  
(or binary_compare)
```

Last updated: January 06, 2020



Previous page
[Querying the Firmware Image](#)

Next page
[Performing Checksum
Calculation on Image/Device](#)





[Privacy Policy](#)

[Your Privacy Choices](#)

[Terms of Service](#)

[Accessibility](#)

[Corporate Policies](#)

[Product Security](#)

[Contact](#)

Copyright © 2026 · Powered by Scroll Sites & Atlassian Confluence