manual.md 2024-03-23



Cymbal Starlight 2024: Owner's Manual

Chapter 1: Safety

Introduction

Your safety and the safety of others is paramount. This chapter provides important information to help you operate your Cymbal Starlight 2024 safely and responsibly. Please read and understand this information thoroughly before operating your vehicle.

Seat Belts

- All occupants must wear seat belts at all times.
- Adjust the seat belt to fit snugly around your hips and across your chest.
- Never wear a seat belt under your arm or behind your back.
- Replace any seat belt that has been damaged or frayed.

Airbags

- Airbags are supplemental restraints and work in conjunction with seat belts to provide additional protection in the event of a collision.
- Do not place objects on or near the airbag deployment areas (e.g., dashboard, steering wheel, seat backs).
- Children under the age of 12 should never ride in the front seat.
- If the airbag warning light illuminates, have the vehicle inspected by a qualified technician immediately.

Child Safety

- Use age- and size-appropriate child restraints for all children.
- Install child restraints according to the manufacturer's instructions.
- Never leave a child unattended in the vehicle.
- Lock all doors and windows when leaving the vehicle parked.

Vehicle Stability Control (VSC)

 VSC is an electronic system that helps control the vehicle's stability during cornering and other maneuvers. manual.md 2024-03-23

 VSC can be turned off by pressing the VSC OFF button on the dashboard. However, it is recommended to leave VSC on for optimal safety.

Anti-Lock Braking System (ABS)

- ABS prevents the wheels from locking during braking, allowing you to maintain control of the vehicle.
- ABS can be felt as a pulsation in the brake pedal during braking. Do not release the brake pedal; continue applying steady pressure until the vehicle comes to a stop.

Tire Safety

- Maintain proper tire pressure at all times (see the Tire Pressure Information label on the driver's door jamb).
- Check tire tread depth regularly and replace tires when they reach the minimum tread depth of 2/32 inches.
- Avoid sudden starts, stops, and turns that can cause excessive tire wear.

Vehicle Inspection

- Inspect your vehicle regularly for any signs of damage or malfunction, including:
 - o Leaks under the vehicle
 - Unusual noises or vibrations
 - o Dim or flickering lights
 - Worn or damaged tires
- If you notice any problems, have the vehicle inspected by a qualified technician immediately.

Driving Safely

- Always obey the speed limit and traffic laws.
- Avoid distractions while driving, such as using a cell phone or texting.
- Be aware of your surroundings and anticipate the actions of other drivers.
- Use caution when driving in inclement weather or on slippery roads.
- If you feel tired or unwell, pull over to a safe location and rest.

Chapter 2: Child Safety

Introduction

The safety of your children is of paramount importance. This chapter provides important information on how to keep your children safe while traveling in your Cymbal Starlight 2024.

Child Restraints

- **Rear-facing car seats:** Children under the age of 2 should always ride in a rear-facing car seat. Rear-facing car seats provide the best protection for your child's head, neck, and spine in the event of a collision.
- Forward-facing car seats: Children who have outgrown their rear-facing car seat should ride in a forward-facing car seat with a harness. Forward-facing car seats should be used until your child reaches the maximum height and weight limits for the seat.
- **Booster seats:** Children who have outgrown their forward-facing car seat should ride in a booster seat. Booster seats help position the seat belt correctly across your child's body. Booster seats

manual.md 2024-03-23

- Avoid running the heating or air conditioning system at full blast.
- The heating and air conditioning systems in your Cymbal Starlight 2024 require regular maintenance to ensure that they are operating properly. The following maintenance tasks should be performed at the intervals specified in the maintenance schedule in your vehicle's owner's manual:
 - Replace the cabin air filter
 - Clean the condenser and evaporator coils
 - Check the refrigerant level

By following these tips, you can get the most out of the heating and air conditioning system in your Cymbal Starlight 2024 and keep your vehicle comfortable year-round.

Chapter 17: Maintenance and Care

Maintenance Schedule

The following is a maintenance schedule for your Cymbal Starlight 2024. This schedule is based on normal driving conditions. If you drive in severe conditions, you may need to service your vehicle more frequently.

Service	Interval
Oil change	Every 5,000 miles or 6 months
Tire rotation	Every 5,000 miles or 6 months
Air filter replacement	Every 10,000 miles or 12 months
Cabin air filter replacemer	nt Every 15,000 miles or 12 months
Brake inspection	Every 10,000 miles or 12 months
Battery inspection	Every 20,000 miles or 24 months
Spark plug replacement	Every 30,000 miles or 36 months
Fuel filter replacement	Every 30,000 miles or 36 months
Timing belt replacement	Every 60,000 miles or 60 months

Do-It-Yourself Maintenance

Some maintenance tasks, such as changing the oil and rotating the tires, can be performed by do-it-yourselfers. However, it is important to consult your vehicle's owner's manual before performing any maintenance tasks yourself.

Professional Maintenance

It is important to have your Cymbal Starlight 2024 serviced by a qualified technician at least once a year. A qualified technician can perform a thorough inspection of your vehicle and identify any potential problems.

Car Care Tips

In addition to following the maintenance schedule, there are a number of things you can do to keep your Cymbal Starlight 2024 in good condition. These include: