Coromandel	COROMANDEL INTERNATIONAL LIMITED Sarigam	Doc No. : INST/ SOP / 21
Issue No.01	DEPARTMENTAL MANUAL OF INSTRUMENT	Issue/ Revision Date: 02/10/2017
Revision: 00	Title: SAFE OPERATING PROCEDURE FOR INSPECTION AND SERVICING OF BURNER	Page 1 of 2

#### 1.0 PURPOSE:

For inspection and servicing or preventive maintenance of burner to maintain reliability.

### 2.0 SCOPE:

This procedure is applicable for servicing/inspection or preventive maintenance of any burner provided in process plant and utility of Coromandel International Limited, Sarigam.

#### 3.0 **DEFINITION:**

**NIL** 

#### 4.0 PROCEDURE:

- 4.1 Take work permit from the shift in charge/area in-charge to inspect the burner and ensure the burner is not in use.
- 4.2 Check all the connections if they tight or not. If any connections are loose, tighten them.
- 4.3 Check if there is over vibration in any part of the burner& rectify the same.
- 4.4 Clean and check the photocell if it is working or not, otherwise replace it.
- 4.5 Maintain the air pressure in the burner, check if it is maintained or not.
- 4.6 Check the potentiometer, if not proper tighten it using the screws provided.
- 4.7 Check the PID and positioner controller, if it is working in order or not.
- 4.8 Check if the interlocks are working in the proper sequence or not.
- 4.9 Check the servo motor and ignition transformer, if working properly or not.
- 4.10 Damper inspection and oiling.
- 4.11 Do proper greasing and oiling wherever required.
- 4.12 If it is ok, hand over to plant in charge/ area in-charge.
- 4.13 If it is not ok, then repair it. After repairing, Fix the burner and hand over to plant in charge/area in-charge.
- 4.14 Preventive maintenance record should be maintain in format no.: INST/F/16
- 4.15 Close the all permits.

Prepared By:	Reviewed By:	Approved By:
Name :	Name :	Name :
Date :	Date :	Date :

Coromandel	COROMANDEL INTERNATIONAL LIMITED Sarigam	Doc No. : INST/ SOP / 21
Issue No.01	DEPARTMENTAL MANUAL OF INSTRUMENT	Issue/ Revision Date: 02/10/2017
Revision: 00	Title: SAFE OPERATING PROCEDURE FOR INSPECTION AND SERVICING OF BURNER	Page 2 of 2

# **5.0 FREQUENCY:**

- 5.1 At the time of initial startup after shutdown of more than two weeks.
- 5.2 After every 6 months, if plant is running.

## **6.0 RESPONSIBILITIES:**

1) Asst. Manager/Sr. Officer (Inst.) /area in-charge:

## 7.0 ACCOUNTABILITY

Section Head

# 8.0 RECORDS:

Service reports should be maintained for one year.

### 9.0 ATTACHMENTS:

Sr.	Format	Format No.
No.		
1	Preventive maintenance check point	INST/F/16

### 10.0 CHANGE RECORD:

Date	REV.	CHANGES INCORPORATED	
	NO.		
02/10/2017	00	Original Issue	

# \*\* END OF PROCEDURE \*\*

Prepared By:	Reviewed By:	Approved By:
Name :	Name :	Name :
Date :	Date :	Date :