DHVANI Pod – Printing Instructions

Side-scan sonar payload pod · 5 prints · PLA · fits a 250 mm bed

Files and colours

File	Qty	Colour
DHVANI_Pod_lower.stl	1	Yellow or orange PLA
DHVANI_Pod_upper.stl	1	Yellow or orange PLA
DHVANI_Pod_saddle_PRINT_2.stl	2	Black or grey PLA
DHVANI_Pod_assembled_VIEW_ONLY.stl	–	Do not print (viewing only)

Paint the long grooved transducer strips on the lower sides black after printing, or swap to black filament when the print reaches them.

Settings (all parts)

Material	Layer height	Walls	Infill	Brim
PLA	0.2 mm	3	15% gyroid	On for lower and upper

Orientation and supports

Part	Place on the bed	Supports
Lower	Flat underside down (as exported)	Tree, build-plate only
Upper	Cut face down (as exported)	Tree, on (inside the dome)
Saddle × 2	Flat side down	None

Important

- The two halves are 247.5 mm long: place them straight along the bed's longest direction.
- Don't scale any part; the pockets are sized to the real boards.
- Print the lower half first so the boards can be test-fitted before the dome.
- Check the slicer preview: the top window, the dial hole and the “DHVANI” text should be visible.
- Clean the plate with isopropyl alcohol before each print.

Hardware for assembly

4 × M3 × 10 mm self-tapping screws · double-sided foam tape