



Handheld Blower & Vacuum

P30



Product Image



Product Name: Turbo Fan

Model: P30

Battery: 18650 battery cell

- **Charging Time:** 2.5 - 3 hours
- **Motor Power:** 184W
- **Maximum Operating Voltage:** 5.5V - 8.4V
- **Maximum Operating Current:** 25A
- **Product Weight:** 248g ± 10g (whole machine)
- **Maximum Wind Speed:** 52m/s
- **Speed Change Mode:** 4 - speed adjustment

Wind Speed Adjustment

- **First Gear:** Gentle Wind (40 minutes ± 7 minutes)
- **Second Gear:** Strong Wind (25 minutes ± 5 minutes)
- **Third Gear:** Super - strong Wind (17 minutes ± 5 minutes)
- **Fourth Gear:** Violent Wind (7.2 minutes ± 2 minutes)

How to Use

- Long - press the circular power - on button for 1.5S to turn on or turn off the device.
- After turning on, double - click the power - on button, and the front air outlet will light up the

illuminating lamp.

- Click the gear button to select the first - gear wind, and then successively for the second - gear wind, third - gear wind.
- Long - press the gear button for 1.5S to enter standby mode.
- When in standby mode, long - press the gear button for 1S to switch to the violent - gear mode.

Charging

- The battery level is displayed on the screen.
- When the battery level is lower than 10%, the fan will automatically turn off.

Maintenance

- 1.Please keep this product out of reach of children and pets.
- 2.Please store it in a dry environment. Do not place this product in high - temperature conditions or expose it to sunlight in a car.
- 3.When not in use, please charge the battery once every three months.
- 4.Before use, remove any debris from the air inlet and air outlet to avoid blockage.
- 5.During use, prevent foreign objects from being sucked into the air inlet. Otherwise, it may cause the turbine to jam, preventing normal operation, overheat the motor, and damage the product.
- 6.Do not use alcohol, nail polish remover, or cleaning agents to clean this product.
- 7.Please do not use or store this product in a humid environment.
- 8.If it stops operating abnormally and cannot be started, please turn it off immediately and stop using it.
- 9.Do not disassemble or modify this product without permission.
- 10.Do not use a fast - charging adapter with a current of more than 3A to charge this product.
- 11.Do not use this product while charging.