# Lesson 6 Subroutines

#### **Overview**

Introduction	Often we have logic we wish to use several places in our programs. The subroutine provides a way to do this effectively. In this section, we will review subroutines, and look at delay timers, which is one example of where we may use subroutines.	
In this section	Following is a list of topics in this section:	
	Description	See Page
	Why we want subroutines	2
	Why we don't want subroutines	3
	Stack	4
	Instructions for building subroutines	5
	Let's try this out	6
	Using the Subroutine	8
	Timing Loops	12
	Wrap Up	14

 Revised: 03 Jan 2004 - 09:11 PM
 Page 1 of 14

 Printed: 03 Jan 2004 - 09:11 PM
 John J. McDonough, WB8RCR

### Why we want subroutines

Introduction	In this section, we will take a look at the advantages of framing our code as subroutines.	
Rework	In developing programs, we often find that the same kinds of logic appears over and over again. By placing this logic in a subroutine, we only need to write the code once. It can then be used over and over within our program.	
Reliability	Subroutines, when well thought out, are standalone little packages of logic. As such, they can be tested independently, and we can be assured that they do what we expect. We can then use them over and over with confidence, and without the need to constantly debug them.	
Readability	Assembler programs tend to get somewhat long and gangly. By breaking our logic into functionally complete modules, we can make our programs a lot easier to understand.	
Debugging	By breaking our code into logical modules, we can debug them more or less independently. This greatly improves the debugging process, as it helps us to focus on one small area. It also gives us a degree of confidence that the other parts of the program can be ignored for the time being.	
Memory	Since this logic we are re-using appears only once in program memory, subroutines can help reduce the program memory demands of our application.	

Revised: 03 Jan 2004 - 09:11 PM Printed: 03 Jan 2004 - 09:11 PM

### Why we don't want subroutines

Introduction	While subroutines have their place, there are reasons to avoid their use. Here are just a few.	
Complexity	If we are going to make maximum use of subroutines, our logic needs to be made a little more flexible. Depending on the particular situation, this can mean our logic is more complex than it might be, had we used to same algorithm in line.	
Performance	Whenever we call a subroutine, we need to have the initial logic we might have put in line, plus, we need to call the subroutine and get back from it. While this overhead isn't great, it is overhead, and it can be an issue in a timing sensitive situation. The total penalty amounts to 4 microseconds with a 4 MHz crystal, or 800 ns with a 20 MHz PIC.  The other issue is that the complexity we mentioned above can lead to reduced performance, as well. This depends on our logic, of course, but it can also be a factor	
	in places where we are pressed for cycles.	
System Limitations	Some of the real power of subroutines comes from having a subroutine call another subroutine, which may call another subroutine. This nesting of subroutines can have a dramatic impact on the amount of code we need to write. Unfortunately, the PIC has a has a stack only eight elements deep, which means we can only nest our subroutine calls seven or eight deep. While this isn't a real common problem, we do need to be cognizant of just how deeply we are nesting subroutines.	

 Revised: 03 Jan 2004 - 09:11 PM
 Page 3 of 14

 Printed: 03 Jan 2004 - 09:11 PM
 John J. McDonough, WB8RCR

#### **Stack**

Introduction	Almost all computers have a special construct called a stack. In some computers, the stack is implemented in the main memory, and there are special pointers to allow for stack specific instructions. In the case of the PIC, the stack is a special hardware memory. Because of the Harvard architecture (remember this from lesson 1?), there are no instructions for directly manipulating the stack. There are instructions which do affect the stack, but we can't actually look at the stack programmatically. (The PIC18 series of microcontrollers do include instructions for directly manipulating the stack.)	
What is a stack	A stack is a special memory which is addressed in a special way. Instead of accessing the stack by an address, like other memory, a stack can only be accessed at the "top". The model is very much like a stack of paper. You an "push" data onto the top of the stack, or "pop" data off the top of the stack, much like you would place a piece of paper onto the top of a pile, and remove it from the top.  However, unlike a pile of paper, you cannot slide a piece of data into the middle of the stack, nor can you reach in and slide a piece of data out of the middle. You can	
	only access the stack from the top.	
The PIC Stack	In the PIC16 parts, the stack is 13 bits wide by 8 words deep. This means that the stack can hold eight program memory locations, and can address the program memory space of any of the PIC16 parts.	
Instructions affecting the stack	The PIC16 instruction set contains no instructions for directly manipulating the stack or the stack pointer. However, there are a few instructions which affect the stack. These are: call, return, retlw, and retfie. In addition, an interrupt affects the stack.	
	We will talk about interrupts and the retfie instruction later in the course. In this lesson, we will examine the call, return, and retlw instructions.	

Revised: 03 Jan 2004 - 09:11 PM Printed: 03 Jan 2004 - 09:11 PM

### Instructions for building subroutines

Introduction	Here we will examine the three instructions that we will use to create subroutines; the call, return, and retlw instructions.	
The call instruction	Whenever we want to use a subroutine, we execute a call instruction. The call instruction is just like a goto instruction, except that before jumping, the current program counter is pushed onto the stack. Since the program counter is incremented as soon as an instruction is loaded by the PIC, this value is one higher than the program counter value for the call.	
The return instruction	The return instruction does the opposite. The return instruction loads the value at the top of the stack into the program counter. This causes the next instruction to be executed to be the instruction after the original call.	
The retlw instruction	Quite often, we would like a subroutine to not only do something, but to return some result to the calling program. This is exactly what the retlw instruction does. This instruction loads a literal value into the working register, and then behaves just like a return instruction.	
Putting this together	The call/return pair provides a way to jump out of our main program, do something, and then come back to where we left off. The structure typically looks something like the following:  Do some stuff call MySub Do some other stuff  MySub Do some stuff return  Typically, the subroutines are grouped together at the start of the program file, and a goto instruction skips around them to the start of the main logic. There is no rule that says it has to be this way, but there are times when it is convenient for subroutines to be near the front, and keeping all the subroutines together makes for greater readability.	

 Revised: 03 Jan 2004 - 09:11 PM
 Page 5 of 14

 Printed: 03 Jan 2004 - 09:11 PM
 John J. McDonough, WB8RCR

Elmer 160 Elmer 160 Lesson 6.doc

#### Let's try this out

#### Introduction

In order to start this new experiment, guess what? We need to create a new project (Lesson6a), and a new assembler file (Lesson6a.asm). Just like we did before.

# Our first subroutine

Insert the following code into the assembler file:

```
processor
                        PIC16F84A
            include
                        <p16f84a.inc>
            config
                        _XT_OSC & _WDT_OFF & _PWRTE_ON
            cblock
                      H'20'
                  Spot1
                              ; A variable to play with
            endc
                        Start ; Skip to mainline
            goto
     Our subroutine begins here
;
Sub1
            incf
                        Spot1,F
           return
     Here is the start of the mainline
Start
                        H'fc'; Put something in
            movlw
            movwf
                        Spot1 ; Spot1
Loop
                        Sub1 ; Call the subroutine
            call
                        Loop ; Do it again
            goto
            end
```

You should be able to cut and paste the above code, although you may have to clean up the tabs a bit. Use the I-beam tool at the top of your PDF reader:



# Running the Program

After assembling the program, open the Stack window (View->Hardware Stack). Pressing F7 three times should bring you to the call instruction. Notice that the stack window hasn't changed. Also notice that the program counter at the bottom of the window shows pc:0x5. Press F7 once more. A lot happens. The program counter goes to 1, and a 6 gets placed on the stack (5 plus 1). The next step increments a file register location, but the next one returns to the instruction after the call (pc:0x6), and the stack pointer returns to point to 'Empty'.

Notice that the stack now contains two 6's. This is actually trash. Whatever is on the stack below the stack pointer (the green arrow) simply doesn't matter. If we do a call, we'll overwrite what is there, and we can't do a return because there is nothing left to pop.

Continued on next page

Revised: 03 Jan 2004 - 09:11 PM

Printed: 03 Jan 2004 - 09:11 PM

#### Let's try this out, Continued

#### Nesting Subroutines

Let's examine what happens when we call one subroutine from another. Change our subroutine to look like the following:

```
; New subroutine begins here
Sub2
    incf     Spot1,F
    return
; Original subroutine begins here
Sub1
    call     Sub2
    return
```

And again, assemble it.

The new code has moved our original call instruction down to location 7, so the call places an 8 on the stack. The new call is at location 3, so a single step puts a 4 at the top of the stack. Notice that everything else is pushed down.

The next step increments Spot1, nothing very exciting there, but yet another step executes the return, changing the program counter to 4, and removing the 4 from the top of the stack. Clicking again, removes the 8 (which has now risen to the top) and sets the program counter to 8.

We can nest subroutines like this, and make successive calls, and the stack mechanism will keep track of where we came from with little worry. However, we can never be more than 8 levels deep or the stack will overflow (and our program will do strange things!)

 Revised: 03 Jan 2004 - 09:11 PM
 Page 7 of 14


 Printed: 03 Jan 2004 - 09:11 PM
 John J. McDonough, WB8RCR

#### **Using the Subroutine**

Introduction	We said earlier that subroutines can help us break our program into manageable pieces. Let's do an example.
	Begin, as usual, by creating a new project, Lesson6b.
Program	PIC programs are almost always intended to do the same thing over and over again.

# **Structure**

As a result, our programs almost always look a little like:



So, we can start almost every program out with code that looks something like:

```
processor pic16f84a
                        <p16f84a.inc>
            include
                         _XT_OSC & _WDT_OFF & _PWRTE_ON
            __config
                         Start ; Skip to mainline
            goto
Start
            goto
                         Loop
            end
OK, certainly we are going to end up with a cblock at the front, too.
```

Continued on next page

Loop

Revised: 03 Jan 2004 - 09:11 PM

Printed: 03 Jan 2004 - 09:11 PM

#### Using the Subroutine, Continued

#### The main loop

Let's suppose that we want to write a program for the PIC-EL which is going to send the word TEST in Morse code over and over again out the transmitter port. With what we have leaned so far, that may seem like a pretty tall order. But by breaking the problem down into small, logical pieces, and breaking those pieces down again and again, we can eventually get to a point where we can envision the code.

We might imagine that our mainline is going to look a bit like the following:

```
Loop

call SendT

call SendE

call SendS

call SendT

call WordSpace

goto Loop
```

Getting from the concept to the code is the second hardest part of developing PIC applications. The subroutine idea can go a long way to helping us.

(The hardest part is coming up with the concept in the first place!)

### Sending the letters

OK. Now we need to send the letters. Well, again, if we think about this problem at a high enough level, it's pretty simple:

```
Send the letter T
SendT
            call
                         Dah
            call
                         LetSpc
            return
      Send the letter E
SendE
            call
                         Dit
            call
                         LetSpc
            return
      Send the letter S
SendS
            call
                         Dit
            call
                         Dit
            call
                         Dit
            call
                         LetSpc
            return
```

We've gone down another level, and we've assumed we're going to write a few more routines; one to send a dit, one to send a dah, and one to wait for the period of time we want between letters.

Continued on next page

 Revised: 03 Jan 2004 - 09:11 PM
 Page 9 of 14

 Printed: 03 Jan 2004 - 09:11 PM
 John J. McDonough, WB8RCR

Elmer 160 Lesson 6.doc

#### Using the Subroutine, Continued

### Sending the elements

Now we need to figure out how to send the elements that make up the Morse letters. That shouldn't be so tough. Maybe something like:

```
Send a Dah
Dah
            call
                         XmitOn
            call
                         DahTime
            call
                         XmitOff
            call
                         DitTime
            return
      Send a Dit
Dit
            call
                         XmitOn
            call
                         DitTime
            call
                         XmitOff
            call
                         DitTime
            return
```

This is starting to get pretty involved, but by applying subroutines, we really haven't done anything particularly hard.

# Keying the Transmitter

OK, now it's time for the big disappointment. Here we are, rolling along, but we're not ready, just yet, to talk about manipulating the PIC's I/O pins. So for now, we're simply going to manipulate a single bit in memory instead of the transmitter.

First we need a word to store that bit:

```
cblock H'20'
Output
endc
```

and we're going to define the particular bit we set:

```
XMTR equ H'07'
```

And we need to initialize the Output variable:

```
Start

clrf Output ; Init output off
```

And we need routines for turning the transmitter (bit) on and off:

Continued on next page

Page 10 of 14 John J. McDonough, WB8RCR Revised: 03 Jan 2004 - 09:11 PM

Printed: 03 Jan 2004 - 09:11 PM

### Using the Subroutine, Continued

Element timing	Now all we have left are subroutines to set the time between our various elements. We want to define all of these from the dit time, so we want some routines like the following:		
	; Delay a dit time DitTime		
	nop return		
	; Delay a dah time DahTime		
	call DitTime call DitTime		
	call DitTime		
	return		
	; Delay a letter space LetSpc		
	call DahTime ; OK, too long		
	return		
	; Delay a word space WordSpace		
	call DahTime		
	call DahTime		
	return		
	For now, we are making our dit time pretty short a call plus a nop plus a return is only 5 cycles, or just over 1 microsecond at 20 MHz. We'll work on that later.		
Testing	Now, if you assemble the program and run it, you can watch the single bit in the file register memory (H'20') flash out T E S T in animate mode. (You may want to		
	download the program from amqrp.org rather than typing).		
Optimizing	You might have noticed that our transmitter on and off routines are really only one instruction. This seems very un-QRP-like. Had we put the bit set/clear in line, we would have used only one instruction instead of three.		
	Either is a perfectly good choice. In this case, there are probably good odds that you may want to do something else when you turn on the transmitter, and having that code separate will make these changes easier.		
	On the other hand, having the code inline is smaller and faster.		

 Revised: 03 Jan 2004 - 09:11 PM
 Page 11 of 14

 Printed: 03 Jan 2004 - 09:11 PM
 John J. McDonough, WB8RCR

### **Timing Loops**

Introduction	It's an odd thing, for a lot of our programs, the PIC will spend most of it's time wasting time. Here we are going to look at how to waste time!  Make yet another project, Lesson6c, but instead of adding an empty Lesson6c.asm file, copy Lesson6b.asm to Lesson6c.asm and add the filled up Lesson6c.asm to your project.		
Counting the hours	Let's see if we can burn enough time with a simple loop. By my calculations, 20 WPM code means about 55 milliseconds per dit. Add a new variable, L1, and change DitTime to look like the following:		
	DitTime		
		movlw	Н'00'
		movwf	L1
	DitTime1		
		decfsz	L1,F
		goto	DitTime1
		return	
	This will spend a lot of time looping around in DitTime1. Now, we could calculate how long this loop will take. Each instruction takes 4 cycles at the crystal frequency, unless that instruction changes the program counter, in which case, it will take twice that. As an example, every time through the loop, the decfsz instruction will take four cycles except the last time, when it does the skip. On the last loop, the decfsz instruction will take 8 cycles.  If we are using a 4 MHz crystal (as we are in the PIC-EL), one instruction, four cycles, conveniently works out to 1 microsecond.		
	The MPLAB IDE included how long a particular		ch feature, however, which allows us to simulate vill take.

Continued on next page


Revised: 03 Jan 2004 - 09:11 PM

Printed: 03 Jan 2004 - 09:11 PM\_

#### Timing Loops, Continued

#### **Stopwatch**

Assemble the modified program. In the DahTime subroutine, add a breakpoint before each of the call DitTime calls.



Now, Select Debugger->Stopwatch from the menu. Check that the processor frequency is shown as 4 MHz. If not, select Debugger->Settings and set the processor to 4 MHz on the Clock tab.

Run the program to the first breakpoint. Click Zero on the stopwatch. Now run the program until the next breakpoint. The stopwatch will measure how long it will take to call the DitTime routine and return. 773 microseconds sounds like a long way from 55 milliseconds.

What if we put another loop inside of our first loop? This way we can waste a lot of time a lot of times!

Just after DitTime1 try something like:

movlw H'00'
movwf L2

DitTime2

decfsz L2,F
goto DitTime2

Running the experiment again gives us something like 197 msec. Too slow, but at least we're on the same planet. If we change our outer loop constant to H'47', though, we will come in to our 20 word per minute time.

In this case, we really only wanted one timer, and everything else was based off of that. In some other cases, we may want a timer to click off, say, a millisecond, and have other timers of 100 msec., 1 second, 1 minute, etc.

 Revised: 03 Jan 2004 - 09:11 PM
 Page 13 of 14

 Printed: 03 Jan 2004 - 09:11 PM
 John J. McDonough, WB8RCR

### Wrap Up

Summary	In this lesson, we have looked at subroutines, and we have studied how the subroutine concept can help us break a fairly complex problem down into small, manageable pieces.  We also took a look at timing loops, and got an idea about how an actual application might look.
Coming Up	In the next lesson, we are going to go back and revisit the status word to see how it can help us overcome the limitation of only having variables with 256 possible values.

Revised: 03 Jan 2004 - 09:11 PM Printed: 03 Jan 2004 - 09:11 PM