Launch HDW Daemon

```
pi@pi4-hdw:~/Desktop/hdw/hdw_node $ ./HarDWareDaemon.sh
pi@pi4-hdw:~/Desktop/hdw/hdw_node $
```

Observe processes

```
[!] HDW is running!
        4886.HDW Report (09/22/2021 06:01:07 PM)      (Detached)
        4875.HDW Collect     (09/22/2021 06:01:06 PM)      (Detached)
        4867.HDW Checkin     (09/22/2021 06:01:06 PM)      (Detached)
pi@pi4-hdw:~/Desktop/hdw/hdw_node $
```

Observe report

Stop HDW Daemon