

- (XBOX boot mp3 will be included in this pdf's folder)

Get a **microSD card (≤32GB, FAT32)**

Plug it into your PC

Format it to FAT32

- Right click → Format → FAT32 → Start

Add your sound file

- Must be **.mp3**
- Rename it like this:

0001.mp3

Put it in the **root of the SD card** (not inside folders)

Safely eject the SD card

Insert it into the DFPlayer