

Microwave Hood Combination

Use & Care Guide

Combinación Microondas Campana

Guía de uso y cuidado

Models/Modelos 665.60622

665.60629




Table of Contents

Warranty2	
Sears Service3	
Microwave Oven Safety4	
Installation Instructions7	
Getting to Know Your	
Microwave Oven8	
How your microwave oven works8	
Radio interference8	
Testing your microwave oven8	
Testing your dinnerware or cookware9	
Operating tips9	
Electrical connection9	
Microwave oven features10	
Control panel features11	
Using the cooking rack14	
Using the exhaust fan14	
Using the cooktop/countertop light15	
Setting the clock15	
Using the kitchen timer16	
Using ADD ONE MINUTE17	
Changing preset cooking times17	
Using Your Microwave Oven18	
Cooking at high cook power18	
Cooking at different cook powers18	
Cooking in stages20	
Progress bar21	
Using AUTO COOK22	
Using AUTO REHEAT23	
Using ZIP DEFROST24	
ZIP DEFROST chart26	
Defrosting tips27	
Using BREAD DEFROST28	
Using POPCORN28 Using BEVERAGE29	
USING BEVERAGE29	
Using BAKED POTATO29	
Using FRESH VEGETABLE30	
Using FROZEN VEGETABLE31	
Using HOLD WARM32	
Caring for Your Microwave Oven33	
Installing and caring for filters34	
Replacing the cooktop and oven lights35	
Cooking Guide36	
Questions and Answers38	
Troubleshooting39	
Index41	
ServiceBack Cover	

Microwave Oven Warranty

FULL ONE-YEAR WARRANTY ON MICROWAVE OVEN

For one year from the date of purchase, if this Kenmore Microwave Oven fails due to a defect in material or workmanship, Sears will repair it free of charge.

FULL FIVE-YEAR WARRANTY ON THE MAGNETRON

For five years from the date of purchase, if the magnetron in this Kenmore Microwave Oven fails due to a defect in material or workmanship, Sears will repair it free of charge.

The above warranty coverage applies only to Microwave Ovens which are used for private household purposes.

WARRANTY SERVICE IS AVAILABLE BY SIMPLY CONTACTING THE NEAREST SEARS STORE OR SERVICE CENTER IN THE UNITED STATES.

This warranty applies only while this product is in use in the United States.

This warranty gives you specific legal rights, and you may also have other rights which vary from state to state.

Sears, Roebuck and Co., Dept. 817WA, Hoffman Estates, IL 60179

For service call: 1-800-4-MY-HOMESM (1-800-469-4663)

Please record your model's information.

Whenever you call to request service for your appliance, you need to know your complete model number and serial number. You can find this information on the model and serial number label/plate (see "Microwave oven features" in the "Getting to Know Your Microwave Oven" section). Also, record the other information shown below.

Model Number	
Serial Number	
Purchase Date	

Get it fixed, at your home or ours!

For repair of major brand appliances **in your own home**... no matter who made it, no matter who sold it!

1-800-4-MY-HOMESM Anytime, day or night (1-800-469-4663)

www.sears.com

To bring in products such as vacuums, lawn equipment and electronics for repair, call for the location of your nearest **Sears Parts & Repair Center**

1-800-488-1222 Anytime, day or night

www.sears.com

For the replacement parts, accessories and owner's manuals that you need to do-it-yourself, call **Sears PartsDirect**SM!

1-800-366-PART 6 a.m. – 11 p.m. CST, (1-800-366-7278) 7 days a week

www.sears.com/partsdirect

To purchase or inquire about a Sears Service Agreement:

1-800-827-6655

7 a.m. - 5 p.m. CST, Mon. - Sat.

Para pedir servicio de reparación a domicilio, y para ordenar piezas con entrega a domicilio:

1-888-SU-HOGARSM

(1-888-784-6427)

Au Canada pour service en français: 1-877-LE-FOYER[™] (1-877-533-6937)

SEARS

HomeCentral