Evitics

A. Setting up RFID Readers
   a. RFIDeas - pcProx readers
      i. Go to the website and download the pcProx configuration utility. (Windows only)
         https://www.rfideas.com/support/product-support/pcprox-plus
      ii. Plug in the reader and run the configuration software you just downloaded. It should look like the screen below. Select the "Data format" tab and make selections to match what shows below.