


Using Tightly Coupled Memory with the Nios II Processor

Tutorial



101 Innovation Drive San Jose, CA 95134 www.altera.com

TU-N2060305-2.0



11.0 July 2011







Contents



Chapter 1. Using Tightly Coupled Memory with the Nios II Processor	
Reasons for Using Tightly Coupled Memory	1–1
Tradeoffs	
Guidelines for Using Tightly Coupled Memory	1–2
Hardware Guidelines	
Software Guidelines	1–3
Locating Functions in Tightly Coupled Memory	1–3
Tightly Coupled Memory Interface	
Restrictions	1-4
Dual Port Memories	
Building a Nios II System with Tightly Coupled Memory	1–5
Hardware and Software Requirements	
Modify the Example Design to Include Tightly Coupled Memories	
Create the Tightly Coupled Memories	
Connect and Position the Tightly Coupled Memories	
Add a Performance Counter	
Generate the Qsys System	1–11
Run the Tightly Coupled Memories Examples from the Nios II Command Shell	1–11
Program and Run the Tightly Coupled Memory Project	
Understanding the Tcl Scripts	
Timer Memory	
Exception Stack	
Timer Definitions	
peripheral_subsystem_sys_clk_timer	
peripheral_subsystem_high_res_timer	
1 1 - 7 - 0	
Additional Information	
Document Revision History	Info-1
How to Contact Altera	
Typographic Conventions	Info-1

iv Contents



1. Using Tightly Coupled Memory with the Nios II Processor

This document describes how to use tightly coupled memory in designs that include a Nios® II processor and discusses some possible applications. It also includes a tutorial that guides you through the process of building a Nios II system with tightly coupled memory.

The Nios II architecture includes tightly coupled master ports that provide guaranteed fixed low-latency access to on-chip memory for performance-critical applications. Tightly coupled master ports can be connected to instruction memory and data memory, to allow fixed low-latency read access to executable code as well as fixed low-latency read or write access to data. Tightly coupled masters are dedicated instruction or data master ports on the Nios II core, which is different from the embedded processor's instruction and data master ports.



This document assumes you are familiar with the Nios II tightly coupled memory. For more information, refer to the *Processor Architecture* chapter in the *Nios II Processor Reference Handbook*.

Reasons for Using Tightly Coupled Memory

You can implement one or more of the following functions or modules using tightly coupled memory to enhance the performance of your system:

- Separate exception stack for use only while handling interrupts
- Fast data buffers
- Fast sections of code
 - Fast interrupt handler
 - Critical loop
- Constant access time that is guaranteed not to have arbitration delays

For programs with modest memory requirements, all of the code and data can be held in a tightly coupled memory pair.

Tradeoffs

There are design tradeoffs when using tightly coupled memory, including the following:

- You must balance the benefits of more general speed enhancement provided by a cache, averaged over time, with the specific dedicated memory block consumed by a tightly coupled memory whose sole purpose is to make a single part of the code faster.
- Software guarantees that performance-critical code or data is located in tightly coupled memory. That particular piece of code or data achieves high performance. Locating the code within tightly coupled memory eliminates cache overhead such as cache flushing, loading, or invalidating.

You must divide on-chip memory equitably to provide the best overall combination of tightly coupled instruction memory, tightly coupled data memory, instruction cache, and data cache.

Guidelines for Using Tightly Coupled Memory

This section details the guidelines and limitations that should be taken into consideration when designing the hardware and software with tightly coupled memory.


Hardware Guidelines

The following guidelines apply to Nios II hardware designs that include tightly coupled memory:

- Tightly coupled masters are presented as additional master ports on the Nios II processor.
- An On-Chip Memory component is the only memory that can connect to a tightly coupled master port on the Nios II core.
- A tightly coupled master on a processor must connect to exactly one on-chip memory slave port. This slave port cannot be shared by any other master port.
- Each on-chip memory can be connected to only one tightly coupled master even if it is a dual port memory.
- The availability of the data and instruction master ports for the tightly coupled memory is dependent on the type of Nios II core used.
- When using the On-Chip Memory component as a tightly coupled memory for Nios II, you must always create it as a RAM, not as a ROM. Tightly coupled memories configured as ROM would result in failure.
- To conserve the logic elements, use one 2-kilobyte (KB) tightly coupled memory, rather than two 1-KB tightly coupled memories.

Figure 1 is a block diagram of a simple Nios II system that includes tightly coupled memories and other Qsys System Integration Tool components.

Figure 1. Nios II System with Tightly Coupled Instruction and Data Memory



Software Guidelines

The following two guidelines apply to Nios II software that uses tightly coupled memory:

- Software accesses tightly coupled memory addresses just like any other addresses.
- Cache operations have no effect when targeting tightly coupled memory.

Locating Functions in Tightly Coupled Memory

Assigning data to a tightly coupled data memory also involves using a section attribute. Alternatively, you can include the tightly coupled memory as a #define in the **system.h** file. The name of the memory is followed by _BASE and is used as a pointer to reference the tightly coupled data memory.

The software example in this tutorial provides a source code example showing how to locate a particular source code function in a particular linker section. A function is declared to reside within a linker section with the C section attribute in the file timer_interrupt_latency.h. This C header file locates

timer interrupt latency irq() in the .exceptions section as follows:

externvoid timer_interrupt_latency_irq (void* base, alt_u32 id) __attribute__ ((section
(".exceptions")));

The Nios II Software Build Tools (SBT) creates linker sections for each memory module in the system. A source code function can be located within a particular tightly coupled instruction memory simply by assigning that function to the linker section created for that tightly coupled instruction memory.

The Nios II SBT creates additional linker sections with address mappings that are controlled by Qsys. For the .exceptions section, the physical address offset and memory module in which to base that linker section is manipulated through Qsys. You locate the .exceptions section in a memory module covered by a tightly coupled data memory using the **Exception Vector** field found on the **Core Nios II** tab of the configuration wizard.



For more information about the C section attribute, refer to the *Developing Programs Using the Hardware Abstraction Layer* chapter in section 2 of the *Nios II Software Developer's Handbook*.

Tightly Coupled Memory Interface

The term *tightly coupled memory interface* refers to an Avalon[®]-like interface that connects one master to one slave. Refer to Figure 1. Tightly coupled memory interfaces connect tightly coupled masters to their tightly coupled slaves. Tightly coupled memory interfaces are designed to be connected to one port of an on-chip memory device. These devices are known as "altsyncrams" to Verilog HDL and VHDL designers.

Restrictions

You must observe the following restrictions when designing with tightly coupled memories:

- Tightly coupled slaves must be on-chip memories.
- Only one master and one slave can be connected to a given tightly coupled memory interface, which makes the tightly coupled memory interface a point-to-point connection.
- Tightly coupled slaves have a data width of 32 bits. Tightly coupled memory interfaces do not support dynamic bus sizing.
- Tightly coupled slaves have a read latency of one cycle, a write latency of zero cycles, and no wait states.

When tightly coupled memory is present, the Nios II core decodes addresses internally to determine if the requested instructions or data reside in tightly coupled memory. If the address resides in tightly coupled memory, the Nios II core accesses the instruction or data through the tightly coupled memory interface. Accessing tightly coupled memory bypasses cache memory. The processor core functions as if cache were not present for the address span of the tightly coupled memory. Instructions for managing the cache do not affect the tightly coupled memory, even if the instruction specifies an address in the range occupied by a tightly coupled memory.

Dual Port Memories

Each tightly coupled master connects to one tightly coupled slave over a tightly coupled interface. For this reason, it is helpful to use dual port memories with the tightly coupled instruction master as shown in Figure 1. The tightly coupled instruction master is incapable of performing writes because it accesses code for execution only. Without a second memory port connected to an Avalon Memory-Mapped (Avalon-MM) data master, the system does not have write access to the tightly coupled instruction memory. Without write access, code cannot be downloaded into the tightly coupled memory by the Nios II SBT for Eclipse, which makes development and debugging difficult. Without a second port on the tightly coupled instruction memory, no data master has access to the memory, which means you have no way to view the contents. By making the tightly coupled instruction memory dual port, the embedded processor's data master can be connected to the second port, allowing both reading and writing of data.

Building a Nios II System with Tightly Coupled Memory

This section provides a detailed list of instructions to create a Nios II system in Qsys that uses two tightly coupled memories, one for instruction access and one for data access. These two tightly coupled memories are connected to the Nios II processor as shown in Figure 1 on page 1–3. Additionally, instructions are provided to build a software project to exercise these tightly coupled memories. The output of the software shows that the tightly coupled memories have much faster access times than other on-chip memories.

To build a Nios II system with tightly coupled memory, perform the following steps. These steps are described more fully in the following sections.

- 1. Modify an existing reference design to include tightly coupled memories.
- 2. Create the tightly coupled memories in Qsys.
- 3. Connect the tightly coupled memories to the masters.
- 4. Position the tightly coupled memories in the Nios II processor's address map.
- 5. Specify the Nios II exception address to access tightly coupled instruction memory.
- 6. Add a performance counter.
- 7. Generate the hardware system.
- 8. Create a software project to exercise the tightly coupled memories.
- 9. Execute the software on the new hardware design.
- 10. Change the Tcl scripts and recompile the design to review how the timer settings work.

Hardware and Software Requirements

The following hardware and software are required to perform this exercise:

- Nios II development tools version 11.0 or later
- Quartus[®] II software version 11.0 or later
- One of the following Altera development kit boards:
 - Nios II Embedded Evaluation Kit (NEEK), Cyclone® III Edition
 - Embedded Systems Development Kit (ESDK), Cyclone III Edition
 - Stratix[®] IV GX FPGA Development Kit

Modify the Example Design to Include Tightly Coupled Memories

First, create a new hardware reference design with tightly coupled memories that is based on the Nios II Ethernet standard design example. To create this modified reference design, perform the following steps:

- 1. Navigate to the Nios II Ethernet Standard Design Example web page and locate the Nios II Ethernet Standard design example .zip file that corresponds to your board.
- Extract the files from the downloaded .zip file and copy the niosii_ethernet_standard_<board> directory to a new directory named standard_tcm.
- 3. In the Windows Start menu, choose **Programs > Altera > Quartus II** <*version>* to run the Quartus II software.
- 4. On the File menu, click **Open Project** and browse to the **standard_tcm\niosii_ethernet_standard_**<**board>.qpf** project file. Click **Open**.
- 5. On the Tools menu, click **Qsys**. When prompted, select **eth_std_main_system.qsys** and click **Open** to open the Qsys design.
- 6. Double-click the **cpu** component in the list of available components on the **System Contents** tab to open the Nios II processor configuration wizard.
- 7. Ensure that Nios II/f is selected on the Core Nios II tab.
- 8. Click the **Caches and Memory Interfaces** tab.
- Select the number of instruction master ports in the drop-down list next to Number of tightly coupled instruction master port(s). In this example, select 1 port.
- 10. Change the **Instruction cache** to **4** KB.
- 11. Select the number of instruction master ports in the drop-down list next to **Number of tightly coupled data master port(s)**. In this example, select **1** port.
- 12. Change the **Data cache** to **2** KB and **Data Cache Line Size** to **4** Bytes.
- 13. Click **Finish** to close the Nios II processor configuration wizard.

Two new master ports now appear under the **cpu** component called **tightly_coupled_instruction_master_0** and **tightly_coupled_data_master_0**. These master ports are not yet connected to the slave ports.

Create the Tightly Coupled Memories

In this section you create two types of tightly coupled memories: a tightly coupled instruction memory and a tightly coupled data memory.

- 1. In the **Component Library** tab, double-click **On-Chip Memory** in the **On-Chip** subfolder of the **Memories and Memory Controllers** folder. The On-Chip Memory configuration wizard appears.
- 2. To complete the configuration of this memory, specify the settings listed in Table 1.
- 3. In the **Size** and **Memory** initialization boxes, specify the settings listed in Table 1.

Table 1. On-Chip Memory Default Settings

Properties		Configuration Settings
	RAM	Turn this option on
Memory type	Dual-Port Access	Turn this option on
	Read During Write Mode	This option is DONT_CARE
	Block type	Auto
Size	Memory Width	32
	Total memory size	4 KB
Dood lateress	Slave s1	1
Read latency	Slave s2	1
Memory initialization	Initialize memory content	Turn this option on
	Enable non-default initialization file	Leave this option off
	Enable In-System Memory Content Editor feature	Leave this option off

- 4. Click **Finish** to close the configuration wizard.
- 5. Click the **System Contents** tab and scroll down to the **onchip_memory2_0** component.



You must name the components exactly as they appear in this tutorial. If your component names differ from the names printed here, the software example will not work.

- 6. Right-click **onchip_memory2_0** and rename the component to **tightly_coupled_instruction_memory**.
- 7. To configure a second on-chip memory, in the list of available memory components, double-click **On-Chip Memory (RAM or ROM)**. The On-Chip Memory configuration wizard appears.

8. Configure the settings that are listed in Table 2. Unlike the tightly coupled instruction memory, this memory is single-port. Total memory size for tightly coupled data memory is twice the size of tightly coupled instruction memory at 8 KB.

Table 2. On-Chip Memory Default Settings

Properties		Configuration Settings	
	RAM	Turn this option on	
	Dual-Port Access	Turn this option off	
Memory type	Read During Write Mode	This option is DONT_CARE	
	Block type	Auto	
Cino	Memory Width	32	
Size	Total memory size	8 KB	
Read latency	Slave s1	1	
	Initialize memory content	Turn this option off	
Memory initialization	Enable non-default initialization file	Leave this option off	
	Enable In-System Memory Content Editor feature	Leave this option off	

- 9. Click **Finish** to close the On-Chip Memory configuration wizard.
- 10. Rename the **onchip_memory2_0** component to **tightly_coupled_data_memory**.

Connect and Position the Tightly Coupled Memories

To associate the masters with the tightly coupled memories, perform the following steps:

- 1. To facilitate creating connections between the tightly coupled memory and the Nios II processor, click each new tightly coupled memory and click **Move Up** to move the individual memories just below the cpu component.
- 2. If necessary, click the + to expand the **tightly_coupled_instruction_memory** component.
- 3. Using the connections panel in Qsys, connect the s1 port of tightly_coupled_instruction_memory to the tightly_coupled_instruction_master_0 component listed under the cpu component. To connect a port, click the empty dot at the intersection of the s1 port and the port you want to connect.
- 4. Similarly, connect the s2 port of tightly_coupled_instruction_memory to the cpu data_master port. This connection is shown in Figure 1 on page 1–3 as the Avalon-MM connection between the Avalon-MM data master port and the Avalon-MM slave port on the tightly coupled instruction memory. Port s2 of this dual-port memory is an Avalon-MM slave port, not a tightly coupled slave port because s2 connects to an Avalon-MM master, which is not a tightly coupled master.
- 5. If necessary, click the + to expand the tightly_coupled_data_memory component.
- 6. Connect the s1 port of tightly_coupled_data_memory to tightly_coupled_data_master_0.

- 7. To change the tightly coupled memories to the same clock domain as the cpu, follow these steps:
 - a. Click in the **Clock** column next to clk1 and clk2 for the s1 and s2 ports, respectively, of **tightly_coupled_instruction_memory**. A list of available clock signals appears.
 - b. Select the same clock domain as the cpu from the list of available clocks to connect this clock to the slave ports.
 - c. Similarly, connect reset1 and reset2 for the s1 and s2 ports, respectively, to clk_reset of the clock source.
 - d. Repeat steps a-c for tightly_coupled_data_memory.
- 8. In the **Base** column, enter the base addresses in Table 3 for all tightly coupled memories.


Table 3. Base Addresses for Tightly Coupled Memories

Port	Base
tightly_coupled_instruction_memory s1	0x20000000
tightly_coupled_instruction_memory s2	0x2000000
tightly_coupled_data_memory s2	0x20002000

The **end** addresses automatically update to reflect the memory size that you specified in the configuration wizard. The base address specification is important. Tightly coupled memories must be mapped so that their addresses *do not overlap* with the embedded processor's memories and peripherals that are connected to its Avalon-MM instruction and data masters.

Figure 2 shows the complete system.

Figure 2. Connections for Tightly Coupled Memories



To simplify address decoding, map the high-order address bit to a unique location. By limiting the decoding logic to one bit, you minimize the effect of address decoding on f_{MAX} . The Nios II component works correctly even if the address map is not optimal; however, it displays a warning during system generation.

As an example of optimal address mapping, if all the normal memories and peripherals in your system occupy addresses below 0x2000000, mapping your tightly coupled memories at addresses from 0x2000000 and above satisfies this requirement.

9. To set the exception address of the Nios II processor, open the Nios II processor's configuration wizard. On the **Core Nios II** tab, in the **Exception vector memory:** list, select **tightly_coupled_instruction_memory_s1**.

The address **Offset** fields are populated automatically and are indexed from the base address specified for the memory module on the **System Contents** tab.


Add a Performance Counter

Add a performance counter peripheral so you can compare the performance of the reads and writes to tightly coupled memory to other memories. To add the performance counter, complete the following steps:

- 1. In the **Component Library** tab, click **Peripherals** to expand the list of available components.
- 2. Under **Debug and Performance**, double-click **Performance Counter Unit** to open the Performance Counter configuration wizard.
- 3. Click **Finish**, accepting the default setting of the **3** simultaneously-measured sections.
- 4. Be sure that the component is named **performance_counter**.
- 5. Move the component up just below the tightly coupled memory components. Connect the control_slave port of the **performance_counter** to the cpu's data master port. Figure 3 shows these connections.
- 6. In **performance_counter**, connect clk to the same clock domain as cpu and reset to clk reset of the clock source.

7. In the **Base** column, change the base address of **performance_counter** to 0x09000000.

Figure 3. Connections for the Performance Counter



Generate the Qsys System

To generate and compile the hardware system, perform the following steps:

- 1. In the **Generation** tab, click **Generate**. Click **Save** to save the changes in the Qsys system.
- 2. In the Quartus II software, on the **Processing** menu, click **Start Compilation**.
- When the Quartus II software compilation is finished, on the Tools menu, click Programmer to program the newly generated niosii_ethernet_standard_<board>.sof into the FPGA.

Run the Tightly Coupled Memories Examples from the Nios II Command Shell


To run the tightly coupled memories example from the Nios II command shell, perform the following steps:

- 1. To open a Nios II command shell under Windows, in the Start menu, point to **Programs** > **Altera** > **Nios II EDS** <*version number*>, and click **Nios II** <*version number*> **Command Shell**.
- 2. Navigate to the working directory for your project. The following steps refer to this directory as *project_directory>.*
- 3. Ensure that the working directory and all subdirectories are writable by typing the following command:

chmod -R + w . ←

4. Download the **tcm.zip** file from the Altera web page for the Tightly Coupled Memory tutorial and unzip it into the *<project_directory>* directory. Figure 4 shows the directory structure for the unzipped files.

Figure 4. Project Directory after Unzipping the Files



5. Change to the **software_examples/app/tcm_isr** subdirectory of your <*project_directory>* by typing the following command:

```
cd software examples/app/tcm isr ←
```

6. Create and build the application by typing the following command:

```
./create-this-app ←
```

7. The linker script file, linker.x in the bsp/timer_hal directory includes a new isrs_region located in tightly coupled instruction memory which is adjacent to the tightly_coupled_instruction_memory region. Example 1 shows the new region.

Example 1. isrs_region Listing in linker.x File

```
MEMORY
{
::
:tightly_coupled_instruction_memory : ORIGIN = 0x20000120, LENGTH = 1664
timer_isrs_region : ORIGIN = 0x200007a0, LENGTH = 2048
:
:
:
}
```

8. The **tcmisr.objdump** in the **app/tcm_isr** directory defines the .isrs section located in the tightly coupled instruction memory. Example 2 shows part of this file.

Example 2. isrs Section Listing in tcm_isr.objdump File

Sections:					
Idx Name	Size	VMA	LMA	File off	Algn
0 .entry	0000000	0000000	0000000	00001000	2**5
	CONTENTS,	ALLOC, LOA	AD, READON	LY, CODE	
1 .exceptions	000001a0	20000120	20000120	00013120	2**2
_	CONTENTS,	ALLOC, LOA	AD, READON	LY, CODE	
2 .isrs	000000c4	200007a0	200007a0	000137a0	2**2
	CONTENTS,	ALLOC, LOA	AD, READON	LY, CODE	
3 .text	0000fea4	10000000	10000000	00001000	2**2
	CONTENTS,	ALLOC, LOA	AD, READON	LY, CODE	
4 .rodata	00000650	1000fea4	1000fea4	00010ea4	2**2
	CONTENTS,	ALLOC, LOA	AD, READON	LY, DATA	
5 .rwdata	00001ba0	100104f4	100104f4	000114f4	2**2
	CONTENTS,	ALLOC, LOA	AD, DATA, S	SMALL DATA	
6 .bss	00000154	10012094	10012094	00013094	2**2
	ALLOC, SM	ALL DATA			
	·	_			

Program and Run the Tightly Coupled Memory Project

To program and run a tightly coupled memory project, perform the following steps:

1. To open a terminal session to capture messages from the Nios II processor, type the following command:

```
nios2-terminal ←
```

If your development board includes more than one JTAG cable, you must specify which cable you are communicating with as an argument to the nios2-terminal command. To do so, first type the following command:

```
jtagconfig -r ←
```

Figure 5. jtagconfig Output

```
[NiosII EDS]$ jtagconfig
1> ByteBlaster [LPT1]
Unable to lock chain (Hardware not attached)
2> USB-Blaster [USB-0]
020B40DD EP2C35
```

Figure 5 shows some sample output from the jtagconfig command. This output shows that the active JTAG cable is number 2. Substitute the number of your JTAG cable for the *<cable_number>* variable in the following command:

```
nios2-terminal -c <cable_number> ←
```

2. In your first shell, enter the following command if you have a single JTAG cable:

```
nios2-download -g tcm_isr.elf ←
```

For development boards with more than one JTAG cable, enter the following command:

```
nios2-download -c <cable_number> -g tcm_isr.elf +
```

Figure 6 is a printout of the statistics that shows the higher speeds obtained by leveraging tightly coupled memories. Note that the number of clock cycles for tightly coupled memory is very similar to that of the cached memory. The result demonstrates that tightly coupled memories allow fixed low-latency read access to executable code as well as fixed low-latency read, write, or read and write access to data.



The timing numbers output varies between Nios development boards.

Figure 6. Tightly Coupled Memory versus Cache Example Real-Time Measures

```
Tightly Coupled Memory vs. Cache Example Real-Time Measurements:

Gyclone III (eth_std_main_system).
Interrupt response time:

Checksum Times:

Tightly coupled memory:

Tightly clock cycles.

All 3 memories match.

Tightly coupled memory:

Tightly clock cycles.

Tightly clock cycles.

All 3 memories match.

Tightly coupled memory:

Tightly clock cycles.

All 3 memories match.

Tightly clocks.

Tightly coupled memory:

Tightly clock cycles.

All 3 memories match.

Tightly clocks.

Tightly coupled memory:

Tightly cou
```

Understanding the Tcl Scripts

The following sections describe creating special memory regions for the timer memory interrupt service routines and timer definitions and locating the exception stack in the tightly coupled memory.

Timer Memory

The timer_memory_section.tcl script is located in the bsp/timer_hal directory. This Tcl script reserves 2048 bytes of the tightly coupled instruction memory. The reserved space is used to store the timer interrupt service routines.

The timer_memory_section.tcl script takes the tightly_coupled_instruction memory region and separates out 2048 bytes of the memory region into a new region called timer_isr_region. The next line of code adds a section mapping the .isrs section to the timer isr region. Example 3 shows this code.

Example 3. Timer ISR Region

```
# Create tightly_coupled_memory region.
add_memory_region tightly_coupled_instruction_memory $slave $offset $new_span
# Create a second region called timer_isr memory_region.
add_memory_region timer_isrs_region $slave $split_offset $split_span
# Create memory mapping to map .isrs to timer_isrs_region.
add section mapping .isrs timer isrs region
```

The timer_interrupt_latency.h file is also updated to reflect the change in the section mapping of the timer_interrupt_latency_irq() timer interrupt service routine to .isrs instead of .exceptions. The timer interrupt service routines are now stored in the timer_isr_region.

The interrupt service routines must be located in the new .isrs section. Otherwise, the linker uses the default setting, defeating the purpose of declaring a special memory section for the interrupt service routine.

To locate the interrupt service routines in the new .isrs section, complete the following steps:

- 1. Add a section mapping to map the .isrs section to the newly added memory region.
- 2. Edit your source files to ensure the interrupt service routines are mapped to the new memory section.
- 3. Compile your project files and check the **linker.x** and **tcm_isr.objdump** files to ensure that the section mapping and memory regions are declared correctly and contain the interrupt service routine.



For more information about linker memory regions, refer to the *Nios II Software Build Tools* chapter in the *Nios II Software Developer's Handbook*.

Exception Stack

The timer_memory_section.tcl script locates the exception stack in the tightly_coupled_data_memory region. Example 4 shows this code.

Example 4. Exception Stack

```
# Locate the exception stack to tightly coupled data memory.
set_setting hal.linker.enable_exception_stack TRUE
set_setting hal.linker.exception_stack_memory_region_name tightly_coupled_data_memory.
aset setting hal.linker.exception stack size 1024
```

Timer Definitions

The following sections describe peripheral_subsystem_sys_clk_timer and peripheral_subsystem_high_res_timer.

peripheral subsystem sys clk timer

The **timer_definition.tcl** script is located in the **bsp/timer_hal** directory. The script defines the timers as follows:

```
set_setting hal.sys_clk_timer peripheral_subsystem_sys_clk_timer
set_setting hal.timestamp_timer none
```

This script is essential for the clocks definitions. The software driver hal.sys_clk_timer must be driven by the hardware clock named peripheral_subsystem_sys_clk_timer. Connecting hal.sys_clk_timer to any other hardware timer results in a compilation error. The following exercise demonstrates this point.

1. Delete or rename the **Makefile** in the **app/tcm_isr** folder. Then delete or rename **public.mk** from the **bsp/timer_hal** folder.

2. Open the timer_definition.tcl file and change

```
peripheral_subsystem_sys_clk_timer to
peripheral_subsystem_high_res_timer as follows:
set_setting hal.sys_clk_timer peripheral_subsystem_high_res_timer
set setting hal.timestamp timer none
```

- 3. Save timer definition.tcl.
- 4. Return to your shell and recreate the application by typing:

```
./create-this-app ←
```

5. Figure 7 shows the error. Setting hal.sys_clk_timer to any other timers except for peripheral subsystem sys clk timer results in the same error message.

Figure 7. Error Message after Changing the hal.sys clk_timer

```
Info: Linking tcm_isr.elf
nios2-elf-g++ -T'..../bsp/timer_hal//linker.x' -msys-crt0='..../bsp/timer_hal
//obj/HAL/src/crt0.o' -msys-lib=hal_bsp -L../../bsp/timer_hal/ -Wl,-Map=tcm_is
r.map -00 -g -Wall -EL -mhw-div -mhw-mul -mno-hw-mulx -o tcm_isr.elf obj/./
tcm.o obj/./timer_interrupt_latency.o -lm
obj/./tcm.o: In function 'alt_main':
c:\rotation\tightly_coupled_memory\3c25\niosii-ethernet-standard-3c25\niosii-eth
ernet-standard-3c25\software_examples\app\tcm_isr/tcm.c:337: warning: Error: Sys
tem clock timer must be configured as sys_clk_timer.
__alt_invalid will be used to invoke linker error.
obj/./tcm.o: In function 'main':
tcm.c:(.text+0x278): undefined reference to '__alt_invalid'
collect2: ld returned 1 exit status
make: **** [tcm_isr.elf] Error 1
make failed
bash-3.1$
```

peripheral subsystem high res timer

The hardware timer called peripheral_subsystem_high_res_timer calculates interrupt latency. timer_interrupt_latency_init(), defined in timer_interrupt_latency.c, installs an interrupt service routine to handle peripheral_subsystem_high_res_timer. Therefore, peripheral_subsystem_high_res_timer must not be tied to the software timestamp driver, hal.timestamp_timer; it is set to none. Because peripheral_subsystem_sys_clk_timer is used for hal.sys_clk_timer, it must not be used for hal.timestamp_timer.

The following exercise shows this point:

- 1. If you have not already done so, delete or rename **Makefile** in the **app/tcm_isr** folder. Delete or rename **public.mk** in the **bsp/timer_hal** folder.
- 2. Open the timer_definition.tcl file and change the setting of hal.timestamp_timer from none to peripheral_subsystem_high_res_timer as follows:

```
set_setting hal.sys_clk_timer peripheral_subsystem_sys_clk_timer
set_setting hal.timestamp_timer peripheral_subsystem_high_res_timer
```

- 3. Save timer_definition.tcl.
- 4. Return to your shell and recreate the application by typing the following command:

```
./create-this-app ←
```

Understanding the Tcl Scripts

5. Figure 8 shows the error that you get. Setting hal.timestamp_timer to peripheral_subsystem_sys_clk_timer or peripheral_subsystem_high_res_timer results in the same error message. Setting hal.timestamp_timer to other hardware timers in the system will not result in the error message in Figure 8.

Figure 8. Error Message after Changing the hal.timestamp_timer

```
Info: Linking tcm_isr.elf
nios2-elf-g++ -T'../../bsp/timer_hal//linker.x' -msys-crt0='../../bsp/timer_hal
//obj/HAL/src/crt0.o' -msys-lib=hal_bsp -L../../bsp/timer_hal/ -Wl,-Map=tcm_is
r.map -00 -g -Wall -EL -mhw-div -mhw-mul -mno-hw-mulx -o tcm_isr.elf obj/./
tcm.o obj/./timer_interrupt_latency.o -lm
obj/./tcm.o: In function 'alt_main':
c:\rotation\tightly_coupled_memory\3c25\niosii-ethernet-standard-3c25\niosii-eth
ernet-standard-3c25\software_examples\app\tcm_isr/tcm.c:339: warning: Error: Sys
tem clock and high res timer cannot be defined as timestamp timer. Please use a
different timer.
__alt_invalid will be used to invoke linker error.
obj/./tcm.o: In function 'main':
tcm.c:\.text+0x278\): undefined reference to '__alt_invalid'
collect2: ld returned 1 exit status
make: **** [tcm_isr.elf] Error 1
make failed
bash-3.1$_
```



This chapter provides additional information about the document and Altera.

Document Revision History

The following table shows the revision history for this tutorial.

Date	Version	Changes
		Converted to new 8.5 x 11" template.
July 2011	2.0	Replaced references to SOPC Builder with Qsys.
		■ Minor text edits.
April 2009	1.1	Minor updates to reflect latest software updates.
July 2008	1.0	Updated to use Quartus II 8.0 and SOPC Builder 8.0. Revised design example instructions to the command line tools instead of the Nios II IDE.
July 2005		Initial release.

How to Contact Altera

To locate the most up-to-date information about Altera products, refer to the following table.

Contact (1)	Contact Method	Address
Technical support	Website	www.altera.com/support
Technical training	Website	www.altera.com/training
recinical training	Email	custrain@altera.com
Product literature	Website	www.altera.com/literature
Non-technical support (General)	Email	nacomp@altera.com
(Software Licensing)	Email	authorization@altera.com

Note to Table:

(1) You can also contact your local Altera sales office or sales representative.

Typographic Conventions

The following table shows the typographic conventions this document uses.

Visual Cue	Meaning
Bold Type with Initial Capital Letters	Indicate command names, dialog box titles, dialog box options, and other GUI labels. For example, Save As dialog box. For GUI elements, capitalization matches the GUI.
bold type	Indicates directory names, project names, disk drive names, file names, file name extensions, software utility names, and GUI labels. For example, qdesigns directory, \mathbf{D}: drive, and \text{chiptrip.gdf} file.

Visual Cue	Meaning	
Italic Type with Initial Capital Letters	Indicate document titles. For example, Stratix IV Design Guidelines.	
	Indicates variables. For example, $n + 1$.	
italic type	Variable names are enclosed in angle brackets (< >). For example, <file name=""> and <project name="">.pof file.</project></file>	
Initial Capital Letters	Indicate keyboard keys and menu names. For example, the Delete key and the Options menu.	
"Subheading Title"	Quotation marks indicate references to sections within a document and titles of Quartus II Help topics. For example, "Typographic Conventions."	
	Indicates signal, port, register, bit, block, and primitive names. For example, \mathtt{datal} , \mathtt{tdi} , and \mathtt{input} . The suffix \mathtt{n} denotes an active-low signal. For example, \mathtt{resetn} .	
Courier type	Indicates command line commands and anything that must be typed exactly as it appears. For example, c:\qdesigns\tutorial\chiptrip.gdf.	
	Also indicates sections of an actual file, such as a Report File, references to parts of files (for example, the AHDL keyword SUBDESIGN), and logic function names (for example, TRI).	
4	An angled arrow instructs you to press the Enter key.	
1., 2., 3., and a., b., c., and so on	Numbered steps indicate a list of items when the sequence of the items is important, such as the steps listed in a procedure.	
	Bullets indicate a list of items when the sequence of the items is not important.	
	The hand points to information that requires special attention.	
?	A question mark directs you to a software help system with related information.	
	The feet direct you to another document or website with related information.	
CAUTION	A caution calls attention to a condition or possible situation that can damage or destroy the product or your work.	
WARNING	A warning calls attention to a condition or possible situation that can cause you injury.	
	The envelope links to the Email Subscription Management Center page of the Altera website, where you can sign up to receive update notifications for Altera documents.	