## File 20120301.1437: Steps in the HAZOP application:

- 1. Transform the process into a process flow diagram with analogous components to pipes, valves, reactors, mixers, heat exchangers, monitoring instruments.
- 2. Divide the PFD into small sections with defined flows among them.
- 3. Define the intention of each section.
- 4. Define significant deviations from each intension, causes, and consequences.
- 5. Identify the safeguards protecting against each deviation/consequence, and whether they are sufficient.

## Standard guide words are:

- NO or NOT (complete negation of the design intent)
- MORE (too much—pressure, flow, level, time)
- LESS (not enough)
- AS WELL AS (generally the right stuff but not quite right)
- PART OF (something else in addition to what's supposed to be there)
- REVERSE (flowing the wrong way)
- OTHER THAN (totally wrong input)
- EARLY (time)
- LATE (time)
- BEFORE (e.g., deploy before inspected) (ordering)
- AFTER (ordering)

## References