

Group 0: System / Group Toggles



→ Group 1 - Keyboard



→ Group 2 - Mouse



→ Group 3 - Macros



→ Group 4 - Scanning



→ Group 4 - Scanning



→ Group 5 - Media



→ Group 6



→ Group 7



→ Group 8




→ Group 9 - Switch


Legend

- dot
- dash
- **Group** group switch
- Mouse** mouse / move / click
- Media** consumer controls
- App** application launcher
- Secret** private macro (value hidden)
- Mod** modifier / lock
- System** repeat / system
- iOS** iOS Switch Control action (Group 4)
- Key** keyboard key

Group 1: Keyboard

	A		R		8
	B		S		9
	C		T		_
	D		U		-
	E		V		,
	F		W		;
	G		X		:
	H		Y		!
	I		Z		?
	J		0		.
	K		1		'
	L		2		"
	M		3		(
	N		4		)
	O		5		[
	P		6		]
	Q		7		{

Group 2: Mouse & Windows

Group 3: Macros

	0		phrase
	1		phrase
	2		phrase
	3		phrase
	4		phrase
	5		phrase
	6		phrase
	7		phrase
	8		phrase
	9		phrase
			phrase
			phrase
	phrase		address
	phrase		email
	phrase		Lock secrets
	phrase		name
	phrase		password1
	phrase		phone
			Unlock secrets (PIN)
			wifi

Group 4: Scanning - Enter, Space, F3-F12 (Switch Control)

	B		4
	C		5
	F		6
	G		7
	H		8
	J		9
	L		Select Item ↵
	M		Previous Item F3
	O		Scanner Menu F4
	P		Home F5
	Q		Tap F6
	V		Long Press F7
	X		Scroll Down F8
	Y		Scroll Up F9
	Z		App Switcher F10
	0		Notif/Control Center F11
	1		Siri F12
	2		Next Item SPACE
	3		

Group 5: Media + App Launchers (USB HID Consumer Controls)



C



G



H



J



M



O



P



Q



V



X



Y



Z



0



1



2



3



4



5



6



7



8



9



🎵 Brightness -



🎵 Brightness +



🎵 Eject



🎵 Fast Forward



🎵 Mute



🎵 Next Track



🎵 Play / Pause



🎵 Prev Track



🎵 Rewind



🎵 Stop



🎵 Volume -



🎵 Volume +



📊 Calculator



📁 File Explorer



📧 Mail






🌐 Web Browser

Group 6 (placeholder)

	A		T
	B		U
	C		V
	D		W
	E		X
	F		Y
	G		Z
	H		0
	I		1
	J		2
	K		3
	L		4
	M		5
	N		6
	O		7
	P		8
	Q		9
	S		

Group 7 (placeholder)

	A		U
	B		V
	C		W
	D		X
	E		Y
	F		Z
	G		0
	H		1
	I		2
	J		3
	K		4
	L		5
	M		6
	N		7
	O		8
	P		9
	Q		Frequently typed phrase
	T		My favourite string here

Group 8 (placeholder)

	A		U
	B		V
	C		W
	D		X
	E		Y
	F		Z
	G		0
	H		1
	I		2
	J		3
	K		4
	L		5
	M		6
	N		7
	O		8
	P		9
	Q	 Frequently typed phrase	
	T	 My favourite string here	

Group 9: Switch - sip holds Enter, puff holds Space (no Morse)



Hold Enter (while you sip)



Hold Space (while you puff)

No Morse codes in this group. The key goes down the moment a sip or puff starts and comes up when it ends - like two plain switches.

To leave (goes to Keyboard): wait 20 seconds without a sip or puff, or hold one puff for 5 seconds. The screen counts down the last 10 seconds, e.g. "KEYBOARD IN 5".