

Group 0: System / Group Toggles



→ Group 1 - Keyboard



→ Group 2 - Mouse



→ Group 3 - Macros



→ Group 4 - Scanning



→ Group 4 - Scanning



→ Group 5 - Media



→ Group 6



→ Group 7



→ Group 8



→ Group 9 - Switch

Legend

- dot
- dash
- **Group** group switch
- Mouse** mouse / move / click
- Media** consumer controls
- App** application launcher
- Secret** private macro (value hidden)
- Mod** modifier / lock
- System** repeat / system
- iOS** iOS Switch Control action (Group 4)
- Key** keyboard key

Group 1: Keyboard

	A		R		8
	B		S		9
	C		T		_
	D		U		-
	E		V		,
	F		W		;
	G		X		:
	H		Y		!
	I		Z		?
	J		0		.
	K		1		'
	L		2		"
	M		3		(
	N		4		)
	O		5		[
	P		6		]
	Q		7		{

Group 2: Mouse & Windows

Group 3: Macros

	0		phrase
	1		phrase
	2		phrase
	3		phrase
	4		phrase
	5		phrase
	6		phrase
	7		phrase
	8		phrase
	9		phrase
			phrase
			phrase
	phrase		address
	phrase		email
	phrase		Lock secrets
	phrase		name
	phrase		password1
	phrase		phone
			Unlock secrets (PIN)
			wifi

Group 4: Scanning - Enter, Space, F3-F12 (Switch Control)

	B			4
	C			5
	F			6
	G			7
	H			8
	J			9
	L		Select Item	
	M		Previous Item	F3
	O		Scanner Menu	F4
	P		Home	F5
	Q		Tap	F6
	V		Long Press	F7
	X		Scroll Down	F8
	Y		Scroll Up	F9
	Z		App Switcher	F10
	0		Notif/Control Center	F11
	1		Siri	F12
	2		Next Item	SPACE
	3			

Group 5: Media + App Launchers (USB HID Consumer Controls)



C



6



G



7



H



8



J



9



M



🎵 Brightness -



O



🎵 Brightness +



P



🎵 Eject



Q



🎵 Fast Forward



V



🎵 Mute



X



🎵 Next Track



Y



🎵 Play / Pause



Z



🎵 Prev Track



0



🎵 Rewind



1



🎵 Stop



2



🎵 Volume -



3



🎵 Volume +



4



🖨 Calculator



5



🖨 File Explorer



🖨 Mail



🖨 Web Browser

Group 6 (placeholder)

	A		T
	B		U
	C		V
	D		W
	E		X
	F		Y
	G		Z
	H		0
	I		1
	J		2
	K		3
	L		4
	M		5
	N		6
	O		7
	P		8
	Q		9
	S		

Group 7 (placeholder)

	A		U
	B		V
	C		W
	D		X
	E		Y
	F		Z
	G		0
	H		1
	I		2
	J		3
	K		4
	L		5
	M		6
	N		7
	O		8
	P		9
	Q		Frequently typed phrase
	T		My favourite string here

Group 8 (placeholder)

	A		U
	B		V
	C		W
	D		X
	E		Y
	F		Z
	G		0
	H		1
	I		2
	J		3
	K		4
	L		5
	M		6
	N		7
	O		8
	P		9
	Q		Frequently typed phrase
	T		My favourite string here

Group 9: Switch - sip holds Enter, puff holds Space (no Morse)



Hold Enter (while you sip)



Hold Space (while you puff)

No Morse codes in this group. The key goes down the moment a sip or puff starts and comes up when it ends - like two plain switches.

To leave (goes to Keyboard): wait 20 seconds without a sip or puff, or hold one puff for 5 seconds. The screen counts down the last 10 seconds, e.g. "KEYBOARD IN 5".