Group 0: System / Group Toggles

●▬●▬●▬	CTRL + Alt + D
●●▬●●▬	CTRL + Alt + H
●●●●●●●●	→ Group 1 - Keyboard
▬▬▬▬▬▬▬▬	→ Group 2 - Mouse
●●●●▬▬▬▬	→ Group 3 - Macros
●●●●●●●▬	→ Group 4 - Scanning
▬▬▬▬●●●●	→ Group 4 - Scanning
●●●●●●▬▬	→ Group 5 - Media
●●●●▬▬▬	→ Group 6
●●●▬▬▬▬	→ Group 7
●●▬▬▬▬▬	→ Group 8
●▬▬▬▬▬▬	→ Group 9 - Switch


Legend


● dot ▬ dash **→ Group** group switch **Mouse** mouse / move / click **Media** consumer controls

App application launcher **Secret** private macro (value hidden) **Mod** modifier / lock

System repeat / system **iOS** iOS Switch Control action (Group 4) **Key** keyboard key

Group 1: Keyboard




}
⏎
F10
@
$
F11
*
←
F12
/
↑
HOME
\
↓
INS
&
→
PgDn
#
DEL
PgUp
%
END
SPACE
`
ESC
CAPS
^
F1
KP NumLk
⇥
F2
LAlt
+
F3
LCTRL
<
F4
LEFT ⊞/⌘
=
F5
LShift
>
F6
PrtScn
|
F7
ScrLk
~
F8
Repeat last
⌫
F9
→ Group 2 - Mouse

Group 2: Mouse & Windows


⇥


=


←


↑


↓


→


ESC


F5


HOME


KP -


KP .


KP *


KP /


KP +


KP ⏎


Menu


PgDn


PgUp


Click left


Click right


Dbl-click left


Dbl-click right


Fast speed


Move ←


Move ←


Move →


Move →


Move ↑


Move ↑


Move ↓



Move ↓



Move ↖


Move ↗


Move ↘


Move ↙


Scroll ↑


Scroll ↓


Slow speed



Toggle drag L


⊞/⌘ + ⇥


Alt + ⇥


CTRL + Alt + HOME


KP NumLk


RAlt


RCTRL



RCTRL + RAlt + ←


RIGHT ⊞/⌘


RShift


Tap CTRL


Repeat last



Repeat last

Restart device (confirm y)

Show version screen

→ Group 1 - Keyboard

Group 3: Macros



Group 4: Scanning - Enter, Space, F3-F12 (Switch Control)




B



C



F



G



H



J



L



M



O



P



Q



V



X



Y




Z




0



1




2



3




4



5



6



7



8



9



Select Item

⏎



Previous Item

F3



Scanner Menu

F4



Home

F5



Tap

F6




Long Press

F7




Scroll Down

F8




Scroll Up

F9




App Switcher

F10



Notif/Control Center

F11



Siri


F12




Next Item

SPACE


Group 5: Media + App Launchers (USB HID Consumer Controls)





Group 6 (placeholder)

	A
	B
	C
	D
	E
	F
	G
	H
	I
	J
	K
	L
	M
	N
	O
	P
	Q
	S

	T
	U
	V
	W
	X
	Y
	Z
	0
	1
	2
	3
	4
	5
	6
	7
	8
	9
	🔒 bank_login

Group 7 (placeholder)

	A
	B
	C
	D
	E
	F
	G
	H
	I
	J
	K
	L
	M
	N
	O
	P
	Q
	T

	U
	V
	W
	X
	Y
	Z
	0
	1
	2
	3
	4
	5
	6
	7
	8
	9
	Frequently typed phrase
	My favourite string here

Group 8 (placeholder)

	A
	B
	C
	D
	E
	F
	G
	H
	I
	J
	K
	L
	M
	N
	O
	P
	Q
	T

	U
	V
	W
	X
	Y
	Z
	0
	1
	2
	3
	4
	5
	6
	7
	8
	9
	Frequently typed phrase
	My favourite string here

Group 9: Switch - sip holds Enter, puff holds Space (no Morse)

`Hold Enter (while you sip)`	`Hold Space (while you puff)`

No Morse codes in this group. The key goes down the moment a sip or puff starts and comes up when it ends - like two plain switches.

To leave (goes to Keyboard): wait 20 seconds without a sip or puff, or hold one puff for 5 seconds. The screen counts down the last 10 seconds, e.g. "KEYBOARD IN 5".