DI57K-03


## **Back Door Courtesy Switch Circuit**

## **CIRCUIT DESCRIPTION**

The back door courtesy switch is built in the back door lock.

This switch goes on when the back door is opened and goes off when back door is closed.

## **WIRING DIAGRAM**



2002 4RUNNER (RM887U)

Author: Date: 738

## **INSPECTION PROCEDURE**

1 Check back door courtesy switch (See page BE-26).

NG

Replace back door courtesy.

OK

2 Check harness and connector between back door courtesy switch and back door ECU (See page IN-28).

NG

Repair or replace harness or connector.

ΟK

Proceed to next circuit inspection shown on problem symptoms table (See page DI-556).

2002 4RUNNER (RM887U)

Author: Date: 739