Orange Pi LTS 4 Notes

Notes specific to this board

- Armbian for non-raspberry pi board doesn't include pi libraries
 - sudo apt-get install libraspberrypi0
 - sudo ln -fs /usr/lib/aarch64-linux-gnu/libbcm host.so /usr/lib/libbcm host.so.0
 - sudo ln -fs /usr/lib/aarch64-linux-gnu/libvcos.so /usr/lib/libvcos.so.0
 - sudo ln -fs /usr/lib/aarch64-linux-gnu/libvchiq arm.so /usr/lib/libvchiq arm.so.0
 - sudo ldconfig
- Includes WiFi on the board. Worked without any issues
- Recent updates break HDMI output. Install an older stable release and don't update until it is fixed. LFMF.

Orange Pi 5b Notes

Notes specific to this board

- Armbian for non-raspberry pi board doesn't include pi libraries
 - sudo apt-get install libraspberrypi0
 - sudo ln -fs /usr/lib/aarch64-linux-gnu/libbcm host.so /usr/lib/libbcm host.so.0
 - sudo ln -fs /usr/lib/aarch64-linux-gnu/libvcos.so /usr/lib/libvcos.so.0
 - sudo ln -fs /usr/lib/aarch64-linux-gnu/libvchiq arm.so /usr/lib/libvchiq arm.so.0
 - sudo ldconfig
- The release armbian image is **not** configured for the 5b board (no emmc)
 - Open armbianenv.txt and change fdtfile=rockchip/rk3588s-orangepi-5.dtb to fdtfile=rockchip/rk3588s-orangepi-5b.dtb
- Install to emmc with the armbian-install command
- Includes WiFi on the board. Worked without any issues.
- The date may be very wrong. This will cause endless problems and prevent apt from working