	shipping BOM	Left to Right, up to down
1	100u/16v	C1, C2
2	100nF/0.1uf 1n	C3, C23, C24, C66 C5,C22
	10n 1000V	C6, C7, C20
5	270pF 1N4937(二极	C21
6	管)	D1, D2, D3
	3mm LED(红 色草帽) DIP8芯片座	D23, D24 IC1,IC2,U80
9	2.54mm*2插 针	J1, J4,P100,
10	2.54mm*3插 针	P3
	100uH	L1
	10mH	L3
	Beep(蜂鸣	
13	器)	LS1
14	5.08mm接插 件	P2
15	5.5*2.1mm (电源接插 件)	P4
13	S8050 -NPN	F 4
16	三极管-直插	Q1, Q3, Q4
	KSP42-NPN 三极	
17		Q2
	33K	R1, R2
	1K	R3, R23
20	3K	R4
21	100K	R5
22	10M	R7, R8, R9, R10, R11, R33
	10K	R16, R24
24	470K	R17, R19, R20
	47K	R18
26	5.1k	R32

27	100R	R100,3296W
	Switch(电源拨动开	
28	关)	S1
29	tube hold(金属座)	U1
	3.5mm port(耳机接	
30	口)	U110
31	NE555	IC1,IC2
32	LM358	U80
33	copper pillar	
		<u> </u>
	PCB	 *1
	-	
	Geiger Tube J305	*1
	Battery box	*1
	dust cover	*1
		l l

There is more materials you could use.	schmetic, code, BOM, and video
tech. support email:	
kezhouee@gmail.com	
cajoetech@qq.com	
youtube, you could	
follow:	kezhouee@gmail.com

*3

Materials DIY Geiger Counter Kit-v1.1

DuPont line

Power Line

Audio cable